


JUKI

Medium-sized 1-Needle Cylinder-bed, Lockstitch
Computer Control Cycle Machine

AMS-220C

INSTRUCTION MANUAL








No.01

29056009


Congratulations on your purchase of JUKI Model AMS-220C.

Please read this instruction manual carefully before using this unit in order to get the most out of it and to enjoy using it for a long time.


PRECAUTIONS TO BE TAKEN




PRECAUTIONS TO BE TAKEN DURING OPERATION




1. When a pattern change is made, or the needle threading switch or the bobbin winder switch or the feeding frame switch is turned ON, the feeding frame ❶ comes down automatically. So, never put your fingers under the feeding frame. Be sure to keep your fingers away from the feeding frame while the machine is in operation.




2. Be sure to turn the power switch OFF before removing belt cover ❶. Do not operate the machine with the belt cover removed.









3. Be sure to load or unload floppy disk ❶ while the power is ON. If the power switch should be turned ON or OFF with the floppy disk mounted the data stored in the disk may be destroyed.



4. After the power switch is turned ON, the feeding frame will automatically move in the sewing area along the X and Y axes once you press the preparation switch. Be sure not to place anything within the range of the sewing area of cover ❶.




5. When the threader and sewing machine are switched ON, sew the desired sewing pattern with the thread tension disk closed. Once you have completed the thread trimming, the thread tension disk will open.



6. When raising the machine head, be sure to remove side-face cover ①, Y-sensor cover ②, table rear cover ③ and belt cover ④. Then move feeding frame ⑤ to the central position, and raise auxiliary cover ⑥ until stopper ⑦ moves backward to its locked position. To bring the machine head down, push up auxiliary cover ⑥ so that the machine head is slightly raised, and then pull stopper ⑦ toward you so that you can bring the machine head down. Whenever you raise the machine head, the belt will come off, so be sure to re-install the belt before operating the machine. (If machine operation is started with the belt removed, error message ⑦ will be indicated. See the list of error message.)

7. During operation, be careful not to allow your or any other person's head or hands to come close to the handwheel, V belt, bobbin winder or motor. Also, do not place anything near any of these parts while the machine is in operation. Doing so may be dangerous.

8. If your machine is equipped with a belt cover, finger guard, eye guard or any other protections, do not operate your machine with any of them removed.



CONTENTS


I. GENERAL	1
1. Configuration	1
2. Features	2
3. Specifications	3
II. INSTALLATION	5
1. Installing the thread stand	5
2. Installing the pedestal	5
3. Connecting the foot switch	5
4. Connecting the air supply	6
5. Adjusting the belt tension	6
III. OPERATION	7
1. Selecting a suitable needle and needle hole guide	7
2. Attaching a needle	7
3. Threading the machine head	7
4. Installing and removing the bobbin case	8
5. Threading the bobbin case	8
6. Winding the bobbin	8
7. Thread tension	9
8. Adjusting the thread take-up spring	9
9. Operation and switches of the AMS-220C	10
10. Control box and its function	14
11. Operation box and its function	17
12. Foot switch	23
13. Switches on the machine head	23
14. DIP switches on the printed circuit board	25
15. Disk formatting function	36
16. Data backup function	37
17. Needle-up position stop function	38
18. Enlargement/reduction function	39
19. Pattern combination function	40
20. Operation procedure flow chart	44
IV. MAINTENANCE	51
1. Adjusting the height of the needle bar	51
2. Adjusting the needle-to-shuttle relationship	51
3. Adjusting the moving knife and the counter knife	53
4. Adjusting the height of the intermediate presser	53
5. Adjusting the height of the feeding frame	53
6. Adjusting the wiper	54
7. Adjusting the thread breakage detector	54
8. Adjusting the needle-up stop position	55
9. Adjusting the opening amount of tension disk	55
10. Adjusting the vertical stroke of the intermediate presser	56
11. Removing the V belt	58
12. Cleaning the filter	59
13. Changing the direction of rotation of the sewing machine	59
14. Replacing the fuse	59
V. OPTIONS	60
VI. TROUBLES AND CORRECTIVE MEASURES	64
VII. EXPLANATION OF TERMINOLOGY	66
[Dimensions of the feeding frame]	70

I. GENERAL

The AMS-220C is an electronic, 1-needle, cylinder-bed, lockstitch pattern sewing machine. It is an industrial automatic sewing machine designed mainly for sewing on various small parts and for joining fabrics. The sewing machine head is equipped with an exclusive long arm, which permits a wider sewing area. Thanks to the incorporation of a 16-bit microprocessor as the control device and the use of a micro floppy disk as the memory medium, the AMS-220C can successfully perform complicated pattern stitching and embroidering. A large semi-rotary shuttle has been adopted, which reduces the frequency of replacing the bobbin thread. You can easily input patterns into the micro-floppy disk, using the JUKI compact programming device (PGM-1, PGM-5, PGM-10B), available optionally. Before you input new sewing pattern data into the micro-floppy disk, you can do trial sewing to check the result and make any necessary modifications. Furthermore, the sewing machine is provided with a data input function in its main unit (main unit input) as a standard feature. You may input data in accordance with the sewing product while moving the feed using the operation panel.

1. Configuration

The following shows the main components of the AMS-220C:



2. Features

- 1) **Easy pattern change**
The work holder is driven by a stepping motor. You can change a stitching pattern simply by specifying the pattern No. affected.
- 2) **Wider sewing size**
An exclusive long arm provided a sewing area as large as 200 mm x 145 mm (width x length).
- 3) **Large semi-rotary shuttle has been adopted.**
A large semi-rotary shuttle reduces the frequency of replacing the bobbin thread.
- 4) **Complicated pattern stitching and embroidering**
The 16-bit microprocessor for memory storage enables the machine to input a pattern or to embroider with a maximum of 4,000 stitches. Furthermore, if using the combination mode, a pattern with a maximum of 16,000 stitches can be sewn.
- 5) **Wide range of pattern scale**
The X scale and Y scale can be independently set 0.01 to 4 times the original pattern. This function is further supported by JUKI's unique method in which pattern enlargement/reduction is done by increasing or decreasing the stitch length or the number of stitches. The combination of these functions permits highly flexible pattern enlargement and reduction.
- 6) **Capable of inputting various patterns**
Pattern data can be easily entered using either the operation panel, which is mounted on the main unit of the sewing machine as a standard device, or a JUKI compact type programming device, which is available as an option. When pattern data are entered under the main unit input feature, input is made in accordance with the sewing product by moving the feed using the switch in the operation panel, taking the needle as a reference. Programming devices which are separately available
PGM-1 Used with connected to the sewing machine. A small pattern can be input with enlarged using the digitizer input function.
PGM-5 Used with connected to the sewing machine. This high-performance device enables the operator to input data only following the procedure same as the main unit input function.
PGM-10B ... Used independently. It is a personal computer type high-performance programming device, allowing the operator to input data while checking the created pattern on the display.
- 7) **A micro-floppy disk as the memory medium for sewing patterns**
A 3.5-inch micro floppy disk is used. The disk accommodates 44 to 691 patterns.
- 8) **Provided with safety and testing facilities**
The AMS-220C is designed to give error indication upon detection of troubles, enabling you to identify the problem at a glance. In addition, the machine incorporates a facility for testing the switches and other functions. This facility is useful for quick troubleshooting.
- 9) **Easy workpiece setting**
The second origin can be set as desired, so you do not have to care about the position of the needle point when setting a workpiece.
- 10) **A longer stitch length**
The stitch length can be set up to 10 mm.
- 11) **Patterns used for the conventional AMS machines can also be used for the AMS-220.**
 - The AMS-220C is capable of using (reading/writing) pattern data stored in floppy disks used with the AMS-210B, 212B and 220B with no additional operation.
 - It is only capable of reading pattern data used with the AMS-210A, -212A and 220A. However, it is not capable writing pattern data on the floppy disk used with the AMS-210A, -212A and -220A.
- 12) **A compressor unit can be attached to the machine after the set-up.**
A compressor unit is optionally available.
It can be attached to your AMS-220C with no additional machining.
- 13) **A milling unit can be attached to the machine after the set-up.**
A milling unit is optionally available.
It can be attached to your AMS-220C, which allows you to machine a plastic feeding frame or aluminum feeding frame as desired with ease.


3. Specifications

- 1) Sewing area: X (lateral) direction 200 mm
Y (longitudinal) direction 145 mm
- 2) • Max. sewing speed: 2,000 s.p.m.
(for stitch lengths of 3 mm or less)
• Jump speed: 208 mm/sec.
- 3) Stitch length: Max. 10 mm (adjustable in 0.16 mm steps)
- 4) Feed motion of feeding frame: Intermittent feed (2-shaft drive by stepping motor)
- 5) Needle bar stroke: 41.2 mm
- 6) Needle: DP x 5, DP x 17
- 7) Lift of feeding frame: 22 mm (standard) Max. 25 mm
- 8) Intermediate presser stroke: 4 mm (standard) (0, 3 ~ 7 mm)
- 9) Lift of intermediate presser: 20 mm
- 10) Shuttle: Large semi-rotary type (self-lubricated)
- 11) Bobbin case: Large semi-rotary type
- 12) Bobbin: Large shuttle
- 13) Lubricating oil: New Defrix Oil No.2 (supplied by oiler)
- 14) Thread trimmer: Consists of moving knife and counter knife (actuated by grooved cam)
- 15) Wiper: Magnetically driven (with release switch)
- 16) Intermediate presser lifter: Raised/lowered by an air cylinder (with release switch)
- 17) Memory medium: 3.5 inch micro floppy disk
Memory pattern: 44 ~ 691 pattern/cassette
- 18) Sewing operation: Starts/ends at sewing start point or the 2nd origin
- 19) Feeding frame: Descends when the feeding frame switch is pressed. Another press on the switch causes the feeding frame to ascend.
- 20) Start: The machine is started by turning the start switch ON with the feeding frame down.
- 21) Emergency stop facility: Used to stop machine operation during a stitching cycle. After an emergency stop, the feeding frame can be moved along the stitching line by operating the "Backward" or "Forward" switch. The interrupted stitching cycle can be completed by pressing the start switch. Alternatively, the "Return to origin" switch may be pressed for quick move to the sewing start point or the 2nd origin after an emergency stop and the thread trimming.
- 22) Enlarging/Reducing facility: Allows a pattern to be enlarged or reduced on the X axis and Y axis, independently when sewing a pattern.
Scale: 0.01 to 4 times (adjustable in 0.01 steps)
- 23) Enlarging/Reducing method: Pattern enlargement/reduction can be done by increasing/decreasing either stitch length or the number of stitches.
- 24) Max. sewing speed limitation: The maximum sewing speed can be set limited to any value within a range of 180 to 2,000 s.p.m., using the external control knob.
- 25) Pattern selection: 1 to 999 patterns can be selected by specifying the desired pattern Nos.
- 26) Pattern checking facility: A pattern configuration can be checked by setting the "Sewing machine ON/OFF switch" to "OFF".
- 27) Error indication: 17 types of error indication are given.
- 28) Programming: Involves point/linear/arc numeral data, temporary stop, thread trim, jump data, sewing speed, and stitch length.
- 29) Bobbin thread counter: Tells the time to replace the bobbin. If this facility is not used, it works as a 0 ~ 999 ring counter with resetting function.
- 30) Memory backup: In case of a power interruption, the pattern being used will automatically be stored in memory so that the interrupted sewing cycle may be resumed simply by pressing the Set Ready switch after the power is restored. No floppy disk is necessary. The memory is held for 100 hrs.
- 31) 2nd origin setting facility: Using jog keys, a 2nd origin (needle position after a sewing cycle) can be set in the desired position within the sewing area. The set 2nd origin is also stored in memory.
- 32) Needle-up stop facility: When the needle does not stop in its upper position, the needle can be brought up to the upper position by turning the needle threading switch ON or OFF. (provided the READY lamp is ON)

- 33) Sewing machine motor: 400W, 4P electronic-stop motor
- 34) Demensions: 1,090 mm (W) × 1,105 mm (L) × 1,150 mm (H) (excluding thread stand)
- 35) Gross weight: 270 kg
- 36) Power consumption: 1 KVA
- 37) Operating temperature range: 5° to 40°C
- 38) Operating humidity range: 20 to 80% (no dew condensation)
- 39) Line voltage: Rated voltage ±10% 50/60 Hz
- 40) Air pressure used: 5 ~ 5.5 kg/cm²
- 41) Air consumption: 1.8 l/min


II. INSTALLATION

1. Installing the thread stand




Assemble the thread stand, and put it in the hole in the top right corner of the machine table. Tighten locknut ① to fix the thread stand. When ceiling wiring is possible, pass the power cord through spool rest rod ②.

2. Installing the pedestal




- 1) Install the pedestal on a flat place.
- 2) Loosen nut ①, and raise caster ③ until it starts idling by turning lever adjuster ②. After the installation, fix level adjuster ② by tightening nut ①.
- 3) The table height is adjusted by loosening eight bolts ④ located at the right and left sides of the pedestal. At this time, be sure to adjust the table height while holding the table at four corners ④ by four persons.

3. Connecting the foot switch




Connect cables ① of the feeding frame and start switch to connector ② of the control box.

4. Connecting the air supply



- 1) Securely connect air supply hose (inside diameter 8 mm x outside diameter 12 mm) to quick-coupling joint ①.
 - 2) Open air cock ②. Pull up air adjusting knob ③, and adjust the air pressure so that air gauge ④ indicates 5 to 5.5 kg/cm² by turning the knob.
 - 3) If the air pressure is lower than 4 kg/cm², the machine stops while indicating error **A** on the display.
- * Close air cock ②, and press push-button ⑤. At this time, the air pressure becomes 0 kg/cm².

5. Adjusting the belt tension



Adjust the belt tension using adjusting nut ① so that the belt slacks about 10 mm when an approximately 1 kg pushing force is applied to part A.

(Caution)

Remove the intermediate presser before installing/removing the belt.


III. OPERATION

1. Selecting a suitable needle and needle hole guide

Material	Needle	Inside diameter of needle hole guide	Thread	Class of work
Extra light-weight	~ # 11 DPx5 (DPx17)	Ø1.6 for knit	~ #60	Knit, tricot
Synthetic	#11 ~ #14 DPx5 (DPx17)	Ø1.6	#60 ~ #30	Men's wear, ladies' wear
Medium-weight	#14 ~ #18 (DPx5) DPx17	Ø2, Ø2.4	#30 ~ #20	Men's wear, ladies' wear, chemical shoes
Heavy-weight	#18 ~ #21 (DPx5) DPx17	Ø2.4, Ø3	#20 ~ #8	Working wear, coats, bags
Extra heavy-weight	#22 ~ #25 (DPx5) DPx17	Ø3, Ø3 with spot facing	#8 ~ #2	Seat belts, leather

* The combinations shown in the above table are mere references. Consequently, the combination may change in accordance with the sewing conditions specified.

2. Attaching a needle




Move wiper ③ in the direction of the arrow, and loosen setscrew ①. Hold needle ② with the long groove facing toward you, and fully insert it into the hole in the needle bar. Tighten setscrew ①.


(Caution)

1. If the needle thread stitches are finished as (A) in the figure, install the needle orienting the groove on the needle slightly to the left.
2. If stitch skipping occurs during sewing, or the needle thread cannot be trimmed, install the needle orienting the groove on the needle slightly to the right.
3. When sewing heavy-weight materials with synthetic fiber thread, use a super needle for synthetic fiber.
4. Before attaching the needle, be sure to turn OFF the power to the machine.

3. Threading the machine head



4. Installing and removing the bobbin case




- 1) Open cylinder arm cap ①.
- 2) Raise and hold latch lever ③ of bobbin case ② to take it out. The bobbin in the bobbin case does not come off as long as the latch lever is raised and held.
- 3) To load the bobbin case into the shuttle, fit it onto the shuttle shaft, and snap in the latch lever of the bobbin case.

(Caution)

If bobbin case ② is not securely loaded in the shuttle, bobbin case ② may slip off during sewing. So be careful.

5. Threading the bobbin case




- 1) Hold bobbin ① in the hand so that it spins clockwise, and set it in bobbin case ②.
- 2) Pass the thread through slot ③ in the bobbin case. Pull the thread to pass it under the tension spring out to thread exit ④. At this time, make sure that the bobbin turns in the direction of the arrow when the thread is pulled.
- 3) Pass the thread through hole ⑤, and pull the thread out about 2.5 cm from the hole.

(Caution)

If the bobbin is installed in the bobbin case orienting the reverse direction, the bobbin thread tension may be affected by the idling spring resulting in an inconsistent tension. So be careful.

6. Winding the bobbin




- 1) Attach bobbin ① to bobbin winder spindle ②.
- 2) Thread the winder in the order as illustrated and wind the thread onto the bobbin four or five turns.
- 3) Push bobbin winder trip latch ③ in the direction of the arrow, and the winder starts to wind the bobbin.
- 4) To adjust the amount of thread wound round the bobbin, loosen nut ④ and screw in adjusting screw ⑤ to decrease the thread amount.

(Caution)

Be sure to use genuine JUKI bobbin cases and bobbins.

7. Thread tension




- 1) Adjusting the needle thread tension
Turn thread tension controller No.1 ① clockwise to decrease the length of the thread which will remain on the needle after thread trimming, or counterclockwise to increase it. Minimize the length of the thread which will remain on the needle as long as the thread does not slip off the needle. Turn thread tension controller No.2 ② clockwise to increase the bobbin thread tension, or counterclockwise to decrease it.
- 2) Adjusting the bobbin thread tension
Turn thread tension adjusting screw ③ clockwise to increase the bobbin thread tension, or counterclockwise to decrease it.

(Caution)

Be sure that thread take-up spring ⑤ is in contact with thread breakage detector ④ in the absence of the needle thread. Also, be sure that the thread breakage detector does not touch any adjacent metallic components other than the thread take-up spring.

8. Adjusting the thread take-up spring



The normal stroke of thread take-up spring ① is 12 to 15 mm, and the tension at the starting point is 15 to 30 g.

- 1) Adjusting the stroke
Loosen screw ②, and turn tension controller assembly ③ clockwise to increase the stroke or counterclockwise to decrease it.
- 2) Adjusting the tension
Insert the blade of a flat-bit screwdriver into the groove in the tension post ④, and turn it clockwise to increase the tension or counterclockwise to decrease it.


(Caution)

Decrease the tension of the thread take-up spring for a synthetic fiber thread (approximately 15 g).

9. Operation and switches of the AMS-220C

1) Operation switches arrangement


Switches are arranged in six different locations in consideration of frequency of operating each of them.



2) Basic operation

The basic operation of the AMS is to create a pattern and read out a pattern. These two kinds of operation allow the AMS to perform its minimum functions. (Explanation of the pattern creating procedure is omitted in this Instruction Manual since it is given in the Instruction Manual for the "main unit input function" and the Instruction Manual for the PGM Series.)

- Basic operation of the AMS (reading out a pattern)



3) Operation and functions of the sewing machine other than those of reading patterns

The AMS comes with automatically-performed functions including an error detecting function of reverse-rotation preventing function, etc. In the following cases, the machine should be operated (switches should be operated) in the way different from the above-stated procedure for reading out a pattern.

①	When sewing troubles including thread breakage occur during sewing (Emergency stop switch, Backward switch, etc.)
②	When higher efficiency, easier operation or further convenient operation is required for sewing (Needle threading switch, DIP switches for each additional function required, etc.)
③	When higher seam quality is required (Wiper switch, Speed adjusting variable resistor, DIP switches for each additional function required, etc.)
④	When performing inspection and maintenance of the sewing machine (Rotary DIP switch)
⑤	When preventing sewing machine troubles (Sewing machine ON/OFF switch, DIP switches of each additional function required, etc.)


The AMS has many functions which are separately named in accordance with the respective purposes. These functions are controlled by the same switches by changing the operating method of them. Now, let's explain these functions in the form of "function" and "operating method of the relevant switches". (See the explanation of the respective functions described on and beyond page 17 and the explanation of the DIP switches described on and beyond page 25.) Switches used to control any function which has no exclusive name are separately described in the form of "function" and "operating method (of the switch)".

4) Sewing mode/Setting mode and pattern reading


The AMS can be set to two different operation modes, one is the **Sewing mode** under which a pattern is actually sewn, a bobbin is wound, etc., the other is the **Setting mode** under which a pattern number, X/Y scale, etc. are specified to enable the machine to read out a pattern desired.

The **Sewing mode** and **Setting mode** can be changed over by operating the Set Ready switch on the operation panel (operation box). If a pattern number and X/Y scale are specified under the **Setting mode**, the machine will read out the pattern at the time of changing over the setting of the switch from the **Setting mode** to the **sewing state**, from the floppy disk loaded in the floppy disk drive.

- **Sewing mode** / **Setting mode**



* Immediately after turning ON the power switch, the machine is set to the **setting mode**, for the sake of ease of operation. This enables the operator to perform pattern changing with ease just after turning ON the power switch, if pattern to be used is frequently changed at the start of the working hours. Thanks to the "backup function", the machine stores the pattern used in memory even when the power to the machine is turned OFF. In the case where the same pattern is used for several days, the operator can set the machine to the **Sewing mode** without reading out the pattern from the floppy disk if pressing the **Set Ready** switch without changing the data specified for the pattern. (Refer to page 37 for the backup function.)



5) Relationship between the sewing mode/setting mode and the switches


Under the **Sewing mode**, the machine is actually operated. On the other hand, preparation for reading of a pattern is carried out under the **setting mode**. This means that the machine functions in the two different ways in accordance with the mode to which the machine is set. Consequently, switches of the machine are divided into the two groups, one is the group of the switches used under the **Sewing mode** and the other is the group of the switches used under the **Setting mode**.

Switches used under the Setting mode	Pattern No. switch/ X scale switch, etc.
Switches used under the Sewing mode	Forward switch/ Backward switch, etc. on the operation panel, Needle threading switch, etc. on the front face of the control box

Even if any of the switches used under the **Sewing mode** is used under the **Setting mode** by mistake, or any of those used under the **Setting mode** is used under the **Sewing mode** by mistake, no trouble may result since the switches are inoperative under the wrong mode.


(Cautions)

- The switches on the front face of the control box are **seesaw switches**. So, the following precautions should be taken when operating these switches.
 Operating the switches used under the **Setting mode** including scale setting switch for **INC/DEC of the stitch length & INC/DEC of the number of stitches** in the sewing mode by mistake will not adversely affect on the sewing as long as the machine operates under the **Sewing mode**.
 However, the operated switch will function when reading a pattern after changing over the mode of the machine from the **Sewing mode** to the **Setting mode**.




- Changeover of the DIP switches is ineffective while the power switch is turned ON regardless of the mode of the sewing machine, i.e., in the **Sewing mode** and in the **Setting mode**. Be sure to change the setting of the DIP switches with the **Power switch turned OFF**.
 (The setting of the DIP switches are read by the machine simultaneously with turning ON of the power switch.)

10. Control box and its function



① Max. speed limitation knob/Bobbin winder ON/OFF switch



• Max. speed limitation knob (used under the Sewing mode)

Normally, the sewing speed is automatically adjusted according to the stitch length. If a slower speed is required, however, turn the knob counterclockwise.

• Bobbin winder ON/OFF switch (used under the Sewing mode)

Pull the knob toward you (To turn ON the Bobbin winder switch) while the sewing machine is stopped, and the feeding frame will automatically come down. Then Turn ON the start switch, and the sewing machine will run at a constant speed winding the bobbin.


The machine can be stopped in the following three different methods.

- ① Press the knob back to its home position. (The Bobbin winder ON/OFF switch is turned OFF.)
 - ② Press the Start switch again.
 - ③ Turn ON the Emergency stop switch.
- If the machine is stopped by taking method ② or ③, it is necessary also to take method ① "press the knob back to its home position".

(Caution)

Before bobbin winding, make sure that there is nothing under the needle.

② Needle threading switch (used under the Sewing mode)




- Set the needle threading switch to the \swarrow side when the sewing machine is stopped, and the intermediate presser and feeding frame will automatically come down, upon which the needle will be threaded.

When the machine is doing the above job, the Start switch will not work even if it is turned ON.



- Move the Needle threading switch up and down when the Emergency stop switch is turned ON and sewing machine is stopped, and thread trimming will be done. The Return to Origin, Forward and Backward keys will now become effective.


- If the Needle threading switch is moved up and down when the needle is not in its upper resting position (error message 3), the sewing machine will automatically rotate and stop in the needle-up stop position. Make sure that there is nothing under the needle. (This function is effective as long as the READY indicator LED lights up.) (See "Needle-up stop function" on page 38.)

③ Scale setting switch (INC/DEC of the stitch length & INC/DEC of the number of stitches)







Set the scale setting switch to INC/DEC of the Stitch Length or INC/DEC of the Number of Stitches to enlarge/reduce a pattern.

When the switch is set to the  side, the stitch length can be increased/decreased, and when set to the  side, the number of stitches can be increased/decreased.




④ Sewing machine ON/OFF switch



When this switch is set to , the sewing machine performs its normal operation. When this switch is set to , only the feed mechanism will work. This switch is set to the  side to check the shape of pattern after reading the pattern, to check the feeding frame against the pattern desired, to check the size of the pattern after enlarging it and to perform other operations.

⑤ Floppy disk driver




Eject button

Floppy disk inserting slot


- 1) Loading the floppy disk
After turning the power switch ON, slowly insert the floppy disk, with its face A pointing away from you, until the eject pushbutton pops out.
- 2) Unloading the floppy disk
Before turning the power switch OFF, press the eject pushbutton and take out the floppy disk.
- 3) Write-protect hole
When the write-protect tab is moved to open the write-protect hole, no data is allowed to be written into the disk, move the write-protect tab until it is exposed.

(Caution)


Never turn the power switch ON or OFF with the floppy disk mounted.




4) Precautions in handling floppy disks




1. Do not place the floppy disk near an ashtray or food and drink.



2. Do not touch the exposed parts of the floppy disk.



3. Do not bring the floppy disk close to a magnetized material.



4. Do not place the floppy disk in a hot place (51°C or higher) or a place exposed to direct sunlight.


11. Operation box and its function

The sewing machine is operated under two different modes. The switches on the operation box are arranged in accordance with the operation mode of the sewing machine. The operation mode of the sewing machine is changed over between these two modes every time the Set Ready switch is pressed.

State	READY indicator lamp	Sewing machine	Switch on the operation box to be used
Sewing mode	Lights up	Operative (sewing, winding a bobbin)	Operation switches
Setting mode	Goes out	Inoperative	Setting switches (Note 1)

(Note 1)



















Among the setting switches, only the 4, 6, 8 and 2 switches can be used as jog switches under the Sewing mode.



1) Function of the setting switches and operating method

..... Used only when the machine is set to the Setting mode (the READY indicator lamp goes out).

Name of switch	Function	Operating method
Pattern No.	<ul style="list-style-type: none"> Used to change the number representing pattern number indicated on the display. Changes pattern No. at the time of reading out the indicated pattern using the Pattern No. switch and 0 (Cancel), 1 through 9 (numeric switches). (A number of three figures) A number of three figures is used as the pattern number to read out the pattern from the floppy disk. 	<p>To make the display indicate 1 2 3, follow the procedure below.</p> <p>Press the Pattern No. switch.</p> <p>↓</p> <p>Continuously press the 1, 2, and 3 switches.</p> <p>(Caution)</p> <p>Be sure to input a pattern number of three figures.</p> <p>Example Pattern No. 1 → 001 Pattern No. 10 → 010 Pattern No. 100 → 100</p>

Name of switch	Function	Operating method
<div style="border: 1px solid black; padding: 2px; width: fit-content; margin-bottom: 5px;">X Scale (review)</div> <div style="border: 1px solid black; padding: 2px; width: fit-content;">Y Scale (end)</div>	<ul style="list-style-type: none"> Used to change the X scale or Y scale on the displays. Respective numbers of three figures on the displays are changed by operating the  or the . Respective numbers of three figures are used as X scale and Y scale when reading out a pattern from the floppy disk. <p>(Caution) The range of number of three figures that can be specified is 001 (%) to 400 (%) while the size of pattern stored in the floppy disk is taken as 100 (%).</p>	<p>To make the X scale display indicated , follow the procedure below.</p> <p>Press the  switch.</p> <p style="text-align: center;">↓</p> <p>Continuously press the ,  and  switches.</p> <p>* Similarly, the Y scale can be changed by pressing the  switch first and then the number switches.</p>
<div style="border: 1px solid black; padding: 2px; width: fit-content;">Counter (set)</div>	<ul style="list-style-type: none"> Used to change the number shown on the counter display. The number of three figures on the display is changed by using the  switch and the number switches. This number is necessary when designating the "bobbin thread counting function" using the relevant DIP switch. Refer to description on the "SW6-3" and "SW6-2" given on page 30 for the details of the "bobbin thread counting function". This number is not related to the function of reading out a pattern from the floppy disk. <p>(Caution) The range of number of three figures that can be specified is 001 to 999.</p>	<p>To make the counter display indicate , follow the procedure below.</p> <p>Press the  switch.</p> <p style="text-align: center;">↓</p> <p>Continuously press the ,  and  switches.</p>
<p>(Number switches)</p> <div style="display: flex; flex-wrap: wrap; gap: 5px;"> <div style="border: 1px solid black; padding: 2px; width: 20px; height: 20px; text-align: center;">7</div> <div style="border: 1px solid black; padding: 2px; width: 20px; height: 20px; text-align: center;">8 ▲</div> <div style="border: 1px solid black; padding: 2px; width: 20px; height: 20px; text-align: center;">9</div> <div style="border: 1px solid black; padding: 2px; width: 20px; height: 20px; text-align: center;">4 ◀</div> <div style="border: 1px solid black; padding: 2px; width: 20px; height: 20px; text-align: center;">5 (Enter)</div> <div style="border: 1px solid black; padding: 2px; width: 20px; height: 20px; text-align: center;">6 ▶</div> <div style="border: 1px solid black; padding: 2px; width: 20px; height: 20px; text-align: center;">1</div> <div style="border: 1px solid black; padding: 2px; width: 20px; height: 20px; text-align: center;">2 ▼</div> <div style="border: 1px solid black; padding: 2px; width: 20px; height: 20px; text-align: center;">3</div> <div style="border: 1px solid black; padding: 2px; width: 20px; height: 20px; text-align: center;">0 (Cancel)</div> </div>	<ul style="list-style-type: none"> Used as number switches to change (specify) the numbers given on the pattern No., X/Y Scale and Counter. <p>(Caution) The , ,  and  switches can also be used as jog switches. The function and operation method of the jog switches are to be described in "3) Operation switches".</p>	

2) Function and operating method of the Set ready switch









..... This switch is used both under the **Setting mode** and **Sewing mode**.

Name of switch	Function	Operating method
<div style="border: 1px solid black; padding: 2px; width: fit-content;">Set Ready (Test)</div>	<ul style="list-style-type: none"> Used to change over the mode of the machine between the Sewing mode (the READY indicator lamp lights up) and the Setting mode (the READY indicator lamp goes out). If any of the numbers shown on the displays (excluding the Counter display) is changed under the Setting mode, the machine will read out a pattern from the floppy disk when changing over the mode of the machine from the setting mode to the Sewing mode. <p>(Caution) Whenever changing over the mode of the machine from the setting mode to the sewing mode, the feeding frame will perform below mentioned operation regardless of reading of a pattern from the floppy disk. So be sure to keep your hands away from the feeding frame.</p> <p>Operations to allow the machine to be set ready for sewing</p> <ol style="list-style-type: none"> ① The feeding frame comes down. ② The origin is retrieved. (The feeding frame moves to the origin.) ③ The feeding frame moves to the sewing start position or to the second origin. ④ The feeding frame goes up. 	<div style="border: 1px solid black; padding: 2px; width: fit-content; margin-bottom: 5px;">Sewing mode</div> <p style="text-align: center;">↓</p> <p style="text-align: center;">Press the <div style="border: 1px solid black; padding: 2px; width: fit-content; display: inline-block;">Set Ready (Test)</div> switch.</p> <p style="text-align: center;">↓</p> <div style="border: 1px solid black; padding: 2px; width: fit-content; margin-bottom: 5px;">Setting mode</div> <p style="text-align: center;">↓</p> <p style="text-align: center;">(Change the numbers shown on the displays.)</p> <p style="text-align: center;">Press the <div style="border: 1px solid black; padding: 2px; width: fit-content; display: inline-block;">Set Ready (Test)</div> switch.</p> <p style="text-align: center;">↓</p> <p style="text-align: center;">Pattern is read from the floppy disk.</p> <p style="text-align: center;">↓</p> <p style="text-align: center;">Operations to allow the machine to be set ready for sewing are performed.</p> <p style="text-align: center;">↓</p> <div style="border: 1px solid black; padding: 2px; width: fit-content; margin-bottom: 5px;">Sewing mode</div>

3) Function of the operation switches and operating method

..... Only used under the **Sewing mode** (the READY indicator lamp lights up).

Name of switch	Function	Operating method
<div style="border: 1px solid black; padding: 2px; width: fit-content; margin-bottom: 10px;">Forward</div> <div style="border: 1px solid black; padding: 2px; width: fit-content;">Backward</div>	<ul style="list-style-type: none"> When the Forward/Backward switch is pressed with the feeding frame down, the material is fed forward/backward by one stitch. When the Forward/Backward switch is kept pressed, the material is fed forward/backward at slow speed for the first one stitch, after which it is automatically fed forward/backward continuously at high speed. The state under which the feeding frame is lowered represents any of the following states, etc. <ol style="list-style-type: none"> ① When the feeding frame is lowered by operating the feeding frame switch. ② After the emergency stop switch is used to stop the sewing machine while the machine is in operation or after thread trimming (when the needle threading switch is moved up and down). ③ After the machine has automatically stopped in an error (error message [9]) during sewing due to needle thread breakage. Example of operations <ol style="list-style-type: none"> ① When checking the shape of pattern newly read out from the floppy disk. ② When you wish to sew the material again from the position where the sewing is automatically interrupted by needle thread breakage. 	<p>To continue sewing after thread breakage, follow the procedure below.</p> <p>The machine automatically stops due to thread breakage.</p> <p style="text-align: center;">↓</p> <p style="text-align: center;">Return the feed mechanism to the stitch where the sewing has been interrupted using the <div style="border: 1px solid black; padding: 2px; width: fit-content; display: inline-block;">Backward</div>.</p> <p style="text-align: center;">↓</p> <p style="text-align: center;">Depress the start switch. (The sewing is re-started.)</p> <p style="text-align: center;">The material is fed forward. →</p> <p style="text-align: center;">Sewing start </p> <p style="text-align: center;">← The material is fed backward.</p> <p style="text-align: center;">Sewing end </p>

<p>Return to Origin</p>	<ul style="list-style-type: none"> When this switch is pressed with the feed frame lowered, the feed mechanism will automatically move straight to the sewing start point or the 2nd origin regardless of the pattern shape. <p>This switch is operative after operating the  or  switch.</p> <p>(Caution) If any special type of feeding frame such as the inverting feeding frame is used and an obstruction exists on the way to the sewing start point or the 2nd origin, the feeding frame may come in contact with the needle, etc. while it returns to the origin. In this case, return the feeding frame to the sewing start point or the 2nd origin by operating the Backward switch.</p>	
<p>Reset (select)</p>	<ul style="list-style-type: none"> Used to reset the number shown on the Counter display when the machine is stopped. This is the switch to re-start the sewing machine after the machine is stopped by the "bobbin thread counting function". Refer to description on the "SW6-3" and "SW6-2" given on page 30 for the details of the "bobbin thread counting function". 	<p>The number of pieces of material specified to be sewn is finished.</p> <p>↓</p> <p>The sewing machine is stopped by the "bobbin thread counting function". (Indicator lamp flashes on and off)</p> <p>↓</p> <p>Press the  switch.</p> <p>↓</p> <p>The number shown on the Counter display is reset. (The machine is set to the state under which it is allowed to re-start sewing.)</p>
<p>Jog switches</p> 	<ul style="list-style-type: none"> They are used to move the sewing position or to specify the 2nd origin. (This function is selected using the relevant DIP switch. See the description on "SW5-3" on page 27.) If any of the switches , ,  and  is pressed immediately after lowering the feeding frame, the feed mechanism will move in the direction shown by the arrow on the pressed switch. The destination is used as the position to start sewing (sewing start point) or the 2nd origin. The movement of the feed mechanism is kept stored in memory unless another movement is specified or the operation mode of the machine is once changed over to the Setting mode . Thanks to the "backup function" (Refer to page 37) the movement of the feed mechanism is automatically stored in memory together with the data on the pattern used even if turning OFF the power to the sewing machine. 	


4) Error indications

Error No.	Indicator lamp	Error description	Action to be taken
1	ON	Comes on if a malfunction has resulted in a data read-out error.	Press the Set Ready Key to read out the data again.
	ON The pattern No. indicator lamp flashes on and off	Starts when there is no data for the relevant number.	Set the correct Pattern No.
	Flash	A floppy disk is no inserted.	Insert a floppy disk.
2	ON	Comes on if the stitch length exceeds 10 mm over the computable range in an attempt to enlarge a pattern based on the number of stitches.	Correctly reset the X-and/on Y-scale.
3	ON	Comes on if the needle is not in its highest position.	Turn the handwheel until error No. "3" disappears. Or turn ON/OFF the Needle Threading switch to raise the needle to its highest position.
4	ON	Comes on if the maximum sewing area (200 mm x 145 mm) is exceeded.	During a sewing cycle: Press the Return to Origin key. While setting the 2nd origin: Press the Jog key.
5	Flash	Starts when the emergency switch is turned ON.	Press the start switch to actuate the sewing machine again. Turn ON/OFF the Needle Threading switch, and the thread will be trimmed. (The lamp display changes from "Flash" to "ON".)
	ON	Comes on when only the feeding frame is moving. Comes on when the emergency switch is turned ON.	Turn ON the start switch after pressing the Return to Origin and the FORWARD or BACKWARD keys.
6	Flash (slowly)	Starts when approximately 1,000 stitches remain for the pattern to be made.	When using the PGM-1 together with the machine.
	Flash (fast)	Starts when approximately 500 stitches remain for the pattern to be made.	When using the PGM-1 together with the machine.
7	ON	Comes on if a malfunction has caused the machine to lock, or if there has been a failure in the needle position detector.	Turn OFF the power switch. Replace the defective parts or eliminate the cause of the machine locking. Then turn ON the power switch.
8	ON	Comes on if a poor connection of a solenoid connector is detected.	Turn OFF the power switch, and check for the loose solenoid connection.
9	ON	Comes on if the needle thread is broken.	Re-thread the machine head, press the Return to Origin key and the FORWARD or BACKWARD keys to move the feeding frame backward. Then press the start switch.

Error No.	Indicator lamp	Error description	Action to be taken
0	Flash	Starts when trying to format a floppy disk with the write-protect tab in the open position (the disk cannot be formatted).	Move the write-protect tab so that it is in its closed position. When using the PGM-1 together with the machine.
	ON	Comes on when trying to format a defective floppy disk.	Replace the floppy disk. When using the PGM-1 together with the machine.
※ A	ON	Comes on when the air pressure is less than 4 kg/cm ² .	Turn OFF the power switch. Set the air pressure to 5 ~ 5.5kg/cm ² .
E	ON	Comes on when the sewing machine rotates in the reverse direction.	Turn OFF the power switch. Change the rotation direction of the motor.


* For a sewing machine using compressed air.

12. Foot switch




- 1) When feeding frame switch ① is depressed, the feeding frame will come down. Another depress on the switch makes the feeding frame go up.
- 2) When start switch ② is depressed with the feeding frame down, the machine will start sewing.

13. Switches on the machine head



- ① Wiper switch (used under the **sewing mode**)



ON	The wiper actuates after thread trimming to sweep the thread.
OFF	The wiper is inoperative.


(Caution)

1. In addition to the wiper switch, the machine comes with the wiper selector switch (DIP switch) to control the "wiper prohibition function". (See the description on the SW6-7 on page 31.)
2. The wiper switch has been designed to operate under the **sewing mode**, however, the switch itself can be operated under the **setting mode** since it is mechanically a seesaw switch.

- ② Emergency stop switch (used under the **sewing mode**)

If this push-button switch is pressed while the machine is running under the **sewing mode**, the machine will stop giving an error message on the display.

(Error message)



(See also the description on the SW7-3 on page 33.)



(Operation after an emergency stop)


1. To re-start the sewing machine without operating any other switch
→ The start switch is operative in the both cases where Error 5 **flashes on and off** and Error 5 **lights up**.
So turn ON the **start switch**.
2. To re-start the sewing machine after changing the sewing start point (stitch) using the **Forward/Backward switch**
→ Move up/down the **Needle threading switch** (to make the thread trimmer actuate). Then the Error 5 will **light up** instead of flashing on and off. Then move the needle the position from which you wish to re-start sewing using the **Forward/Backward switch**, and turn ON the **start switch**.

(Caution) Moving the **Needle threading switch** up and down will make the sewing machine turn by one revolution, during which the needle will go up and come down. Never place your hands, etc. under the needle when operating the **Needle threading switch**.


3. To return the needle to the sewing start point (or the 2nd origin)
→ Move up/down the **Needle threading switch** to make the error 5 **light up** instead of flashing on and off. Then turn ON the **Return to Origin switch**. (The needle returns to the sewing start point (or the 2nd origin) and the feeding frame goes up.)

(Caution)

If your machine is equipped with an inverting clamp or if you use a special type of feeding frame, the inverting clamp or feeding frame may partly protrude from the needle. In this case, if turning ON the **Return to Origin switch** to make the needle return to the sewing start point, the **needle may hit against the protruded section of the inverting clamp or feeding frame on the way to the sewing start point. This is very dangerous since needle breakage, etc. may result.** Consequently, in the aforementioned case, return the needle to the sewing start point (or the 2nd origin) by keeping pressing the **Backward switch**, and raise the feeding frame using the **Return to Origin switch**.



14. DIP switches on the printed circuit board




Remove five setscrew ⑨ from control box cover ⑧, loosen three screws ⑩, and remove control box cover ⑧, You will then see DIP switches ②, ④, ⑤, ⑥ and ⑦ mounted on the I/F printed circuit board located on the right as you face it.





The functions of the DIP switches are as follows:


(Caution)




Be sure to set the DIP switches while the power switch is turned OFF.


(Setting the DIP switches while the power switch is turned ON will not be effective.)


Name of switch	Function															
<p>④ DIP switch 4 (SW4)</p>  <p>(at the time of delivery)</p>	<p>• SW4-3, -4 The feed timing can be changed in accordance with the material thickness.</p> <table border="1"> <thead> <tr> <th>SW 4 - 3</th> <th>SW 4 - 4</th> <th>Material thickness for reference</th> </tr> </thead> <tbody> <tr> <td>ON</td> <td>ON</td> <td>Less than 2 mm (at the time of delivery)</td> </tr> <tr> <td>OFF</td> <td>ON</td> <td>2 mm or more - less than 3 mm</td> </tr> <tr> <td>ON</td> <td>OFF</td> <td>3 mm or more - less than 4 mm</td> </tr> <tr> <td>OFF</td> <td>OFF</td> <td>4 mm or more</td> </tr> </tbody> </table> <p>(Caution) The feed timing may change depending on the type of material to be sewn, stitching method, etc. Select a suitable feed timing in accordance with the sewing product.</p> <p>• SW4-1 and -2 are used for maintenance. They do not need to be operated. Set these switches to the OFF positions.</p>	SW 4 - 3	SW 4 - 4	Material thickness for reference	ON	ON	Less than 2 mm (at the time of delivery)	OFF	ON	2 mm or more - less than 3 mm	ON	OFF	3 mm or more - less than 4 mm	OFF	OFF	4 mm or more
SW 4 - 3	SW 4 - 4	Material thickness for reference														
ON	ON	Less than 2 mm (at the time of delivery)														
OFF	ON	2 mm or more - less than 3 mm														
ON	OFF	3 mm or more - less than 4 mm														
OFF	OFF	4 mm or more														


Name of switch	Function														
<p>⑤ DIP switch 5 (SW5)</p>  <p>(at the time of delivery)</p>	<p>• SW5-2 "Cycle stitching facility A" (Feeding frame position selection A) It is used to select the position of the feeding frame (up or down) when the "temporary stop" command (pause) position in a pattern is reached.</p> <table border="1" data-bbox="518 324 1364 705"> <tr> <td data-bbox="518 324 758 515"> <p>ON (This switch has been set to the ON position at the time of delivery.)</p> </td> <td data-bbox="758 324 1364 515"> <p>The machine pauses at the position where the "temporary stop" command has been entered in a pattern with the feeding frame <u>raised</u>. (Cycle stitching function) <u>Turn ON the feeding frame switch</u>. → <u>Turn ON the start switch</u>. Then the machine starts sewing the next cycle.</p> </td> </tr> <tr> <td data-bbox="518 515 758 705"> <p>OFF</p> </td> <td data-bbox="758 515 1364 705"> <p>The machine pauses at the position where the "temporary stop" command has been entered in a pattern with the feeding frame <u>lowered</u>. <u>Turn ON the start switch</u>. Then the machine starts sewing the next cycle.</p> </td> </tr> </table> <p>* Temporary stop command This command is used to temporarily stop the machine in a pattern. This command can be entered at a desired position (two or more positions) in a pattern to allow you to create (modify) it with ease when using the main unit input function/PGM-1, etc.</p> <p>* Cycle sewing Several sewing processes (cycles) are continuously sewn. A pattern can be divided by the temporary stop command so that the material may be turned or changed while the feeding frame is raised.</p> <p>(Caution) When the machine is in the cycle sewing mode (ON), be sure to take note of the following:</p> <table border="1" data-bbox="526 1164 1380 1892"> <tr> <td data-bbox="526 1164 662 1243">Forward</td> <td data-bbox="710 1164 1380 1254">When the Forward or Backward key is pressed, the machine halts at the preset temporary stop point where the feeding frame can be raised or lowered using the feeding frame switch.</td> </tr> <tr> <td data-bbox="526 1265 662 1344">Backward</td> <td data-bbox="710 1265 1380 1411">When the pedal change-over function A (SW5-7) is set to its <u>OFF</u> position (the feeding frame descends as long as the pedal is depressed), the feeding frame automatically goes up. When the switch is set to its <u>ON</u> position, turn <u>ON</u> the feeding frame switch, then turn <u>OFF</u> it.</td> </tr> <tr> <td data-bbox="526 1478 662 1556">Return to Origin</td> <td data-bbox="710 1478 1380 1601">When the Return to Origin switch is pressed, the machine goes back to the beginning of the first cycle of the pattern. If you want to go back to the beginning of the cycle being sewn, use the Backward key.</td> </tr> <tr> <td data-bbox="526 1601 662 1736"> Bobbin thread counter  </td> <td data-bbox="710 1624 1380 1724">The counter counts up upon the completion of one pattern. If a pattern includes 3 cycles, the counter is incremented when the 3 cycles have been sewn.</td> </tr> <tr> <td data-bbox="526 1780 662 1870">Set Ready (Test)</td> <td data-bbox="710 1780 1380 1904">The Set Ready switch is rendered ineffective while sewing a pattern (between cycles) even if the feeding frame goes up. Press the Set Ready switch after pressing the Return to Origin switch or after completion of the pattern.</td> </tr> </table>	<p>ON (This switch has been set to the ON position at the time of delivery.)</p>	<p>The machine pauses at the position where the "temporary stop" command has been entered in a pattern with the feeding frame <u>raised</u>. (Cycle stitching function) <u>Turn ON the feeding frame switch</u>. → <u>Turn ON the start switch</u>. Then the machine starts sewing the next cycle.</p>	<p>OFF</p>	<p>The machine pauses at the position where the "temporary stop" command has been entered in a pattern with the feeding frame <u>lowered</u>. <u>Turn ON the start switch</u>. Then the machine starts sewing the next cycle.</p>	Forward	When the Forward or Backward key is pressed, the machine halts at the preset temporary stop point where the feeding frame can be raised or lowered using the feeding frame switch.	Backward	When the pedal change-over function A (SW5-7) is set to its <u>OFF</u> position (the feeding frame descends as long as the pedal is depressed), the feeding frame automatically goes up. When the switch is set to its <u>ON</u> position, turn <u>ON</u> the feeding frame switch, then turn <u>OFF</u> it.	Return to Origin	When the Return to Origin switch is pressed, the machine goes back to the beginning of the first cycle of the pattern. If you want to go back to the beginning of the cycle being sewn, use the Backward key.	Bobbin thread counter 	The counter counts up upon the completion of one pattern. If a pattern includes 3 cycles, the counter is incremented when the 3 cycles have been sewn.	Set Ready (Test)	The Set Ready switch is rendered ineffective while sewing a pattern (between cycles) even if the feeding frame goes up. Press the Set Ready switch after pressing the Return to Origin switch or after completion of the pattern.
<p>ON (This switch has been set to the ON position at the time of delivery.)</p>	<p>The machine pauses at the position where the "temporary stop" command has been entered in a pattern with the feeding frame <u>raised</u>. (Cycle stitching function) <u>Turn ON the feeding frame switch</u>. → <u>Turn ON the start switch</u>. Then the machine starts sewing the next cycle.</p>														
<p>OFF</p>	<p>The machine pauses at the position where the "temporary stop" command has been entered in a pattern with the feeding frame <u>lowered</u>. <u>Turn ON the start switch</u>. Then the machine starts sewing the next cycle.</p>														
Forward	When the Forward or Backward key is pressed, the machine halts at the preset temporary stop point where the feeding frame can be raised or lowered using the feeding frame switch.														
Backward	When the pedal change-over function A (SW5-7) is set to its <u>OFF</u> position (the feeding frame descends as long as the pedal is depressed), the feeding frame automatically goes up. When the switch is set to its <u>ON</u> position, turn <u>ON</u> the feeding frame switch, then turn <u>OFF</u> it.														
Return to Origin	When the Return to Origin switch is pressed, the machine goes back to the beginning of the first cycle of the pattern. If you want to go back to the beginning of the cycle being sewn, use the Backward key.														
Bobbin thread counter 	The counter counts up upon the completion of one pattern. If a pattern includes 3 cycles, the counter is incremented when the 3 cycles have been sewn.														
Set Ready (Test)	The Set Ready switch is rendered ineffective while sewing a pattern (between cycles) even if the feeding frame goes up. Press the Set Ready switch after pressing the Return to Origin switch or after completion of the pattern.														


Name of switch	Function				
<p>⑤ DIP switch 5 (SW5)</p>  <p>(at the time of delivery)</p>	<p>• SW5-3 Used to select either the "2nd origin setting function" or the "sewing start point moving function"</p> <table border="1" data-bbox="496 360 1364 913"> <tr> <td data-bbox="496 360 746 723"> <p>OFF (This switch has been set to the OFF position at the time of delivery.)</p> </td> <td data-bbox="746 360 1364 723"> <p>A 2nd origin can be newly set using the jog switches. (The location of the pattern is not changed.) (Caution) If the 2nd origin is specified within the pattern, note the followings. ① If a 2nd origin is newly specified using the jog switches, the conventional 2nd origin located in the pattern is ignored and the newly specified 2nd origin becomes effective. ② If the jog switches are not operated, the 2nd origin located in the pattern remains effective.</p> </td> </tr> <tr> <td data-bbox="496 723 746 913"> <p>ON</p> </td> <td data-bbox="746 723 1364 913"> <p>The location of the pattern can be changed by operating the jog switches. (The "sewing start point moving function") (The 2nd origin located within the pattern is ignored, and the machine does not stop at the 2nd origin.)</p> </td> </tr> </table> <p>* 2nd origin It is also called "turnout point". It means a point where the tip of needle rests when setting the workpiece to be sewn on the machine. Normally, the tip of needle of an AMS sewing machine rests at the sewing start point (the first stitch of a pattern) before starting sewing. However, a 2nd origin is used whenever the needle resting at the sewing start point becomes an obstruction to the setting of a workpiece on the machine. In this case, the location of the pattern does not change. (Note that only one 2nd origin can be specified in the single pattern.)</p> <p>* How to reset/change the specified point (the 2nd origin or the sewing start point) and how to store it in memory Reset To reset (cancel) the point specified using the jog switches, (Cancel) press the Set Ready switch twice. The specified point is also canceled when reading out another pattern from the floppy disk. At this time, the feeding frame comes down and the origin is retrieved. So be careful not to allow your hands to be caught under the feeding frame. (If you wish to reset (ignore) the 2nd origin located within a pattern, set the SW5-3 to the ON position.) Change A point specified using the jog switches is automatically replaced by a newly specified point. So specify a new point at any desired position without canceling the conventional point. Store in memory When turning OFF the power to the machine under the sewing mode, the "backup function" works to store the specified point as well as the pattern in memory.</p>	<p>OFF (This switch has been set to the OFF position at the time of delivery.)</p>	<p>A 2nd origin can be newly set using the jog switches. (The location of the pattern is not changed.) (Caution) If the 2nd origin is specified within the pattern, note the followings. ① If a 2nd origin is newly specified using the jog switches, the conventional 2nd origin located in the pattern is ignored and the newly specified 2nd origin becomes effective. ② If the jog switches are not operated, the 2nd origin located in the pattern remains effective.</p>	<p>ON</p>	<p>The location of the pattern can be changed by operating the jog switches. (The "sewing start point moving function") (The 2nd origin located within the pattern is ignored, and the machine does not stop at the 2nd origin.)</p>
<p>OFF (This switch has been set to the OFF position at the time of delivery.)</p>	<p>A 2nd origin can be newly set using the jog switches. (The location of the pattern is not changed.) (Caution) If the 2nd origin is specified within the pattern, note the followings. ① If a 2nd origin is newly specified using the jog switches, the conventional 2nd origin located in the pattern is ignored and the newly specified 2nd origin becomes effective. ② If the jog switches are not operated, the 2nd origin located in the pattern remains effective.</p>				
<p>ON</p>	<p>The location of the pattern can be changed by operating the jog switches. (The "sewing start point moving function") (The 2nd origin located within the pattern is ignored, and the machine does not stop at the 2nd origin.)</p>				


Name of switch	Function				
<p>⑤ DIP switch 5 (SW5)</p>  <p>(at the time of delivery)</p>	<p>• SW5-4 Wiper actuating point selecting function</p> <p>Normally, the wiper sweeps across the clearance between the intermediate presser and the needle. When sewing heavy-weight material, the clearance may be too small for the wiper to work. In this case, the wiper will be able to sweep across the clearance between the intermediate presser and the work-piece after the intermediate presser has reached the highest position in its stroke.</p> <table border="1" data-bbox="517 452 1374 721"> <tr> <td data-bbox="517 452 762 555">ON</td> <td data-bbox="762 452 1374 555">The wiper sweeps between the intermediate presser and the workpiece after the intermediate presser has reached the highest position in its stroke.</td> </tr> <tr> <td data-bbox="517 555 762 721">OFF (This switch has been set to the OFF position at the time of delivery.)</td> <td data-bbox="762 555 1374 721">The intermediate presser goes up after the wiper has swept across the clearance between the needle and the intermediate presser.</td> </tr> </table> <div style="display: flex; justify-content: space-around; align-items: flex-end;"> <div data-bbox="715 734 890 1010" style="text-align: center;">  <p>(OFF) Material thickness: up to 3 mm</p> </div> <div data-bbox="1018 743 1385 1010" style="text-align: center;">  <p>Wiper Intermediate presser</p> <p>(ON) Material thickness: 3 to 5 mm</p> </div> </div>	ON	The wiper sweeps between the intermediate presser and the workpiece after the intermediate presser has reached the highest position in its stroke.	OFF (This switch has been set to the OFF position at the time of delivery.)	The intermediate presser goes up after the wiper has swept across the clearance between the needle and the intermediate presser.
ON	The wiper sweeps between the intermediate presser and the workpiece after the intermediate presser has reached the highest position in its stroke.				
OFF (This switch has been set to the OFF position at the time of delivery.)	The intermediate presser goes up after the wiper has swept across the clearance between the needle and the intermediate presser.				
	<p>• SW5-5 Origin detection selector switch</p> <p>If the workpiece is not caught in the way during feeding or an excessive load is applied to the workpiece, a feeding failure (step-out) may result. In this case, the needle may come in contact with the feeding frame or the finished pattern may be dislocated in the next sewing.</p> <table border="1" data-bbox="504 1205 1362 1473"> <tr> <td data-bbox="504 1205 750 1308">ON</td> <td data-bbox="750 1205 1362 1308">After the completion of sewing, the machine returns to the sewing start point or the 2nd origin after detecting the origin.</td> </tr> <tr> <td data-bbox="504 1308 750 1473">OFF (This switch has been set to the OFF position at the time of delivery.)</td> <td data-bbox="750 1308 1362 1473">After the completion of sewing, the machine returns to the sewing start point or the 2nd origin.</td> </tr> </table>	ON	After the completion of sewing, the machine returns to the sewing start point or the 2nd origin after detecting the origin.	OFF (This switch has been set to the OFF position at the time of delivery.)	After the completion of sewing, the machine returns to the sewing start point or the 2nd origin.
ON	After the completion of sewing, the machine returns to the sewing start point or the 2nd origin after detecting the origin.				
OFF (This switch has been set to the OFF position at the time of delivery.)	After the completion of sewing, the machine returns to the sewing start point or the 2nd origin.				
	<p>• SW5-7 "Pedal change-over function A"</p> <table border="1" data-bbox="504 1536 1362 1794"> <tr> <td data-bbox="504 1536 750 1697">ON (This switch has been set to the ON position at the time of delivery.)</td> <td data-bbox="750 1536 1362 1697">Depress the feeding frame switch, and the feeding frame will come down. Depress the switch again, and the feeding frame will go up.</td> </tr> <tr> <td data-bbox="504 1697 750 1794">OFF</td> <td data-bbox="750 1697 1362 1794">The feeding frame keep lowering as long as the feeding frame switch is depressed.</td> </tr> </table>	ON (This switch has been set to the ON position at the time of delivery.)	Depress the feeding frame switch , and the feeding frame will come down. Depress the switch again, and the feeding frame will go up.	OFF	The feeding frame keep lowering as long as the feeding frame switch is depressed.
ON (This switch has been set to the ON position at the time of delivery.)	Depress the feeding frame switch , and the feeding frame will come down. Depress the switch again, and the feeding frame will go up.				
OFF	The feeding frame keep lowering as long as the feeding frame switch is depressed.				
	<p>• SW5-1, -6 and -8 are used for maintenance. They do not need to be operated. Leave these switches as they have factory-set at the time of delivery.</p>				


Name of switch	Function				
<p>⑥ DIP switch 6 (SW6)</p>  <p>(at the time of delivery)</p>	<p>• SW6-2 The setting of the Bobbin thread counter</p> <p>When the bobbin thread counting function is specified by setting the SW6-3 to the OFF position, the Counter counts the number of finished pieces until the set value is reached. This switch is used to select the counting method to be employed between subtraction and addition.</p> <table border="1" data-bbox="507 526 1359 1451"> <tr> <td data-bbox="507 526 778 891">ON</td> <td data-bbox="778 526 1359 891"> <p>Subtraction counter</p> <p>Set the number of workpieces to be sewn beforehand, which is shown on the Counter first. After one piece of workpiece has been finished, "1" will be subtracted from the value set on the Counter display. When the value indicated on the Counter display is "000", it will flash on and off, and sewing will no longer possible.</p> <p>Turning ON the Reset switch will reset the Counter, and the predetermined number of workpieces to be sewn will appear again on the Counter. At this time, the machine can start sewing.</p> </td> </tr> <tr> <td data-bbox="507 891 778 1451">OFF (This switch has been set to the OFF position at the time of delivery.)</td> <td data-bbox="778 891 1359 1451"> <p>Addition counter</p> <p>The Counter starts counting up the number of workpieces finished from "000". After one piece of workpiece has been finished, "1" will be added to the value shown on the Counter display. When the value indicated on the Counter display is the predetermined number of workpieces to be sewn, it will flash on and off, and sewing will no longer possible.</p> <p>Turning ON the Reset switch will reset the Counter, and "000" will appear again on the Counter. At this time, the machine can start sewing.</p> <p>(Caution)</p> <p>After inputting a set value of the Counter under the setting mode, the Counter display flashes on and off immediately after pressing the Set Ready switch though the machine has not yet sewn any workpiece. In this case, press the Reset switch once to reset the value indicated on the Counter, then start sewing.</p> </td> </tr> </table> <p>Refer to the explanation of the "SW6-3" on page 30 for the detailed description of the "bobbin thread counting function".</p>	ON	<p>Subtraction counter</p> <p>Set the number of workpieces to be sewn beforehand, which is shown on the Counter first. After one piece of workpiece has been finished, "1" will be subtracted from the value set on the Counter display. When the value indicated on the Counter display is "000", it will flash on and off, and sewing will no longer possible.</p> <p>Turning ON the Reset switch will reset the Counter, and the predetermined number of workpieces to be sewn will appear again on the Counter. At this time, the machine can start sewing.</p>	OFF (This switch has been set to the OFF position at the time of delivery.)	<p>Addition counter</p> <p>The Counter starts counting up the number of workpieces finished from "000". After one piece of workpiece has been finished, "1" will be added to the value shown on the Counter display. When the value indicated on the Counter display is the predetermined number of workpieces to be sewn, it will flash on and off, and sewing will no longer possible.</p> <p>Turning ON the Reset switch will reset the Counter, and "000" will appear again on the Counter. At this time, the machine can start sewing.</p> <p>(Caution)</p> <p>After inputting a set value of the Counter under the setting mode, the Counter display flashes on and off immediately after pressing the Set Ready switch though the machine has not yet sewn any workpiece. In this case, press the Reset switch once to reset the value indicated on the Counter, then start sewing.</p>
ON	<p>Subtraction counter</p> <p>Set the number of workpieces to be sewn beforehand, which is shown on the Counter first. After one piece of workpiece has been finished, "1" will be subtracted from the value set on the Counter display. When the value indicated on the Counter display is "000", it will flash on and off, and sewing will no longer possible.</p> <p>Turning ON the Reset switch will reset the Counter, and the predetermined number of workpieces to be sewn will appear again on the Counter. At this time, the machine can start sewing.</p>				
OFF (This switch has been set to the OFF position at the time of delivery.)	<p>Addition counter</p> <p>The Counter starts counting up the number of workpieces finished from "000". After one piece of workpiece has been finished, "1" will be added to the value shown on the Counter display. When the value indicated on the Counter display is the predetermined number of workpieces to be sewn, it will flash on and off, and sewing will no longer possible.</p> <p>Turning ON the Reset switch will reset the Counter, and "000" will appear again on the Counter. At this time, the machine can start sewing.</p> <p>(Caution)</p> <p>After inputting a set value of the Counter under the setting mode, the Counter display flashes on and off immediately after pressing the Set Ready switch though the machine has not yet sewn any workpiece. In this case, press the Reset switch once to reset the value indicated on the Counter, then start sewing.</p>				


Name of switch	Function				
<p>⑥ DIP switch 6 (SW6)</p>  <p style="text-align: center;">SW6</p> <p>(at the time of delivery)</p>	<p>• SW6-3 Selection of the "bobbin thread counting function"</p> <table border="1" data-bbox="513 246 1374 548"> <tr> <td style="text-align: center;">OFF</td> <td>The bobbin thread counting function is operative. (The function works.)</td> </tr> <tr> <td>ON (This switch has been set to the ON position at the time of delivery.)</td> <td>The bobbin thread counting function is inoperative. The Counter display on the operation panel works as the addition counter which counts up from "000" to "999". (When "999" is reached, the number on the display returns to "000".) The number on the Counter display is reset to "000" whenever pressing the Reset switch.</td> </tr> </table> <p>* Bobbin thread counting function</p> <p>This is the function to make the number shown on the Counter display flash on and off to warn the operator that it is the time to stop the sewing machine (the feeding frame switch and start switch become inoperative) and to change the bobbin after the completion of sewing the pattern on the predetermined number of workpieces.</p> <ul style="list-style-type: none"> Count the number of workpieces that can be sewn with one bobbin by pattern beforehand, and set the number on the Counter under the setting mode. (See the explanation of the switches on the operation panel on page 17.) Depressing the Reset switch make the feeding frame switch and start switch operative again allowing the sewing machine to continue sewing. (At this time, the number indicated on the Counter display will return to the initial value.) The two types of indicating method (counting method) are available for the Counter display, one is addition and the other is subtraction. Refer to the description on the SW6-2. <p>• Bobbin thread counting function flow</p> <pre> graph TD A[Input (specify) a value on the Counter display under the setting mode.] --> B[Turn ON the Set Ready switch.] B --> C[Sew the number of workpieces specified.] C --> D[The display flashes on and off. The sewing is no longer possible. The feeding frame switch and start switch are inoperative.] D --> E[Replace the bobbin.] E --> F[Turn ON the Reset switch. The display is reset.] F --> C </pre> <p>(Repeat)</p>	OFF	The bobbin thread counting function is operative. (The function works.)	ON (This switch has been set to the ON position at the time of delivery.)	The bobbin thread counting function is inoperative. The Counter display on the operation panel works as the addition counter which counts up from "000" to "999". (When "999" is reached, the number on the display returns to "000".) The number on the Counter display is reset to "000" whenever pressing the Reset switch .
OFF	The bobbin thread counting function is operative. (The function works.)				
ON (This switch has been set to the ON position at the time of delivery.)	The bobbin thread counting function is inoperative. The Counter display on the operation panel works as the addition counter which counts up from "000" to "999". (When "999" is reached, the number on the display returns to "000".) The number on the Counter display is reset to "000" whenever pressing the Reset switch .				

Name of switch	Function				
<p>⑥ DIP switch 6 (SW6)</p>  <p style="text-align: center;">SW6</p> <p>(at the time delivery)</p>	<p>• SW6-4 Selection of the "enlargement/reduction function"</p> <table border="1" data-bbox="526 360 1369 622"> <tr> <td data-bbox="526 360 783 465">ON</td> <td data-bbox="783 360 1369 465">The pattern cannot be enlarged/reduced. The [X/Y scale] switches in the control panel are made inoperative and the scale is fixed at 100%.</td> </tr> <tr> <td data-bbox="526 465 783 622">OFF (This switch has been set to the OFF position at the time of delivery)</td> <td data-bbox="783 465 1369 622">The pattern is enlarged/reduced when reading in the pattern from the floppy disk.</td> </tr> </table> <p>Refer to the explanation of the "[X scale] switch" and "[Y scale] switch" on page 18 for how to specify the X/Y scale.</p>	ON	The pattern cannot be enlarged/reduced. The [X/Y scale] switches in the control panel are made inoperative and the scale is fixed at 100%.	OFF (This switch has been set to the OFF position at the time of delivery)	The pattern is enlarged/reduced when reading in the pattern from the floppy disk.
	ON	The pattern cannot be enlarged/reduced. The [X/Y scale] switches in the control panel are made inoperative and the scale is fixed at 100%.			
	OFF (This switch has been set to the OFF position at the time of delivery)	The pattern is enlarged/reduced when reading in the pattern from the floppy disk.			
	<p>• SW6-5 Selection of the "thread breakage detection function"</p> <table border="1" data-bbox="526 819 1369 1108"> <tr> <td data-bbox="526 819 783 952">ON</td> <td data-bbox="783 819 1369 952">The "thread breakage detection function" is not effective. Set the SW6-5 to the ON position when the sewing machine is idling.</td> </tr> <tr> <td data-bbox="526 952 783 1108">OFF (This switch has been set to the OFF position at the time of delivery.)</td> <td data-bbox="783 952 1369 1108">The "thread breakage detecting function" works. When a thread breakage occurs, the machine automatically performs thread trimming, and stops running indicating error [9].</td> </tr> </table>	ON	The "thread breakage detection function" is not effective. Set the SW6-5 to the ON position when the sewing machine is idling.	OFF (This switch has been set to the OFF position at the time of delivery.)	The "thread breakage detecting function" works. When a thread breakage occurs, the machine automatically performs thread trimming, and stops running indicating error [9].
ON	The "thread breakage detection function" is not effective. Set the SW6-5 to the ON position when the sewing machine is idling.				
OFF (This switch has been set to the OFF position at the time of delivery.)	The "thread breakage detecting function" works. When a thread breakage occurs, the machine automatically performs thread trimming, and stops running indicating error [9].				
<p>• SW6-6 Selection of the "thread trimmer prohibition function"</p> <p>This switch is used to make the machine perform sewing without actuating the thread trimmer even if the thread trimming command has been entered in a pattern.</p> <table border="1" data-bbox="526 1279 1369 1592"> <tr> <td data-bbox="526 1279 783 1435">ON</td> <td data-bbox="783 1279 1369 1435">Thread trimmer does not work. Set the SW6-6 to the ON position when the thread trimmer components may be damaged by an excessive load if the thread trimmer is actuated in the case where a thick thread is used.</td> </tr> <tr> <td data-bbox="526 1435 783 1592">OFF (This switch has been set to the OFF position at the time of delivery.)</td> <td data-bbox="783 1435 1369 1592">The thread trimmer is actuated by the "thread trimming command".</td> </tr> </table>	ON	Thread trimmer does not work. Set the SW6-6 to the ON position when the thread trimmer components may be damaged by an excessive load if the thread trimmer is actuated in the case where a thick thread is used.	OFF (This switch has been set to the OFF position at the time of delivery.)	The thread trimmer is actuated by the "thread trimming command".	
ON	Thread trimmer does not work. Set the SW6-6 to the ON position when the thread trimmer components may be damaged by an excessive load if the thread trimmer is actuated in the case where a thick thread is used.				
OFF (This switch has been set to the OFF position at the time of delivery.)	The thread trimmer is actuated by the "thread trimming command".				
<p>• SW6-7 Selection of the "wiper prohibition function"</p> <p>The switch mounted on the machine head can be used to stop the wiper but the SW6-7 is used to make the wiper inoperative in the stage of function setting. This shortens the time required for sewing by a certain degree.</p> <table border="1" data-bbox="526 1787 1369 2011"> <tr> <td data-bbox="526 1787 783 1843">ON</td> <td data-bbox="783 1787 1369 1843">The wiper does not work.</td> </tr> <tr> <td data-bbox="526 1843 783 2011">OFF (This switch has been set to the OFF position at the time of delivery)</td> <td data-bbox="783 1843 1369 2011">The wiper actuates after thread trimming.</td> </tr> </table>	ON	The wiper does not work.	OFF (This switch has been set to the OFF position at the time of delivery)	The wiper actuates after thread trimming.	
ON	The wiper does not work.				
OFF (This switch has been set to the OFF position at the time of delivery)	The wiper actuates after thread trimming.				

Name of switch	Function				
<p>⑥ DIP switch 6 (SW6)</p>  <p>(at the time of delivery)</p>	<p>• SW6-8 Selection of the "intermediate presser stop function"</p> <p>This switch is used to make the intermediate presser inoperative.</p> <table border="1" data-bbox="523 280 1364 660"> <tr> <td data-bbox="523 280 782 504">ON</td> <td data-bbox="782 280 1364 504">The intermediate presser does not work. (Caution) If the intermediate presser is set to inoperative with the intermediate presser attached on the machine, the needle bar may hit against the intermediate presser, resulting in breakage of the related components.</td> </tr> <tr> <td data-bbox="523 504 782 660">OFF (This switch has been set to the OFF position at the time delivery.)</td> <td data-bbox="782 504 1364 660">The intermediate presser actuates.</td> </tr> </table> <p>(Caution) Set the SW6-8 to the OFF position as long as the intermediate presser is normally used.</p>	ON	The intermediate presser does not work. (Caution) If the intermediate presser is set to inoperative with the intermediate presser attached on the machine, the needle bar may hit against the intermediate presser, resulting in breakage of the related components.	OFF (This switch has been set to the OFF position at the time delivery.)	The intermediate presser actuates.
ON	The intermediate presser does not work. (Caution) If the intermediate presser is set to inoperative with the intermediate presser attached on the machine, the needle bar may hit against the intermediate presser, resulting in breakage of the related components.				
OFF (This switch has been set to the OFF position at the time delivery.)	The intermediate presser actuates.				
	<p>• SW6-1 is used for maintenance. It does not need to be operated. Leave this switch to its OFF position.</p>				

Name of switch	Function																					
<p>⑦ DIP switch 7 (SW7)</p>  <p>(at the time of delivery)</p>	<p>• SW7-3 Selection of the "thread trimming after emergency stop function"</p> <p>This switch is used to make the machine automatically actuate the thread trimmer after pressing the Emergency stop switch on the machine head.</p> <table border="1" data-bbox="497 443 1369 996"> <tr> <td data-bbox="497 443 778 728">ON</td> <td data-bbox="778 443 1369 728"> <p>When the Emergency stop switch is turned ON, the machine automatically actuates the thread trimmer and stops with its needle up. Since the machine performs thread trimming, the error indication 5 lights up instead of flashing on and off. Consequently, you can operate the Forward switch, Backward switch and Return to Origin switch immediately after the aforementioned operation.</p> </td> </tr> <tr> <td data-bbox="497 728 778 996">OFF (This switch has been set to the OFF position at the time of delivery.)</td> <td data-bbox="778 728 1369 996"> <p>When the Emergency stop switch is turned ON, the machine will stop with its needle up. The error indication 5 flashes on and off. To make the Forward and Backward switches and Return to Origin switch operative, move the Needle threading switch up and down once (to turn it ON and OFF) so that the error indication 5 lights up.</p> </td> </tr> </table> <p>Refer to the description on the switches on the operation panel on page 19 for the function and operation of the Forward and Backward switches and Return to Origin switch.</p>	ON	<p>When the Emergency stop switch is turned ON, the machine automatically actuates the thread trimmer and stops with its needle up. Since the machine performs thread trimming, the error indication 5 lights up instead of flashing on and off. Consequently, you can operate the Forward switch, Backward switch and Return to Origin switch immediately after the aforementioned operation.</p>	OFF (This switch has been set to the OFF position at the time of delivery.)	<p>When the Emergency stop switch is turned ON, the machine will stop with its needle up. The error indication 5 flashes on and off. To make the Forward and Backward switches and Return to Origin switch operative, move the Needle threading switch up and down once (to turn it ON and OFF) so that the error indication 5 lights up.</p>																	
ON	<p>When the Emergency stop switch is turned ON, the machine automatically actuates the thread trimmer and stops with its needle up. Since the machine performs thread trimming, the error indication 5 lights up instead of flashing on and off. Consequently, you can operate the Forward switch, Backward switch and Return to Origin switch immediately after the aforementioned operation.</p>																					
OFF (This switch has been set to the OFF position at the time of delivery.)	<p>When the Emergency stop switch is turned ON, the machine will stop with its needle up. The error indication 5 flashes on and off. To make the Forward and Backward switches and Return to Origin switch operative, move the Needle threading switch up and down once (to turn it ON and OFF) so that the error indication 5 lights up.</p>																					
	<p>• SW7-4 Selection of the sewing speed at sewing start</p> <p>The rotational speed (sewing speed) of the sewing machine at the start of sewing can be set to one of the following two different speeds.</p> <table border="1" data-bbox="555 1281 1295 1451"> <thead> <tr> <th>SW7-4</th> <th>1st stitch</th> <th>2nd stitch</th> <th>3rd stitch</th> <th>4th stitch</th> <th>5th stitch</th> <th>6th stitch</th> </tr> </thead> <tbody> <tr> <td>OFF</td> <td>200</td> <td>→ 600</td> <td>→ 1000</td> <td>→ 1400</td> <td>→ 1800</td> <td>→ 2000</td> </tr> <tr> <td>ON</td> <td>600</td> <td>→ 600</td> <td>→ 1000</td> <td>→ 1400</td> <td>→ 1800</td> <td>→ 2000</td> </tr> </tbody> </table> <p>This switch has been set to the OFF position at the time of delivery.</p> <p>* Sewing speed In the AMS machines, the sewing speed is limited by stitch length. For example, the maximum sewing speed is 2,000 s.p.m. when sewing a pattern with the stitch length of 3 mm as shown in the table above. However, the maximum sewing speed for a pattern with the stitch length of 4 mm is 1,500 s.p.m., which means that the sewing speed cannot be set to a value exceeding 1,500 s.p.m.</p>	SW7-4	1st stitch	2nd stitch	3rd stitch	4th stitch	5th stitch	6th stitch	OFF	200	→ 600	→ 1000	→ 1400	→ 1800	→ 2000	ON	600	→ 600	→ 1000	→ 1400	→ 1800	→ 2000
SW7-4	1st stitch	2nd stitch	3rd stitch	4th stitch	5th stitch	6th stitch																
OFF	200	→ 600	→ 1000	→ 1400	→ 1800	→ 2000																
ON	600	→ 600	→ 1000	→ 1400	→ 1800	→ 2000																

Name of switch	Function				
<p>⑦ DIP switch 7 (SW7)</p>  <p>(at the time of delivery)</p>	<p>• SW7-6 Selection of the "feeding frame position at sewing end change-over function"</p> <table border="1" data-bbox="497 253 1361 683"> <tr> <td data-bbox="497 253 774 510">ON</td> <td data-bbox="774 253 1361 510"> <p>The feeding frame keeps clamping the sewing product (cloth, etc.) instead of going up upon completion of sewing. If you wish to raise the feeding frame, depress the <u>feeding frame switch</u>. (Caution) The sewing machine cannot start sewing unless the feeding frame is lifted once.</p> </td> </tr> <tr> <td data-bbox="497 510 774 683">OFF (This switch has been set to the OFF position at the time of delivery.)</td> <td data-bbox="774 510 1361 683"> <p>The feeding frame goes up upon completion of sewing. (Normal state)</p> </td> </tr> </table>	ON	<p>The feeding frame keeps clamping the sewing product (cloth, etc.) instead of going up upon completion of sewing. If you wish to raise the feeding frame, depress the <u>feeding frame switch</u>. (Caution) The sewing machine cannot start sewing unless the feeding frame is lifted once.</p>	OFF (This switch has been set to the OFF position at the time of delivery.)	<p>The feeding frame goes up upon completion of sewing. (Normal state)</p>
ON	<p>The feeding frame keeps clamping the sewing product (cloth, etc.) instead of going up upon completion of sewing. If you wish to raise the feeding frame, depress the <u>feeding frame switch</u>. (Caution) The sewing machine cannot start sewing unless the feeding frame is lifted once.</p>				
OFF (This switch has been set to the OFF position at the time of delivery.)	<p>The feeding frame goes up upon completion of sewing. (Normal state)</p>				
	<p>• SW7-7 Selection of the "automatic retainer compensation function"</p> <p>This switch is used to select either automatically or manually correct the position of the retainer.</p> <table border="1" data-bbox="497 835 1361 1070"> <tr> <td data-bbox="497 835 774 902">OFF</td> <td data-bbox="774 835 1361 902"> <p>The "automatic retainer compensation function" works.</p> </td> </tr> <tr> <td data-bbox="497 902 774 1070">ON (This switch has been set to the ON position at the time of delivery.)</td> <td data-bbox="774 902 1361 1070"> <p>The "automatic retainer compensation function" does not work.</p> </td> </tr> </table> <p>• Retainer compensation The X-Y table built in the sewing machine uses the component called "retainer" which moves together with the feed mechanism. It may shift from its predetermined position after a long period of usage, resulting in deformed shape of sewing pattern or an error in the origin retrieval. So, it is necessary to correctly position the retainer approximately once a day.</p> <p>① Automatic compensating operation The automatic retainer compensation function works when turning ON the <u>Set Ready switch</u> for the first time after turning <u>ON the power</u> to the machine. The feeding frame comes down, and the feed mechanism travels back and forth until its stroke end is reached. (Then, the feed mechanism moves to the sewing start point or the 2nd origin as in the case of normal sewing, and the feeding frame goes up. This completes the automatic retainer compensating action.) * <u>The automatic retainer compensation is not performed when the <u>Set Ready switch</u> is pressed for the second time and afterward.</u></p> <p>② How to manually correct the position of the retainer Turn OFF the power to the sewing machine. Then gradually move the feed mechanism by hand, back and forth and to the right and left until it will go no further. (About once a day)</p>	OFF	<p>The "automatic retainer compensation function" works.</p>	ON (This switch has been set to the ON position at the time of delivery.)	<p>The "automatic retainer compensation function" does not work.</p>
OFF	<p>The "automatic retainer compensation function" works.</p>				
ON (This switch has been set to the ON position at the time of delivery.)	<p>The "automatic retainer compensation function" does not work.</p>				
	<p>• SW7-1, -2, -5 and -8 are used for maintenance. They do not need to be operated. Leave these switches as they have factory-set at the time of delivery.</p>				


Name of switch	Function
② Rotary DIP Switch 2 (SW2) 	<ul style="list-style-type: none"> Value set at "0".... (This switch is set at "0" at the time of delivery) Make sure that the switch has been set at "0" for normal sewing.
	<ul style="list-style-type: none"> Value set at "2".... Serves to check the input of the individual switches and detection signals, as well as the output of the numerical displays. <ol style="list-style-type: none"> When the switch is set at "2" and the power switch is turned ON, all the digital displays will be indicated by "8". When the feeding frame switch or the start switch is pressed, the step of display A will be updated. When a step input is received, the corresponding display will be indicated by "1" or "0" to indicate the status of the switch.

(Display)

Pattern No.	A	B	C
X-scale	D	E	F
Y-scale	G	H	I

(Display table)

Display Step A	B	C	D	E	F	G	H	I
0	0 (Operation switch)	1 (Operation switch)	2 (Operation switch)	3 (Operation switch)	4 (Operation switch)	5 (Operation switch)	6 (Operation switch)	7 (Operation switch)
1	8 (Operation switch)	9 (Operation switch)	Pattern No. (Operation switch)	X-scale (Operation switch)	Y-scale (Operation switch)	Bobbin winder (Operation switch)	Forward (Operation switch)	Backward (Operation switch)
2	Reset (Operation switch)	Return to Origin (Operation switch)	Ready (Operation switch)	Emergency stop Thread trimming ON/OFF (SW7-3)	Sewing speed 1 (SW7-4)	Sewing speed 2 (SW7-5)	Sewing end Presser ON/OFF (SW7-6)	Initial feed action (SW7-7)
3	Material thickness (SW4-4)	Material thickness (SW4-3)	Digitizer X/Y inversion (SW4-2)	Combination standard (SW4-1)	Air sensor	(SW7-1)	(SW7-2)	Needle threading switch (Control box)
4	Start switch	Feeding frame switch 1	Feeding frame switch 2	Emergency stop switch	Bobbin winder (Control box)	Sewing machine ON/OFF switch (Control box)	INC/DEC of the stitch length or No. of stitches switch (Control box)	(PGM-1)
5	Standard/double-step work clamp (SW5-8)	Pedal selector (SW5-7)	Double-step work clamp Pedal selector (SW5-6)	Origin detection (SW5-5)	Wiper actuating position selection function (SW5-4)	Sewing start point travel, Second origin setting (SW5-3)	Cycle sewing function (SW5-2)	Double step work clamp Cycle sewing function (SW5-1)
6	Intermediate presser stop function (SW6-8)	Wiper prohibition (SW6-7)	Thread trimmer inoperative (SW6-6)	Needle thread breakage detection function (SW6-5)	Enlargement/reduction prohibition (SW6-4)	Reset function (SW6-3)	Counter function (SW6-2)	Double-step work clamp Sequence selector (SW6-1)
7	(SW1-8)	(SW1-4)	(SW1-2)	(SW1-1)	(SW2-8)	(SW2-4)	(SW2-2)	(SW2-1)
8			Thread breakage detector	Down detection signal	Up detection signal	Solenoid slip-off signal	T/G pulse signal	
9	X origin	Y origin	+ X limit	-X limit	+Y limit	-Y limit		



DIP switch name	Function
② Rotary DIP Switch 2 (SW2) 	<ul style="list-style-type: none"> • Value set at "5"... Serves to check the machine origin. <ol style="list-style-type: none"> 1. Set the switch at "5", turn ON the power switch, and treadle the feeding frame switch. The feeding frame will come down. 2. Treadle the start switch, the origin will be automatically found, and the machine will stop at the origin. The feeding frame remains lowered.
	<ul style="list-style-type: none"> • The DIP switches, SW2-1, 3, 4, 6 to 9, A to F are used for maintenance purposes. These switches do not particularly need to be reset before operation.

15. Disk formatting function

Any new disk must be formatted (on the *MS-DOS) before use.

All patterns stored in a disk can also be erased by formatting.

* MS-DOS is a registered trademark of Microsoft Inc., in the U.S.A.



- 1) Turn ON the **power switch** while pressing switches ① and ②. This makes the machine ready for formatting a disk. At this time the Pattern No. display will show "FFF".
- 2) Insert a disk into which data can be written (a disk with its write protect hole closed) into the disk drive, and press the **Set Ready switch**.
- 3) The Pattern No. display indicates the format track Nos., and tracks from 0 to 79 are formatted. After the completion of formatting the disk, the Pattern No. display will show "FFF".
- 4) When the disk has been formatted, turn OFF the power to the machine once and turn ON it again. This will allow the machine to exit from the disk formatting mode.

(Caution)

If you should take the disk out or turn the power OFF during formatting, the disk cannot be used. The disk must be formatted again.

If an error "0" is displayed, it means the disk is defective. Do not use the disk.

16. Data backup function

In order to operate your AMS sewing machine, it is necessary to read a pattern you wish to sew in the main unit of the sewing machine after energizing the sewing machine (turning ON the power switch).


However, if you use the same pattern repeatedly, you can omit the aforementioned procedure when actuating the sewing machine (turning ON the power switch) after turning OFF the power switch once.

(Operating procedure)

- When you turn OFF the power switch while the machine operates under the sewing mode (while the READY indicator lamp lights up), the currently used pattern which has been read in the main unit of the sewing machine is automatically stored in memory built in the main unit of the sewing machine.

(If turning OFF the power switch when the machine is in the setting mode, the data backup function does not work.)

- Then, turn ON the power switch, and turn ON the Set Ready switch without changing the set values for the "Pattern No.", "X scale" and "Y scale". This will change over the operation mode of the sewing machine to the setting mode without taking the pattern read-in procedure. As a result, you can use the pattern used before turning OFF the power switch for sewing again. (In this case, there is no need for a floppy disk.)



(Caution)

1. The 2nd origin and sewing start point which are set by jog switches are also stored in memory together with the pattern.
2. Even if setting the Pattern No., X scale and Y scale to the values same as those used before turning OFF the power switch, the machine does not perform the pattern read-in operation.

3. If you wish to read the pattern with the Pattern No. same as that sewn before turning OFF the power switch from another floppy disk using the X scale and Y scale same as those used before, turn OFF the power switch once while the machine is set to the setting mode to make the data backup function inoperative.
4. The scale setting switch for INC/DEC of the stitch length & INC/DEC of the number of stitches mounted on the front face of the control box, as well as the Pattern No., etc., is also related to the pattern reading function. So, if changing the set value of the scale setting switch, the data backup function will be ineffective.

17. Needle-up position stop function

In the AMS machines, when the needle is not at its highest position, error No. 3 will be indicated on the display. In this case, the foot switch, etc. are inoperative and the sewing machine cannot be operated. If the needle is not in its highest position under the sewing mode, you can bring the needle to its highest position by operating this switch instead of manually turning the pulley.

(Operating procedure)

If the needle is not in its highest position under the sewing mode, move the Needle threading switch mounted on the front face of the control box up and down after confirming there is nothing under the tip of needle.

- ① Move up the Needle threading switch. The feeding frame and the intermediate presser come down.
- ② Move down the Needle thread switch. The sewing machine makes one revolution (the needle goes up and comes down), and stops with its needle up. → The feeding frame and the intermediate presser go up.


(Caution)

The feeding frame, intermediate presser and needle moves up and down. It is very dangerous, therefore, to perform the above-stated operation with your hands, etc. placed under the feeding frame, intermediate presser and the tip of needle. So be careful.


18. Enlargement/reduction function

The AMS machine is capable of enlarging/reducing a pattern when reading the pattern from the floppy disk. The pattern can be enlarged/reduced in the range of 1% to 400% (1/100 to 4 times of the original size) while the size of pattern written in the floppy disk is taken as 100%.

1) Switches used for the enlargement/reduction function



2) Operating procedure



19. Pattern combination function




This function enables the machine to read only the desired parts of the patterns stored in the floppy disk to combine them for sewing.

The total number of stitches that can be combined is 16,000 stitches at the maximum. As long as the total number of stitches does not exceed 16,000, you need not care about the number of patterns.

If you have created embroidery patterns of all the alphabets respectively in the floppy patterns beforehand, you can combine some of these patterns to sew initials. This allows you to sew many different persons' names using a considerably small number of patterns (only 26 different patterns from A through Z).


(Patterns stored in the floppy disk)

- No. 1 ← "A"
- No. 2 ← "B"
- No. 3 ← "C"
- No. 4 ← "D"
- ⋮
- No. 26 ← "Z"



Pattern combination function

(Operating procedure)



This function is operated in the special way which is different from the other functions.

① Actuating the "pattern combination function"


Basically, the function is actuated by pressing the power switch while pressing the switches on the operation panel, as in the case of actuating the "disk formatting function" (See page 36).

The "pattern combination function" can be actuated in the four different ways in accordance with the pattern combining methods.

	Actuating method	Pattern combining method
1	Turn ON the power switch while pressing the 0 and 2 switches.	The patterns are overlapped. (Fig. 1) (The origins of the respective pattern read in the machine are aligned.)
2	Turn ON the power switch while pressing the 0 and 5 switches.	The patterns are spliced. (Fig. 2) (The sewing end of the pattern read first is aligned with the origin of the pattern to be read next.)
3	Turn ON the power switch while pressing the 0 and 3 switches.	The patterns are overlapped while inserting a "temporary stop (pause)" between them. (Fig. 3)
4	Turn ON the power switch while pressing the 0 and 6 switches.	The patterns are spliced while inserting a "temporary stop (pause)" between them. (Fig. 4)


- Example of pattern combination -

Patterns stored in the floppy disk




For all the combination of patterns, pattern No. 1 is read in first, and pattern No. 2 is read next.


(Fig. 1)



(Fig. 2)



(Fig. 3)




(Caution)

Refer to the description on the SW5-2 on page 26 for the function of the "temporary stop (pause)".

② Reading in a pattern

Normally, the pattern created under the setting mode is automatically read in at the moment when the setting mode is changed over to the sewing mode by turning ON the Set Ready switch. However, the pattern is read under the setting mode when actuating the "pattern combination function".

Use the Reset (select) to read in the pattern.



* When the data reading operation has been completed, turn ON the READY switch. This will make the sewing machine ready for sewing and to allow you to sew the combined patterns.

③ Erasing the pattern read in

If you have read in the pattern which is not necessary for your sewing by mistake and combine it with the other patterns, you cannot erase the wrong pattern.

So, if you have made a mistake in the pattern reading operation, it is necessary for you to re-actuate the function and carry out the pattern reading operation from the very start.

(This is also applied to the case where you wish to make a new combination of patterns after completing the previous sewing.)

④ Storing the patterns combined in memory

The patterns you have combined are stored in memory in the main unit of the sewing machine by turning OFF the **power switch** under the **sewing mode** (when the READY indicator **lamp lights** up) by means of the backup function described on page 37. If you use the combined patterns again for the next sewing, actuate the machine by turning ON the **power switch** as in the normal operation.

(Caution)


- The Counter display (bobbin thread counter) on the operation panel does not count up/down until all the patterns combined have been finished.

(Refer to the explanation of the SW6-2 on page 29 for the Counter.)

- Be sure to start sewing the patterns combined after confirming that the combined patterns do not exceed the predetermined sewing area.

20. Operation procedure flow chart

Follow the operation flow chart given below:



Sewing machine ON/OFF switch → OFF
 INC/DEC of the stitch length or the number of stitches → select one of the two.
 Bobbin winder → OFF
 Needle threading switch → OFF


The sewing machine motor starts.
 The operation panel lamps light up.


The ready indication lamp flashes on and off during the computation.

Error indication "A": When the air pressure drops.
 Error indication "3": When the needle is not in its highest position.

Refer to the explanation of the error indications. (Page 21)


The feed mechanism travels to its X/Y limit once after turning ON the power switch.






Positioning

Is the material clamped securely?




The thread breakage detector mechanism has been activated.



Threading the machine

Move to the 2nd origin if it has been set.



Eliminate the cause of the emergency stop.

★ Cautions in Operation


- 1) Before sewing a new pattern or a newly enlarged pattern, be sure to carry out trial sewing to check the pattern size with respect to the feeding frame.
- 2) The maximum sewing speed varies according to the stitch length.
The maximum sewing speed is automatically limited as shown in the table below according to the stitch length. If necessary, the maximum sewing speed can also be limited manually using the max.speed limit control knob.

Stitch length (mm)	Max.sewing speed (s.p.m.)
8.4~10.0	600
7.2~ 8.2	700
6.6~ 7.0	800
6.0~ 6.4	900
5.4~ 5.8	1,000
5.2	1,100
4.8~ 5.0	1,200
4.4~ 4.6	1,300
4.2	1,400
3.8~ 4.0	1,500
3.6	1,600
3.4	1,800
3.2	1,900
0.2~ 3.0	2,000

- 3) When an error indication is given, be sure to identify the cause and take corrective action.
- 4) Prior to operation, be sure to close the control box cover in order to prevent dust from getting into the control box. Dust into the control box may lead to malfunctions or failures. **Clean the fan filter once every week.**
- 5) Be sure to turn the power OFF before opening the control box cover.
- 6) Avoid checking the control circuitry by a tester, or else the tester voltage may be applied to a semiconductor component, and the component may be damaged.
- 7) Be sure that there is no obstacle under the needle before depressing the start switch to wind a bobbin.
- 8) Do not put your fingers or any other things under the feeding frame when the machine is computing (this is indicated by the READY lamp flashing ON and OFF), since the feeding frame comes down automatically upon completion of the computation.
- 9) Do not pull the sewing product on the machine during sewing. This may shift the needle position. If the X-Y needle entry point is dislocated, press the Set Ready switch twice. This will make the needle return to its predetermined sewing start position.

IV. MAINTENANCE

1. Adjusting the height of the needle bar




- 1) Bring needle bar ① to the lowest point of its stroke. Make the upper marker line on the needle bar align with the bottom end of the needle bar lower bushing, and remove cap ② . Then loosen needle bar connection screw ③ , and adjust the height of the needle bar properly.
- 2) The needle bar has a pair of marker lines for the DP x 5 and another pair of marker lines for the DP x 17. Properly use these pairs of marker lines according to the needle used.

(Caution)

After adjustment, be sure to turn the handwheel to check that the pulley rotates smoothly with a uniform torque. Slightly retard the shuttle timing for sewing floppy materials, or slightly advance it for sewing heavy-weight materials.


2. Adjusting the needle-to-shuttle relationship




- 1) Turn the pulley by hand so that lower marker line ② on the ascending needle bar ① is aligned to bottom end of needle bar lower bushing ③ . Loosen screw ④ (with hexagon socket head) in the shuttle driver. Open right and left hooks ⑤ in the direction of the arrows while pulling them toward you, and remove shuttle race ring ⑥ .

(Caution)


At this time, be careful not to let shuttle ⑦ come off and fall.



- 2) Adjust so that the point of shuttle ⑦ meets the center of needle ⑧, and that plane A of shuttle driver ⑨ is flush with shuttle driving shaft ⑩. Then tighten screw ④ in the driver.




- 3) Loosen screw ⑪ in the shuttle driving shaft front bushing. Then turn adjusting shaft ⑫ of the shuttle driving shaft front bushing so that a clearance of 0 mm is provided between needle ⑧ and front end face of driver ⑨. Then tighten screw ⑪.




- 4) Loosen screw ⑬ in the shuttle race. Turn shuttle race adjusting shaft ⑭ clockwise/counterclockwise to adjust the longitudinal position of the shuttle race so that a clearance of 0.01 to 0.06 mm is provided between needle ⑧ and the blade point of shuttle ⑦.
- 5) After the longitudinal position of the shuttle race has been properly adjusted, adjust the direction of rotation so that a clearance of 7.5 mm is provided between the needle and the shuttle race. Then tighten screw ⑬ in the shuttle race ring.
(When using thin threads with a thread count of #50 or higher, adjust the clearance between the needle and the shuttle race to 7.2 mm.)


3. Adjusting the moving knife and the counter knife




- 1) Stop the machine with its needle up. Eliminate a play in the knife components by moving them in the direction of the arrow. Then, loosen adjustment screw ②, and adjust so that, when the machine stops with its needle up, a 3.5 mm clearance is provided between the thread spreader of moving knife ① and the end of the needle eyelet.
- 2) After the adjustment, manually actuate the thread trimmer to check for proper positioning.
- 3) Loosen screw ⑤, and adjust so that a clearance of 0.8 mm is provided between needle hole guide ③ and counter knife ④.

4. Adjusting the height of the intermediate presser



- 1) Confirm that the needle enters just the center of intermediate presser ①.
- 2) When Needle threading switch ② on the control box is set to the  position while the READY indicator lamp lights up, the feeding frame and the intermediate presser will come down. Loosen screw ③, and adjust so that a clearance of 0.5 mm (thickness of the needle thread used) is provided between the material and the bottom end of the intermediate presser when the needle is brought to the lowest point of its stroke by turning the pulley. If using a floppy material, adjust the clearance as small as the extent where the intermediate presser comes in contact with the material (a 0 mm clearance).
- 3) After the adjustment, set Needle threading switch ② to the  position. Then the machine rotates until it stops with its needle up. (The intermediate presser can be used with the material of which thickness is 5 mm or less.)


5. Adjusting the height of the feeding frame



- 1) Loosen screws ①, and move work clamp stopper ② to in the direction of arrow A to decrease the height of feeding frame ③, or in the direction of arrow B to increase it.
 - 2) After the adjustment, securely tighten screws ①.
- (Caution)

The machine has on its right- and left-hand sides work clamp stopper ②. So be sure the adjust both of them in the same manner.

6. Adjusting the wiper




When the READY indicator lamp is ON, move the needle up to its highest position, and set the Needle threading switch to the ∇ position. Adjust so that, when wiper ① passes under the needle point, the clearance between the wiper and the needle point becomes 1 mm or more and the clearance between the wiper and the intermediate presser becomes also 1 mm or more.

Loosen screw ②, and perform the aforementioned adjustment.

When the wiper ① is in its home position, the distance between the center of the needle and the end face of wiper ① should be 40 mm.


Loosen wiper arm clamping screw ③, and perform the aforementioned adjustment by changing the installing angle of wiper arm ④. (If using a material of which thickness exceeds 3 mm, there will be no clearance between the wiper and the needle and also between the wiper and the intermediate presser. In this case, change over the DIP switch SW5-4 referring to page 28.)

7. Adjusting the thread breakage detector



- 1) Adjust so that thread breakage detector disk ① is always in contact with thread take-up spring ② in the absence of the needle thread.
(Slack: approx. 0.5 mm)
- 2) Whenever the stroke of thread take-up spring ② has been changed, be sure to readjust thread breakage detector disk ①. To make this adjustment, loosen screw ③.
- 3) Adjust so that thread breakage detector disk ① does not touch any adjacent metallic parts other than thread take-up spring ②.


8. Adjusting the needle-up position



- 1) Marker dot ① on the machine arm should stop between upper red marker dot ② and lower red marker dot ③ on the handwheel.
 - 2) When adjusting screw ④ is loosened and moved in the direction of arrow A, the machine will stop at lower marker dot ③. When it is moved in the direction of arrow B, the machine will stop at upper marker dot ②.
- (Caution)





1. Usually, no adjustment is required. However, if the stop position has been adjusted, be sure to check the new stop position, setting a workpiece.
2. If the machine stops before the lower marker dot is reached, chances for thread trimmer failure or thread slipping off the needle may increase. On the contrary, if the machine stops beyond the upper marker dot, the wiper may interfere with the needle. Properly adjust the stop position.

9. Adjusting the opening amount of tension disk



- 1) Remove the arm top cover.
- 2) Loosen screw ①, and adjust the opening amount of the tension disk at the time of thread trimming to 0.6 to 0.8 mm by moving tension bracket ②.
- 3) After the adjustment, turn the handwheel by hand to confirm that the tension is kept open until the thread take-up lever reaches its highest dead point and it is securely closed after the thread take-up lever has once reached there.


10. Adjusting the vertical stroke of the intermediate presser



- ★ The vertical stroke of the intermediate presser can be changed within the range of 3 to 7 mm.
- 1) Remove screw ①, and remove cover ②.
- 2) Loosen nut ③ in the intermediate presser connecting shaft, and move intermediate presser rod ④ in the direction of arrow A to make the vertical stroke of the intermediate presser larger, or in the direction arrow B to make it smaller. The standard adjustment value is 4 mm.
- 3) Marker dots ④, ⑤ and ⑥ on intermediate presser arm ⑤ are used as reference when adjusting the stroke on the intermediate presser foot. When marker ④ is aligned with the center of nut ③ of the intermediate presser rod connecting shaft, the vertical stroke of the intermediate presser becomes 6 mm. When marker ⑤ is aligned with the center of the nut, it becomes 5 mm, or when marker ⑥ is aligned with the center of the nut, it becomes 4 mm.


- ★ To adjust the vertical stroke of the intermediate presser to 0 mm (to keep the intermediate presser at its lowest dead point), perform the following adjustment.
- 4) Fix nut ③ of the intermediate presser connecting shaft to the lowest position.
- 5) Bring the needle bar to its highest dead point.
- 6) Remove screw ⑥, and remove front cover ⑦.
- 7) Loosen screw ⑧, and adjust so that a clearance of 0.5 mm is provided between intermediate presser positioning link ⑩ and positioning pin ⑪ by moving intermediate presser oscillating shaft ⑨.
- 8) Firmly tighten screw ⑧.

* Confirm that intermediate presser positioning link ⑩ does not come in contact with positioning pin ⑪ and that intermediate presser oscillating shaft ⑨ does not come in intermediate presser spring ⑫ when turning the handwheel by hand to make the main shaft rotate.
 Carry out the above-stated adjustment after setting the air pressure to 0 kg/cm². (See "4. Connecting the air supply" on page 6.)



- ★ To return the vertical stroke of the intermediate presser foot from 0 mm to 3 to 7 mm, perform the following adjustment.
- 9) Bring the needle bar to its lowest dead point.
 - 10) Loosen screw ⑧, and move intermediate presser oscillating shaft ⑨ to make intermediate presser positioning link ⑩ come in close contact with positioning pin ⑪. Then adjust the clearance ⑬ between intermediate presser connecting stud and intermediate presser bar bushing ⑭ to 3 mm.
 - 11) Firmly tighten screw ⑧.


11. Removing the V belt



- 1) Remove side cover ①, Y sensor cover ②, table rear cover ③ and belt cover ④.
- 2) Remove screws ⑤, and remove Y-direction slit plate ⑥.
- 3) Remove V belt ⑦.

(To install Y-direction slit-plate ⑥, determine first the longitudinal position of the slip plate using positioning pin ③. Then install the slip plate so that it enters in the groove of Y sensors as deep as 5 mm from the top of the sensors. Confirm that Y-direction slit plate ⑥ passes the center of the groove of Y sensors ⑨ and that the slit plate does not come in contact with the sensors.)


12. Cleaning the filter



Clean the filter ② of the control box fan once every week.


- 1) Pull the screen kit ① in the direction of the arrow to remove it.
- 2) Wash the filter ② under running water.
- 3) Reinstall the filter ② and the screen kit ① .

13. Changing the direction of rotation of the sewing machine



- 1) Turn the power switch OFF.
- 2) Remove connector ① from the rear of the motor (on the opposite side from the handwheel).
- 3) Change the direction of connector by 180°, and reconnect it securely until it will go no further.

14. Replacing the fuse






The machine uses the following six fuses:






- ① 7A standard melting fuse for stepping motor (X) protection
- ② 7A standard melting fuse for stepping motor (Y) protection
- ③ 10A standard melting fuse for stepping motor power supply protection
- ④ 7AT time-lag fuse for solenoid power supply protection
- ⑤ 1A standard melting fuse for 100VAC power supply protection
- ⑥ 2A standard melting fuse for marking light power supply protection






(Caution)


To replace a blown fuse, turn the power switch OFF, open the control box cover, and replace it with a new fuse with the specified capacity.

V. OPTIONS

Name of part	Type	Part No.	Size (mm)
<p>1. Intermediate presser foot</p> 	Intermediate presser foot (A)	B1601 220 000	$\phi A \times \phi B \times l \times L$ 2.2×3.6×6×29.5
	Intermediate presser foot (B)	B1601 220 00B	$\phi A \times \phi B \times l \times L$ 3.5×5.5×6×29.5
	Intermediate presser foot (E)	B1601 220 00E	$\phi A \times \phi B \times l \times L$ 1.6×2.6×6×29.5
	Intermediate presser foot (F)	B1601 220 00F	$\phi A \times \phi B \times l \times L$ 2.2×3.6×9×29.5
	Intermediate presser foot (G)	B1601 220 00G	$\phi A \times \phi B \times l \times L$ 2.7×4.1×5×29.5
	Intermediate presser foot (C)	B1601 220 00C	$\phi A \times \phi B \times \phi C \times l \times L$ 2.2×3.6×12×6×29.5
	Intermediate presser foot (D)	B1601 220 00D	$\phi A \times \phi B \times L$ 2.2×12×34.5
<p>2. Needle hole guide</p> 	Needle hole guide (A) for light-weight materials	B2426 210 00A	$\phi A = 1.6$
	Needle hole guide (B) for medium-weight materials	B2426 210 00B	$\phi A = 2.0$
	Needle hole guide (C) for knitted materials	B2426 210 00C	$\phi A = 1.6$
	Needle hole guide (D) for heavy-weight materials	B2426 210 00D	$\phi A = 2.4$
	Needle hole guide (F) for heavy-weight materials	B2426 210 00F	$\phi A = 3.0$
	Needle hole guide (G) for heavy-weight materials	B2426 210 00G	$\phi A = 3.0$ (with a counterbore)
	<p>3. Plastic blank</p> 	Plastic feeding frame blank stud	B2559 220 000
Plastic feeding frame blank plate		B2557 220 000	$A \times B \times t$ 278×193×3
Screw		SS1090510SP	
Rubber sheet		B2591 220 000	$A \times B \times t$ 250×200×1.5

Name of part	Type	Part No.	Size (mm)
4. Auxiliary throat plate cover sheet 	Auxiliary throat plate cover sheet	B1170 220 000	$A \times B \times t$ $564 \times 300 \times 0.13$
5. Sponge sheet for feeding frame 	Sponge sheet for feeding frame	B2591 220 00B	$A \times B \times t$ $296 \times 196 \times 1.5$
6. Feeding frame blank 	Feeding frame blank	B2553 220 0Y0	$A \times B \times t$ $344 \times 218 \times 4$
7. Feed plate blank 	Feed plate blank with knurl	B2556 220 0Y0	$l_1 = 350$ $l_2 = 243$
	Feed plate blank without knurl	B2556 220 0YB	$l_1 = 350$ $l_2 = 243$

Name of part	Type	Part No.	Size (mm)
8. Origin gauge 	Origin gauge	B2593 220 000	$A \times B \times t$ $294 \times 193 \times 3$
9. Origin reference lower plate 	Origin reference lower plate	B2594 220 000	$l_1 \times l_2$ 350×243.5
10. Cassette holder 	Cassette holder fixing plate setscrew	SS9151 440 CP	
	Cassette holder fixing plate	B2581 220 000	$l_1 = 328$
	Cassette holder (asm.)	B2582 220 0A0	$l_1 \times l_2$ 380×247.5
11. Compressor unit 		CU03	

Name of part	Type
<p data-bbox="215 302 414 336">12. Milling device</p> 	<p data-bbox="997 302 1077 336">MU03</p>

VI. TROUBLES AND CORRECTIVE MEASURES

Trouble	Cause	Corrective measures	Page
1. Thread slips off the needle at sewing start	① Stitches are skipped at sewing start.	○ Adjust the clearance between the needle and the shuttle to 0.01 to 0.06 mm.	51
	② The thread remaining on the needle after thread trimming is too short.	○ Decrease the tension given by thread tension controller No.1.	9
	③ The bobbin thread is too short.	○ Increase the tension of the thread take-up spring.	9
		○ Decrease the bobbin thread tension.	9
	④ The feed timing is bad.	○ Increase the clearance between the needle hole guide and the counter knife.	53
		○ Properly adjust the feed timing.	24
2. Thread often breaks or synthetic thread splits finely.	① The shuttle or the shuttle driver has scratches.	○ Remove the shuttle or the shuttle driver, and remove the scratches, using a whetstone or buff.	7
	② The needle has a defective eye.	○ Replace the needle.	
	③ The needle hole guide has scratches.	○ Buff or replace the needle hole guide.	
	④ The intermediate presser hole is scratched.	○ Buff or replace the intermediate presser.	
	⑤ The needle hits the intermediate presser.	○ Adjust the position of the intermediate presser.	
	⑥ Fibrous wastes are in the groove of the shuttle race.	○ Remove the shuttle, and remove the fibrous wastes.	
	⑦ The needle thread tension is too high.	○ Decrease the needle thread tension.	
	⑧ The thread take-up spring tension is too high.	○ Decrease the thread take-up spring tension.	
⑨ The synthetic thread melts due to frictional heat.	○ Use silicone oil.	7	
	○ Use a needle with lower count.	7	
	○ Decrease the sewing speed.	50	
3. Needle often breaks.	① The needle is bent.	○ Replace the needle.	7
	② The needle hits the intermediate presser.	○ Adjust the position of the intermediate presser properly.	24
	③ The feed timing is bad.	○ Adjust the timing to feed the material properly.	
	④ The needle is too thin for the material.	○ Change the needle with one of which count is suited to the material.	7
	⑤ The needle bends in contact with the shuttle driver.	○ Correct the needle-to-shuttle relationship in position.	51
4. Thread trimmer fails to trim thread.	① The counter knife is dull.	○ Replace the counter knife.	53
	② The clearance between the needle hole guide and the counter knife is too small.	○ Correct the clearance.	53
	③ The moving knife has been improperly positioned.	○ Correct the position of the moving knife.	
	④ The last stitch has been skipped.	○ Correct the timing between the needle and the shuttle.	51
		○ Attach the needle so that the long groove of the needle faces slightly to the right.	7

Trouble	Cause	Corrective measures	Page
5. Stitches are frequently skipped.	① The timing between the needle and the shuttle is bad.	○ Correctly position the shuttle with respect to the needle.	51
	② The clearance between the needle and the shuttle is too large.	○ Correctly position the shuttle with respect to the needle.	51
	③ The needle is bent.	○ Replace the needle.	7
	④ The feed timing is not correct.	○ Correct the feed timing.	24
	⑤ The needle bends in contact with the shuttle driver.	○ Correct the position of the shuttle driver.	51
	⑥ The height of the intermediate presser is incorrect.	○ Correct the height of the intermediate presser.	53
	⑦ The needle is not attached correctly.	○ Attach the needle so that the long groove of the needle faces slightly to the right.	7
6. Improperly tensed stitches are made.	① Needle thread tension is insufficient.	○ Increase the needle thread tension.	9
	② Tension disc No. 2 floats from its predetermined position.	○ Adjust installation of tension disc No. 2.	9
	③ Feed timing is not proper.	○ Adjust the material feed timing.	24
	④ Height of intermediate presser is improper.	○ Adjust the height of the intermediate presser.	53
7. Thread breadks at the time of thread trimming.	① The moving knife has been improperly positioned.	○ Correct the position of the moving knife.	53
8. The sewing product slips out of the predetermined position on the machine during sewing.	① The sewing product is not securely clamped.	○ Attach a non-slip material such as a piece of emery paper on the reverse side of the feeding frame. ○ Machine an exclusive feeding frame made of metal.	
9. The needle thread loosens.	① The needle thread is insufficient.	○ Increase the needle thread tension.	
	② Single yarn of the needle thread loosens due to untwisted needle thread.	○ Increase the needle thread tension. ○ Replace the needle with a thicker needle. ○ Apply silicon oil.	

VII. EXPLANATION OF TERMINOLOGY

- Needle-up stop position

The needle (main shaft) always stops at the predetermined position at the sewing end. This predetermined position is called the needle-up stop position. If the needle (main shaft) is not in the highest position before the sewing machine starts sewing or starts idling or other operations, an error may result. In this case, the sewing machine is inoperative.
- Feed

The AMS Series feeds the workpiece (cloth, etc.) using a stepping motor in accordance with the motion of needle in order to sew the workpiece according to the pattern desired. The components that transmit the motion of stepping motor to the workpiece are called the "feed."
- Feed forward/Feed backward

The feed is moved forward or backward by operating the Forward switch or Backward switch on the operation panel. The position of the needle can be moved toward the sewing end along the pattern shape by one stitch by pressing the Forward switch. On the other hand, it can be moved toward the sewing start along the pattern shape by one stitch by pressing the Backward switch. This function is conveniently used when sewing a pattern from the middle or checking a pattern shape.
- Feed timing

The AMS Series of sewing machine has adopted the "intermittent feed system" to feed the material. This system feeds the workpiece (cloth, etc.) while the needle comes off the workpiece. It is to say, the feed completes the feeding of the workpiece when the needle penetrates the workpiece. The relationship between the vertical stroke of the needle and the performance of the feed mechanism is called the "feed timing."

 - * If the thickness of the workpiece is excessive, the needle starts penetrating the workpiece before the feed completes the feeding of the workpiece, resulting in stitch skipping or needle breakage. In this case, adjust the feed timing using the relevant DIP switch.
- Jump feed

This means that the needle point moves without sewing the workpiece. The "jump feed" is available as same as the "zigzag" input and "point sewing" input in the "Main Unit Input Function" or the "PGM Series." The "jump" is widely used to join a pattern with another or many other occasions.
- Function

One particular action of the machine is called "function."
There are many different kinds of function including major ones such as the "pattern combining function" which are actuated by operating several switches and minor ones such as "needle-up position stop function" which are actuated by operating single switch.
These function will help you greatly as you are familiar with the operation of the AMS Series of sewing machine.

 - * All the functions of this sewing machine are listed on page 67.
- Origin

The word "origin" indicates the following two different points according to circumstances.

 - ① Mechanical origin For the AMS sewing machine, a mechanical origin is designated that can be found by the relevant sensor.
The mechanical origin is the standard position of the main unit of the sewing machine.
 - ② Origin for a pattern This is the standard position of the pattern created.
When reading a pattern in the sewing machine, the origin for the pattern should be aligned with the mechanical origin of the sewing machine.
(The two origins may not be aligned with each other when using the pattern combining function.)

- **Origin retrieval**
 This is the performance to let the stepping motor which moves the workpiece (cloth, etc.) know the position of the origin (mechanical origin) after turning ON the power to the sewing machine.
 Turning ON the **Set Ready** switch under the **setting state** makes the stepping motor retrieve the mechanical origin. After the completion of the performance of origin retrieval, the motor moves to the sewing start.
(Caution) The feeding frame automatically comes down at the time of origin retrieval. So, do not put your hands, etc. under the feeding frame at that time.
- **Return to origin**
 This function is actuated by pressing the **Return to Origin** switch on the operation panel.
 When the **Return to Origin** switch is pressed in the middle of a pattern, the needle position may move (return) directly to the sewing start and the feeding frame goes up.
 If the pattern has the 2nd origin, the needle point may move (return) to the 2nd origin.
- **Cycle**
 If a pattern contains a pause (intermediate stop command), the machine automatically stops at the pause position to allow the operator to raise the feeding frame and add a workpiece (cloth, etc.) to the currently sewn one.
 The former part of a pattern and latter part of it which is divided by a pause are respectively called "cycle." Consequently, in this case, the pattern has two cycles.
- **Jog switches**
 These switches are used to move the feed and the needle point as desired. They are used in the "2nd origin setting function", "sewing start point changing function" and "main unit input function."
- **Setting state**
 This is one of the basic terms used for the AMS Series. The setting state is a state of the sewing machine in which the values (pattern No., etc.) required to allow the AMS to read pattern data are specified using the operation panel switches.
- **Second origin**
 The 2nd origin is a position (point) to which the needle point is moved before starting sewing regardless of the shape of pattern to be sewn. Normally, the 2nd origin is created in a pattern at the time of inputting pattern data, however, the AMS Series is capable of inputting the 2nd origin using the 2nd origin setting function of the main unit of the sewing machine just before sewing a pattern selected.
- **Sewing start point**
 This is the position of the first stitch of a pattern. If the 2nd origin has not been specified, the needle point moves to the sewing start point before starting sewing.
- **Inversion point**
 This is the position to drive the inverting mechanism (reverse the inverting clamp). It is necessary for an inversion pattern (label attaching pattern, etc.) sewn by the AMS sewing machine with an inverting mechanism.
 There are two different methods to input an inversion point, one is to input it automatically at the predetermined position and the other is to input it at a position that can be specified as desired.
- **Pattern**
 A sewing pattern to be sewn. Generally, this word indicates the patterns that have been written in a floppy disk. If you find words "sewing pattern", suppose that the 2nd origin or jump are not contained in the words. However, remember that the word "pattern" includes all the data of pattern including the 2nd origin and jump.
 * Pattern data is sometimes called "data" in explanations.
- **Writing a pattern**
 This is the procedure to store a pattern created using the "main unit input function" or "PGM Series" of programming devices in a floppy disk.
 To write a pattern using the "main unit input function", it is necessary for you to prepare a "2DD" floppy disk which has been formatted beforehand.

• Inputting a pattern

This is the procedure to create a pattern to be sewn using the "main unit input function" or "PGM Series" of programming devices.

After inputting a pattern, the pattern is written in a floppy disk (stored in memory). Then the actual sewing is carried out using the floppy disk with set in the sewing machine.

* Refer to the Instruction Manual for the "main unit input function" or that for the "PGM Series" for how to input (create) a pattern.

• Reading a pattern

This is the procedure to read a pattern stored in a floppy disk out to the memory of the main unit of the sewing machine.

This procedure is also called "read-out of a pattern." Both words can be also used in the case of taking a pattern in the memory of the input devices including the PGM-1.

• Disk format

Any new disk cannot be used with the AMS or PGM Series as it is. It must be initialized to make it adaptable to a device with which the disk is to be used. The procedure is called "disk format" (or "format").

* If you format a used-up floppy disk, all the data stored in it will be erased, as you know by the word "initialize." After the formatting, the floppy disk will be one that is same as a new floppy disk formatted.

• Flow chart

It is a chart that shows the operating procedure and the performance of the sewing machine provoked by the procedure in order. Some flow charts are inserted in this Instruction Manual. They explain the aforementioned items concerning certain operations respectively in a simple way. In addition, a flow chart covering the whole operation of the sewing machine is shown.

The flow charts will help you in many occasions.

• Sewing size

Each model of the AMS Series of sewing machine has its own sewing size within which the sewing is possible. (Refer to the "Specifications.") If the needle point excessively goes out of the specified sewing size when sewing a large pattern, the relevant sensor works to stop the sewing machine with the Error 4 indicated on the panel.

• READY indicator LED

This is the indicator lamp to discriminate the sewing state from the setting state of the sewing machine. (Refer to page 14 for each state of the sewing machine.)

(Sewing state ... The READY indicator LED lights up. Setting state ... The READY indicator LED goes out.)

• Sewing state

This is one of the basic terms for the AMS Series. It is the state under which the AMS sewing machine is capable of performing normal operation (sewing, bobbin winding, etc.).

• Sewing speed

The sewing speed is expressed in the unit of "s.p.m.", which indicates the number of stitches to be sewn in one minute.

In the AMS Series, the maximum sewing speed is limited in accordance with the stitch length.

However, the sewing speed can be specified in several ways as long as the sewing speed remains within the max. sewing speed.

• Retainer compensation

This is one of the maintenance procedures to help you use the AMS for a long time.

(Major functions table)

Name of function	Page for reference
Main unit input function	
Data back-up function	P. 37
Enlargement/reduction function	P. 31
Second origin setting function	P. 27
Wiper actuating point selecting function	P. 28
Bobbin replacement setting function	P. 30
Thread trimmer prohibition function	P. 31
Intermediate presser stop function	P. 32
Function of changing-over the feeding frame position at the sewing end	P. 34
Error detecting function (safety mechanism)	
Pattern combination function	P. 40
Disk formatting function	P. 36
Needle-up stop function	P. 37
Sewing start point moving function	P. 33
Pedal change-over function	P. 28
Bobbin thread counting function	P. 29
Wiper prohibition function	P. 31
Function of automatic thread trimming at the time of emergency	P. 33
Automatic retainer compensation function	P. 34
Cycle stitching function	P. 26

[Dimensions of the feeding frame]

