

clckr
USER MANUAL
ENGLISH

1

ATTENTION!

SPECIAL INSTRUCTIONS FOR MOBILE PHONE WITH GLASS BACKPLATE:


IF YOU HAVE A DEVICE WITH A GLASS BACK AND DO NOT USE A CASE, PLEASE USE THE SUPPLIED FILM AS INDICATED BELOW:

PAY ATTENTION!

STICK THE FILM ON TO YOUR DEVICE BEFORE ATTACHING YOUR GRIP. THIS WILL ENSURE THAT THE GRIP WILL STAY IN PLACE.

THIS PROCEDURE IS NOT NECESSARY FOR OTHER DEVICES OR WITH THE USE OF A CASE. KEEP IN MIND THAT THIS FILM CAN ONLY BE USED ONCE.

1. THE GRIP
2. FILM
3. DEVICE



2

APPLICATION OF THE GRIP:



APPLY YOUR GRIP AT ROOM TEMPERATURE.

DECIDE WHERE YOU WOULD LIKE TO POSITION YOUR GRIP BEFORE APPLYING, AS YOU CAN ONLY MOUNT IT A COUPLE OF TIMES.

IF YOU ARE USING A MOBILE DEVICE WITH GLASS BACKPLATE PLEASE USE THE ADDITIONAL FILM BEFORE PLACING THE GRIP (SEE PAGE 1).

CAREFULLY READ THE REVERSE SIDE OF THIS MANUAL ON HOW TO CORRECTLY APPLY THE GRIP TO YOUR PHONE OR PHONE CASE.

3



APPLYING THE GRIP

1. CLEAN THE BACK OF YOUR PHONE OR CASE.
2. REMOVE THE PROTECTIVE LAYER FROM THE ADHESIVE TAPE.
3. POSITION THE GRIP NEAR THE BOTTOM OF YOUR PHONE OR CASE, AS SHOWN ABOVE, AND APPLY PRESURE FOR 1 MINUTE.
4. PULL THE GRIP TO CHECK IF THE GRIP STICKS PROPERLY TO THE PHONE OR CASE.

4

CLCKR IS NOT RESPONSIBLE FOR:

*ANY DAMAGE TO ANY SURFACE CAUSED BY THE USE OR APPLICATION OF THE GRIP.

*ANY DISCOLORATION RESULTING FROM THE APPLICATION OR REMOVAL OF YOUR GRIP.

*ANY DAMAGE TO ANY DEVICE AND DEVICE PROTECTION RESULTING FROM THE INCORRECT USE OF THE GRIP. CAREFULLY READ THE MANUAL ON THE REVERSE SIDE TO SEE HOW THE GRIP CAN BE USED CORRECTLY.

* ANY DAMAGE TO A MOBILE DEVICE WITH A GLASS BACK AS RESULT OF NOT USING THE ADDITIONAL ADHESIVE TAPE.



clckr.com




#clckr



@clckrofficial


5



GRIP & STAND USAGE

1. OPEN THE BAND BY PULLING THE TOP OF THE 'CLOSED' STRAP AS SHOWN.
2. YOUR STRAP IS NOW IN AN 'OPEN' POSITION.
3. FOLD THE STRAP LIKE SHOWN AND PRESS BOTH SIDES UNTIL THEY SNAP. YOUR STRAP IS NOW IN 'STAND' FUNCTION.


6



GRIP FUNCTION

1. START WITH THE GRIP IN THE 'OPEN' POSITION.
2. SLIDE IN YOUR HAND PALM FACING YOUR PHONE. THE GRIP SHOULD BE PLACED WITHIN THE MARKED AREA*.
3. HOLD NATURALLY FOR A SECURE GRIP DURING YOUR ACTIVITY.

7



STAND FUNCTION

1. START WITH THE GRIP IN 'STAND' FUNCTION.
2. THE GRIP WILL NOW FORM A STEADY VERTICAL 'PORTRAIT' STAND FUNCTION.
3. ROTATE YOUR PHONE FOR A STEADY HORIZONTAL 'LANDSCAPE' STAND FUNCTION.

8

REMOVING THE GRIP:

TO REMOVE THE GRIP FROM ANY SURFACE CAREFULLY PUT YOUR FINGERNAIL UNDER THE BACK OF THE PLASTIC BACKPLATE AND CAREFULLY LIFT IT FROM THE ATTACHED SURFACE.

