



- 1 Register a domain (profile) at the Microhard NMS website at nms.microhardcorp.com. Click on [Register](#), located in the top right corner of the page.



- 2 Fill in the registration information as described below.



Domain Name: Logical management zone for cellular devices to report to, separate from other users. Each device needs to be directed to this domain.


Domain Password: Required for each device for security and to ensure each device reports to the correct zone.

Email Address: The email address used here will be the login username. Upon registration a confirmation email will be sent. Once confirmed, you will be the administrator of the domain and able to create sub-domains, users, etc.

- 3 Log into the IPn3G as shown in the [IPn3G Quick Start](#) and navigate to the [Tools > NMS Settings](#) menu.



- 4 Configure the IPn3G to report to NMS as described below.



NMS Server/IP: Enter the address of where the NMS is hosted. The default is nms.microhardcorp.com, unless hosted privately.

Domain: Enter the Domain information as it was entered in the registration step.

Carrier Location: Enable/Disable location estimation via carrier connection. When enabled there is some data consumption to retrieve the information from internet.


Report Status: Enable/Disable UDP reporting to the NMS system.

Interval(s): Enter how often the unit will report data to NMS. Set according to your data plan.

Interfaces: Choose which data to report. The more selected, the bigger the UDP packets.

- 5 The Web Service is used to remotely control the device, such as scheduled reboots, firmware upgrade, etc. Once enabled, the unit will periodically check to see if there are any tasks for it to perform.

- 6 When NMS receives the first report from the IPn3G, it will send an Email to the Domain Administrator to authorize the device to join the domain. If it is desired to have devices join the domain without requiring authorization, this can be changed in NMS, under [Settings > Domain Management](#), and then right clicking on the desired domain name, and selecting Edit Domain



Microhard Systems Inc.


150 Country Hills Landing N.W. Calgary, AB T3K 5P3

Web: www.microhardcorp.com

Email: info@microhardcorp.com



Phone: (403) 248 - 0028 Fax: (403) 248 - 2762

- 1 Install SIM Card - Ensure contacts are facing up, and the notch is towards the modem as shown. The card will "click" into place when installed correctly.



- 2 Install/Attach Antennas


- 3 Attach/Apply power (7-30 VDC)



- 4 Connect to the USB (requires drivers) or Ethernet port for configuration. To access the WebUI, open a web browser and enter the IP address in the address bar, for USB use **192.168.111.1**, for Ethernet use **192.168.0.1**.



- 5 Login using the default login, username: **admin** password **admin**



- 6 Under the Carrier tab, configure the APN, Username, Password, etc, as required by your Cellular Carrier

To download the most up to date user manuals, visit the Microhard Website @

www.microhardcorp.com/support

Login using your existing account, or for specific access to the Cellular products use the following general login:

Email: cellular@microhardcorp.com

Password: **mhscell**

**Please clear your browsers cache (history) if you experience difficulties logging in*

To connect to the IPn3G for web browser configuration use the following default IP Addresses:

Ethernet/RJ45: **192.168.0.1**

USB/NDIS: **192.168.111.1**

The default login as follows:

Username: **admin**

Password: **admin**

Microhard Systems Inc.

**150 Country Hills Landing N.W.
Calgary, AB T3K 5P3**

**Web: www.microhardcorp.com
Email: info@microhardcorp.com**

Phone: (403) 248 - 0028

Fax: (403) 248 - 2762