

Unified victor Integration Software for DMP Integration version 3.00.1165.0

Version A2 Release Notes
January 2016

This document provides important information about the victor Integration Software for DMP Intrusion Integration. Please read this file before installing the product.

Product: victor Integration Software for DMP Intrusion Integration

- Release: 4.8 SP1
- DMP Integration Software: v3.00.1165.0

Contents

1. Overview	2
2. Software Requirements	2
3. Qualified Operating Systems	2
4. Contents	2
5. Server Prerequisites	2
6. Client Prerequisites	2
7. Installation	3
8. Post Installation	3
9. Issues and Limitations	3
End of Release Notes	4

1. Overview

The victor platform provides seamless integration with the DMP Intrusion Security System, allowing customers to monitor their important intrusion system devices from victor. The software also monitors the Intrusion Panel status; arm/disarm Partition, activate/de-activate Output and Bypass/Reset Zones.

2. Software Requirements

The victor Application Server Integration software for DMP Intrusion requires the following firmware versions:

- DMP Intrusion firmware:

DMP Panel Model	DMP Panel Firmware
XR500N	V206, V208, V212
Canadian Version XR500N	V208, V206, V212
XR500E	V212, V208
XR100N	V206,V208, V212

- victor Unified Client: V4.8 SP1

3. Qualified Operating Systems

All Operating systems supported by victor are supported by this driver. Refer to victor product data sheets.

4. Contents

The victor Integration Software for DMP Integration contains the following:

- `Unified_DMP-Integration.exe` - DMP Unified Integration software setup file.

5. Server Prerequisites

- Administrator rights on the server.
- victor Application Server licensed for DMP Integration.

6. Client Prerequisites

- Administrator rights on the client.
- Administration Workstation.
- Monitoring Station.
- victor unified client.

7. Installation

Install the DMP Integration on the victor Application Server/remote client by running `Unified_DMP-Integration.exe`.

For detailed instructions on installing the DMP Integration to victor, see the *victor unified client DMP Integration User Manual*.

NOTE: The DMP Integration server components cannot be installed on a victor Application Server MAS.

Close any running applications to avoid installation problems.

NOTE: Client workstations requiring the ability to setup the DMP Integration objects will need to install the DMP Unified Integration client components.

8. Post Installation

1. Launch the Server Configuration Application (Run as Administrator) from the Start Menu:
 - Start > All Programs > Tyco
2. Restart the CrossFire services:
On the Services tab:
 - a. Click **Stop Service** for the Crossfire Framework Services and wait for all Services to show **Status: Stopped**.
 - b. Click **Start Service** for the Crossfire Framework Services and wait for it to show **Status: Running**.
 - c. Click **Start Service** for the Crossfire Server Component Framework Services and wait for **Status: Running** to appear across all services.
3. On the Server Components tab:
 - a. Click **Start Service** for the **DMP Driver Service** and wait for it to show **Status: Running**.

9. Issues and Limitations

The following are the list of DMP Intrusion Integration functionalities, which are not working in the current release:

- When the DMP Partition is disarmed, the DMP Zones that were previously in a bypassed state display the victor supervision status as **Bypass** instead of **Open**, due to panel limitations.
- DMP panel comes online irrespective of Panel Type selected in the DMP Panel Configuration window.
- DMP output status is not reported by the panel to victor. Output status is only updated during the synchronization operation.
- Messages for the activities performed during the offline state of the panel are reported with the current timestamp.
- DMP Hardware with the Canadian version does not support remote Arm.
- Occasionally, multiple device activity messages are logged in the victor Activity Viewer.
- First time configuration of 'Blank' type zone shows status as 'Unknown' for Hardware, Supervision and Active state.

- After disarming armed Partition from victor, associated bad state zones status is still displayed as 'Bypassed' in victor.
- Partition schedule status is only updated after Synchronization. Because the panel does not notify the schedule status changes through the Alarm Channel, Partition schedule status changes are not reported in the Victor Activity Viewer. Once Synchronization has been performed, the Partition schedule status will be updated.
- Key Fob zones are not supported in this integration.
- Migration of a standalone machine with a DMP Driver to SAS is not supported.
- Journaling of system activity messages is not supported in this integration.
- When victor unified client is upgraded from 4.7.1 to 4.8 SP1 or from 4.8 to 4.8 SP1, the integration service will be missing from the Server Configuration application. Resynchronize the DMP integration driver from **Programs and Features** or the integration installer, and click **Resynchronize**.

End of Release Notes

The trademarks, logos, and service marks displayed on this document are registered in the United States [or other countries]. Any misuse of the trademarks is strictly prohibited and Tyco Security Products will aggressively enforce its intellectual property rights to the fullest extent of the law, including pursuit of criminal prosecution wherever necessary. All trademarks not owned by Tyco Security Products are the property of their respective owners, and are used with permission or allowed under applicable laws.

Product offerings and specifications are subject to change without notice. Actual products may vary from photos. Not all products include all features. Availability varies by region; contact your sales representative.

© 2016 Tyco Security Products.
All rights reserved.