

OTIS Elevator integration for victor v5.2

Release Notes

8200-1147-1111
Document Revision: C0
March 2021

This document provides important information about the unified victor Integration Software for OTIS Elevator Integration. Read this document before you install the product.

Product: Unified Integration Software for OTIS Elevator Integration

- Integration Software Version: 2.61.11.0

This driver release is qualified with victor when installed on:

- victor Unified Systems v3.60 (C•CURE v2.61 and victor v5.0)
- victor Unified Systems v3.65 (C•CURE v2.61 and victor v5.1)
- victor Unified Systems v3.70 (C•CURE v2.70 and victor v5.2)

Overview

The OTIS Compass Elevator System Integration in combination with the Unified victor system provides security to particular floors in a multi-level building. It ensures that that only authorized persons can access a particular floor, or exit from that floor.

Access to particular floors is determined by swiping a card to a card reader. The card reader is located outside the elevator car, either near Destination Entry Computer (DEC) or inside DEC. The DEC accesses the personnel privilege assigned to a specific OTIS Elevator access configuration outside of the elevator.

Features

The Unified OTIS Elevators Integration offers the following features:

- Supports Operational Modes 1 through 4:
 - Mode 1 - Default Floor Only
 - Mode 2 - Access to Authorized Floors
 - Mode 3 - User Entry of Destination Floor
 - Mode 4 - User Entry of Default Floor

You can also schedule these modes.

- Supports Interface Control Document (ICD) Version 1.0, 2.0 and 3.0.
- Provides floor selection messages for a DEC.
- Provides a Destination Entry Server (DES) Audit display that shows the elevator activity of personnel.
- Supports front and rear door configuration.
- Schedule-based floor access for all personnel.
- Supports DEC PIN code entry. When this feature is enabled the customer can use PIN code entry to navigate to floors in the building without needing to swipe their card.
- Supports the use of card swipe on the inbuilt reader of the DEC.
- Remote monitoring using the Activity Viewer.
- Each elevator group supports 255 floors, and the front and rear doors of each elevator cab.
- Each elevator system supports up to 240 DEC devices.

- Supports Default Floor configuration.
- Schedule actions to secure (locked) or unsecure (unlocked) floors.
- Supports the assigning of an exemption group who can access secured floors.
- Supported 5 DES per Server and 3 DEC per DES

Hardware Requirements

The OTIS Elevator Integration has the same hardware, and disk space requirements as the Unified Application Server. If the target computer meets the Unified Server requirements, then it satisfies OTIS Elevator Integration requirements.

Software Requirements

The unified OTIS Elevators Integration requires the following software:

- victor unified client: v5.0/v5.1/v5.2
- C•CURE 9000 Security and Event Management System and Software House iSTAR Controllers
- OTIS Simulator version AAA31468BAD
- OTIS DEC (physical device: PN- XAA23505A) version AAA31526AAA

Contents of the Installation Package

The following table lists the contents of the OTIS Elevator Integration installation package:

Table 1: Installation Package

File	Description
OTIS_Integration.exe	Installation program for the Otis Elevator System Integration software
victor-Otis-v5-2-UM-8200-1147-1128-C0-en.pdf	victor OTIS Elevator System Integration Guide
victor-Otis-v5-2-RN-8200-1147-1111-C0-en.pdf	Release Notes for Unified OTIS Elevator Integration

Supported Installation Types

The unified OTIS Elevator Integration supports the following installation types:

- Unified Standalone
- Unified Enterprise

Pre-Installation

Before you install the unified OTIS Elevator Integration, ensure that your system meets the following criteria:

On the victor Application Server:

- You must have appropriate Windows permissions.
- You must be a member of the local Administrators group, or you must have equivalent privileges.
- Ensure that you are on a reliable network.
- You must install the Unified Application Server with the following options:
 - Unified Application Server
 - OTIS

On the Clients:

- You must have appropriate Windows permissions.
- You must be a member of the local Administrators group, or you must have equivalent privileges.
- You must install the Monitoring station, Administration workstation and the victor. See the *victor Installation Quick Start Guide* for more information. This is available at www.americandynamics.net.

Installation

Note:

- You must install the OTIS Elevator Integration in the same folder as victor.
- Close all applications to avoid problems during installation.

Follow the same steps to install OTIS Elevator Integration on the Server and on Clients:

1. Navigate to <http://www.americandynamics.net>.
2. Download an appropriate version of the OTIS Integration Software Driver.
3. Right-click `OTIS_Integration.exe` and select **Run as Administrator**.
The Install Wizard begins installing the software, and the OTIS Elevator Integration **Welcome** screen appears.
4. Click **Next** and follow the Install Wizard prompts.
5. On the License Agreement, select the I accept the terms in the license agreement check box and then click Next.
6. Click **Finish** to complete the installation.

Note: You cannot install the OTIS Elevator Integration server components on a victor Application Server MAS (Master Application Server).

Post-Installation

Perform the following steps after installation:

1. Launch the Server Configuration Application:
 - a. On the taskbar, click the **Start** button and then click **All Programs**.
 - b. Click Tyco, right-click the Server Configuration and then click Run as Administrator. The Server Configuration Application page opens.
2. Start the OTIS Services:
 - a. On the Server Configuration Application page, click to open the Services tab.
 - b. Ensure that both Crossfire Framework Service and Crossfire Server Component Framework Service are **running**.
 - c. In the **Extension Services** area, locate the **OTIS Receiver Driver Service**. Select the **Enabled** check box and then click the **Start** button. The status of the OTIS Receiver Driver Service changes to **Running**.
3. Launch the victor client:
 - a. On the taskbar, click the **Start** button and then click **All Programs**.
 - b. Click **victor**.
4. Launch the C•CURE client:
 - a. On the taskbar, click the **Start** button and then click **All Programs**.
 - b. Click **Tyco** and then click **C•CURE 9000**.

Upgrading the OTIS Elevator Integration

Caution:

If you have made any changes in the configuration file - `OTISElevatorDriverService.exe`, ensure that you back up the file before you upgrade. The configuration file is located at `Tyco\CrossFire\ServerComponents`.

Follow the steps to upgrade the OTIS Elevator Integration:

- Upgrade victor v4.8 SP1/v4.8.1/v4.9 to v5.2, and then install the OTIS Elevator System Integration.
- Upgrade victor v4.9.1 to v5.2, and then install the OTIS Elevator System Integration.

Note: This driver is compatible with victor v5.0, victor v5.1 and victor v5.2. A new installation or resynchronization is not required if the integration was installed on victor v5.0 and victor v5.1, and you upgrade to victor 5.2.

Scalability

This driver is qualified with 5 DES per server and 3 DEC's per DES.

Language Support

This driver supports the English (US) language.

Compatibility Matrix

The table below lists the Compatibility Matrix for the OTIS Elevator Integration:

Table 2: Compatibility Matrix

victor versions 5.0, 5.1 and 5.2	
Partner	OTIS
Partner Product	Elevator Integration/Destination Dispatch
Partner Product version	OTIS DEC version AAA31526AAA OTIS Simulator version AAA31468BAD ICD version 1.0, 2.0, and 3.0.
Integration driver version	2.61.11.0
victor License option	ADVC-OTIS
Enterprise certified	Yes
Redundancy certified	No
Supported Server OS	All OS supported by victor Server
Supported Client OS	All OS supported by victor Client
Supported SQL	All SQL Server supported by victor

Known Issues and Limitations

This section describes the OTIS Elevator known limitations.

- To upgrade this driver to the current version, you must use the same User Account that you used to install the earlier version of the OTIS Elevator Integration.
- If you assign multiple clearances to a personnel record, the landing matrix is retrieved for all clearances, including expired clearances that are associated with this personnel record.
- OTIS Elevator Integration does not support the following access control functions:
 1. Antipassback
 2. Area Lockout
 3. Area Configuration
 4. Occupancy Counting
 5. Intrusion Zones
- When group manual actions are canceled from the MAS Client Activity Viewer, no actions are performed.
- Synchronized audit and journal log messages on MAS do not show the complete details of configured objects.
- For deactivated and canceled manual actions, the operator icon is displayed in the Journal Log Messages instead of the manual action icon.
- Manual actions performed on OTIS landing objects in the MAS Remote Client (victor) do not work.
- Validation of parity bit is not supported during processing of card reader data received from OTIS DEC.
- You must select the ICD version manually. It is not automatically configured based on the ICD version in the DES (Destination Entry Server).
- You must reboot the DES after you change the ICD version. This ensures that victor reflects the allowed floors in the DES.
- During the upgrade the ICD version is set as '3'. After an upgrade you must set the ICD version to an appropriate value.
- The card format that is configured with the Issue Code field must be linked with the CHUID that is configured with the Issue Code field.
- Do not configure personnel with identical card numbers if card formats of the same data length and format fields are associated with the DEC.
- If you install the OTIS Elevator Integration on remote clients, the Integration Setup dialogue box appears and you may be prompted to select an Installation Option for Redundancy sever. Ignore this message and click Next to continue with installation.
- If you select the Redundancy sever installation using supported third party redundancy check box, provide the virtual server location, and then click Next; this selection can be ignored and there is no functional impact.
- victor does not have provision to create Clearance, hence it is mandatory to create Clearance in C•CURE before creating Clearance Landing Matrix in victor.
- Migration of a standalone machine with an OTIS Driver to SAS is not supported.
- After changing the IP address of Elevator System you must restart the OTIS driver service.
- If you install the OTIS Elevator Integration on remote clients, the **Integration Setup** dialogue box appears and you may be prompted to select an Installation Option for the Redundancy sever. Ignore this message and click **Next** to continue with installation.

If you select the **Redundancy sever installation using supported third party redundancy** check box, provide the virtual server location, and then click **Next**; this selection is ignored and there is no functional impact.

- When you install the OTIS integration, if the Connection Strings Encrypted option is enabled in the Server Configuration Application, Crossfire services fail to start.
 1. In the Server Configuration Application, select the **Database** tab.
 2. Clear the Connection Strings Encrypted check box.
 3. Install the OTIS integration.

4. In the Server Configuration Application, select the **Database** tab.
5. Select the Connection Strings Encrypted check box.

Defects Fixed

The following table lists the defects that are fixed in this version of the software:

Table 3: General Fixes

Category	SPAR Number	SPAR Description
OTIS Driver	671123	DEC status is displayed as Offline after the clock synchronization of victor server system.

End of Release Notes

The trademarks, logos, and service marks displayed on this document are registered in the United States [or other countries]. Any misuse of the trademarks is strictly prohibited and Tyco Security Products will aggressively enforce its intellectual property rights to the fullest extent of the law, including pursuit of criminal prosecution wherever necessary. All trademarks not owned by Tyco Security Products are the property of their respective owners, and are used with permission or allowed under applicable laws.

Product offerings and specifications are subject to change without notice. Actual products may vary from photos. Not all products include all features. Availability varies by region; contact your sales representative.

© 2021 Johnson Controls. All right reserved. JOHNSON CONTROLS, TYCO, and AMERICAN DYNAMICS are trademarks of Johnson Controls.