

DAILY

WEEKLY

TROUBLESHOOTING

## PRINT EVERY DAY to maximize your printer performance.



### PRINT EVERY DAY

Print an image or color test every day to keep your ink flowing smoothly.



### LEAVE PRINTER POWERED ON

The printer will run minor maintenance when not in use.



### CLEAN PRINTER SURFACE

Wipe the outer surface of your printer with a damp cloth. Allow to air dry before use.



### CLEAN PRINTER ROLLERS

Power printer off. Wipe rollers (located inside the printer cover and printer bed) with a damp cloth. *Do not use excessive moisture and do not drip liquid inside the printer.* Allow to air dry before use.

*Always sanitize food contact surfaces per store/bakery procedures.*

### PRINT COLOR TESTS



From main menu, select **Maintenance**.



Select **Color Test**. Follow the on-screen instructions to complete the color test.

Color test looks like this:



Your printer is working correctly! You can use your printer immediately.

Color test looks like this:



Your print head may be clogged. Continue to complete a Print Head Cleaning.

### PRINT HEAD CLEANING



Select **Print Head Cleaning**. Follow the on-screen instructions to complete the print head cleaning. A color test will print upon completion.

Repeat the print head cleaning, up to 4 times, until the color test has no broken lines. If issue persists, please call PhotoCake Technical Support for **Deep Clean** instructions.

*Note: Maintenance can be performed on regular printer paper. Printing color tests or print head cleaning does not deduct media or image credits from your account.*