


Z14I Rugged Laptop Office Docking User's Manual



Package Contents

If any of following items is damaged, please contact your retailer.

Office Docking



Adapter




Power cord



NOTE

The pictures are for reference only, actual items may slightly differ.

Product Overview




No.	Item
1	Terminal
2	Alignment bracket
3	Lock/Unlock switch
4	Lock latch
5	LAN LED
6	Power LED
7	DC-in jack
8	LAN (Ethernet) port
9	2x USB3.0 ports
10	2x USB2.0 ports
11	DP (DisplayPort) port
12	HDMI port
13	GA port
14	COM (Serial) port
15	Audio out jack
16	Microphone input jack

LED Indicator Behavior

LAN LED	Indicates the wired network connection status: <ul style="list-style-type: none"> - Green: a link is established - Flashing Green: when there is activity on the port
Power LED	The LED light stays on when the AC power is plugged in.


Docking the Laptop PC

1. Align the Laptop PC by the alignment bracket and terminal contact and then place the Laptop PC onto the docking cradle. **Be sure to insert the handle side first as shown the illustration.**



Note: Always remove the stylus before placing the Laptop PC onto the docking cradle.


2. Slide the Lock/Unlock switch to the lock position to secure the Laptop PC to the docking cradle.




Note: The rear I/O door cannot be fully opened once the Laptop PC is fully secured to the docking cradle. If you need to access the COM port, it is recommended to use the COM port of the docking cradle.

Undocking the Laptop PC


1. Slide the Lock/Unlock switch to the unlock position to disengage the connection. Be sure the device is properly turned off.



2. Lift to remove the Laptop PC.



- When the Laptop PC is locked to the docking cradle:
 - All LAN, USB, COM, and HDMI ports are functioning properly on both sides, either on the Laptop PC or the docking cradle.
 - The DP and VGA ports of the Laptop PC will be disabled. You can only use these ports on the docking cradle.
 - The LAN ports of the standard model are independent, which means that all three LAN ports can work at the same time.



Federal Communications Commission Statement

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Warning: Operation of this equipment in a residential environment could cause radio interference.

IC Regulations

This device complies with Industry Canada's licence-exempt RSSs. Operation is subject to the following two conditions: (1) This device may not cause interference; and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.