

MODEL 420XL and 420

Pressure Vacuum Breakers – 1/2" and 3/4"



Item Number	Description	1/2"	3/4"
1	CANOPY SCREW	421-11	421-11
2	CANOPY	421-3	421-3
3	BONNET	421-20	421-20
4	O-RING	034N	034N
5	RELIEF VALVE ASSY	-	-
6	AIR INLET DISC	421A-34	421A-34
7	FLOAT	-	-
8	SPRING RETAINER	421A-80	421A-80
9	CHECK SPRING	421-33	421-33
10	POPPET	421-30	421-30
11	SEAL RING	421-12	421-12
12	SEAT	421-18	421-18
13	O-RING	126N	126N
14	SHUT-OFF VALVE	12-850TXL	34-850TXL
15	TEST COCK	18-860XL	18-860XL
16	FLOAT ASSEMBLY	421-340	421-340
17	SEAT ASSEMBLY	421-180	421-180

Repair Kit, Complete

RK12-420

Qty.	Part Number	Part Number
1	421-180	SEAT ASSEMBLY
1	421-340	FLOAT ASSEMBLY
1	421-20	BONNET
1	034N	O-RING

Repair Kit, Rubber


RK12-420R

Qty.	Part Number	Part Number
1	421-12	SEAT RING
1	421A-34	AIR INLET DISC
1	126N	O-RING
1	034N	O-RING

Repair Kit, Freeze

RK12-420FK

Qty.	Part Number	Description
1	421-20	BONNET
1	421-30	POPPET
1	421-340	FLOAT ASSEMBLY
1	034N	O-RING
1	421-12	SEAL RING



MODEL 420XL and 420

Pressure Vacuum Breakers – 1"



Item Number	Description	1"
1	CANOPY SCREW	7000-11B
2	CANOPY	423-3
3	BONNET	423-20
4	O-RING	039N
5	RELIEF VALVE ASSY	-
6	AIR INLET DISC	423A-34
7	FLOAT	-
8	SPRING RETAINER	423A-80
9	CHECK SPRING	423-33
10	POPPET	423-30
11	SEAL RING	423-12
12	SEAT	423-18
13	O-RING	133N
14	SHUT-OFF VALVE	1-850TXL
15	TEST COCK	18-860XL
16	FLOAT ASSEMBLY	423-340
17	SEAT ASSEMBLY	423-180

Repair Kit, Complete

RK1-420

Qty.	Part Number	Description
1	423-180	SEAT ASSEMBLY
1	423-340	FLOAT ASSEMBLY
1	423-20	BONNET
1	039N	O-RING

Repair Kit, Rubber

RK1-420R

Qty.	Part Number	Description
1	423-12	SEAT RING
1	423A-34	AIR INLET DISC
1	133N	O-RING
1	039N	O-RING

Repair Kit, Freeze

RK1-420FK

Qty.	Part Number	Description
1	423-12	SEAL RING
1	423-20	BONNET
1	423-30	POPPET
1	423-340	FLOAT ASSEMBLY
1	039N	O-RING

