


ABOUT YOUR PHONE

ADVANCED FEATURES



orbic[®]
magic
5G™



DISCOVER



USE



ENJOY



1. MAIN CAMERA / ULTRA-WIDE / MACRO / FLASH

2. SIM / MEMORY CARD TRAY

3. **BACK:** Return to previous screen, menu or option.

4. HEADSET JACK

5. FINGERPRINT SENSOR

6. FRONT CAMERA

7. VOLUME

8. **POWER / LOCK**

- Wake up or lock the screen with a quick press.
- Press and hold for additional options:
 - » Emergency
 - » Power off
 - » Restart

9. **HOME**

- Press to access the Home screen.
- Press and hold to open Google Assistant.

10. **RECENT APPS**

- Press to open the recently used applications.
- Split screen view: Tap the recently-used applications icon. Tap the icon located at the top of the app you want to open. Tap Split Screen icon. To open another app, tap it. The apps will appear on the top and bottom of the screen.

11. USB / CHARGING PORT

TABLE OF CONTENTS

1. YOUR DEVICE 1

- Serial number
- Phone number
- SIM number

2. ADVANCED FEATURES 5

Google Account 6

- Google Drive
- Google Backup
- Google Assistant

Accessibility 10

- Screen Readers
- Display
- Interaction Controls
- Audio & On-screen Text
- Experimental

Apps 14

- Use folders
- Play Store
- Google Apps

Calendar 16

Camera 17

- Take a picture
- Options
- Modes
- Settings
- Photos
- Edit pictures and videos
- Google Lens

Contacts 24

- Make a Contact widget

Data Usage 25

Digital Wellbeing and Parental Controls 26

- Screen time
- Ways to disconnect
- Reduce interruptions
- Parental controls

Multiple Users 28

Nearby Share 29

Office Features	30
Printing	
Split screen multi-tasking	
VPN	
Set up and manage a VPN	
Screenshots	32
Security	33
Screen Lock	
Fingerprint Recognition	
Face Unlock	
Google Play Protect	
Find My Device	
App Pinning	
Wi-Fi	37
Wi-Fi direct	
Health & Safety Information	39

1. Your Device

Learn how to access the unique numbers that identify your device. Keep these for future reference.

ESSENTIAL INFORMATION

Your phone has several unique identifier numbers that you may need for activation and other functions. You can access these numbers as follows:

Serial Number

- Home > Swipe up > Settings > About phone
Your Serial Number will appear under **IMEI**.

Phone Number

- Home > Swipe up > Settings > About phone
Your Phone Number will appear under **Phone number**.

SIM Number

- Settings > About phone > SIM status
Your SIM Number will appear under **ICCID**.

Your SIM number can also be found on the red Activation Card that came with your phone or, on the SIM card.

1. Locate the SIM/Memory Card tray on the left edge of the phone.
2. Press the pin tool provided into the hole until the tray pops out.
3. On the SIM card, you will see a number beginning with **89**. This is your SIM number.

For more information about your device:

Go to your service provider's website > Help >
Tutorials and User Manuals > select device

2. Advanced Features

Learn about the advanced features that can make your device more personal and more fun to use.

GOOGLE ACCOUNT

A Google (Gmail) account can be created during the setup process on your phone. You can also create an account at any time at google.com/gmail.

You will need to create a Google (Gmail) account to access Google cloud and other phone features. Once your account is created, you will have **15GB** of storage linked to your account.

Having a Google (Gmail) account will give you access to several features on your phone including:

- Google Drive cloud storage
- Google Assistant
- Google Play store
- Find My Device
- and more

Google Drive

► Settings > System > Backup > Back up to Google Drive

Google Drive is a file storage and synchronizing solution that lets you store files in the Google cloud. You can access information stored on Google Drive from any device or location, allowing you to collaborate on documents and to share files and photos. Using Google Drive also helps you save memory space on your device.

The files you store on Google Drive are private by default. You can change your privacy settings and share individual files and folders with specific people or choose to make them public so that anyone on the internet can view your shared files. You can change privacy settings at any time.

Google Backup

Once your Google account is configured, the following options will be available:

- **Sync settings:** Enable or disable syncing for contacts, calendar, and other apps.
- **Back up my data:** Select content from your device to back up to your Google account.
- **Restore:** Information in your Google accounts such as Contacts and Calendar can be restored. This may vary by Android version and device.

With a Google account you can:

- Activate device protection features.
- Download apps and other content from Google Play.
- Back up your apps to Google, and sync Google services like Calendar and Contacts with your other devices.

What content can be backed up and restored?

- Apps and app data
- Call history
- Contacts
- Calendar
- Device settings
- Photos and videos
- SMS texts
- Wi-Fi networks and passwords

Google Assistant

- Settings > Google > Settings for Google apps > Search, Assistant & Voice > Google Assistant > Voice Match

Your device has the Google Assistant feature built-in which you can access after you sign into your Google (Gmail) account. To launch the Google Assistant, press and hold the Home button, follow the prompts, and complete the set-up.

Once you complete the setup, you can access Google Assistant by simply saying “OK Google” or “Hey Google”. You can use this voice assistant to launch apps, make plans, ask a variety of questions, and carry out tasks with a quick voice command.

ACCESSIBILITY

► Home Screen > Swipe up > Settings > Accessibility

Accessibility services are special features and enhancements that make using the device easier. The services available in Accessibility allow you to customize the device to improve the experience of people with physical, sensory, or cognitive disabilities. You can turn Accessibility features ON/OFF as needed.

Many of the services available in Accessibility will make using the phone more comfortable for other users also.

Screen Readers

- **Select to Speak:** Tap a specific item on your screen to hear it read aloud.
- **TalkBack:** Set the device to read aloud what you touch, select, and activate on the screen so you can hear it without having to see it.
- **Text-to-speech output:** This is where you can set the language, speech rate and pitch of the Screen Reader so you can best understand its voice.

Display

- **Font size:** Change the font size for easy viewing.
- **Display size:** Set the items on the screen to a size that is easy for you to see. Some items may change position.
- **Dark theme:** Switch the color theme of the operating system or apps to black. Very useful in dim light or at night to diminish eye strain. Some apps may not support this feature.
- **Magnification:** Zoom in or out on the screen with finger actions or by setting a shortcut. You can temporarily magnify what is under your finger by touching and holding your finger anywhere on the screen. This feature does not work on the keyboard or navigation bar.
- **Color correction:** Adjust the color of the screen if you are color blind or have difficulty reading the display because of the screen color.
- **Color inversion:** Invert the colors on the screen to help you see the content better.
- **Large mouse pointer:** Magnify the mouse pointer so that you can locate it and see it easier.
- **Remove animations:** Remove certain screen effects if you are sensitive to motion.

Interaction Controls

- **Accessibility Menu:** This feature provides an accessibility icon at the bottom of the screen. Tap the icon to launch a large on-screen menu that gives you access to several features on your phone.
- **Switch Access:** Allows you to control your device using one or more switches instead of the touchscreen to select items, to scroll, enter text, and more. Set up switches and actions in Settings.
- **Autoclick:** When you are using a mouse, the cursor automatically clicks on an item after it stops moving for a certain amount of time.
- **Power button ends call:** Press the power key to end a call instead of having to touch the screen.
- **Auto-rotate screen:** Automatically change the screen orientation according to the physical position of the device.
- **Touch & hold delay:** Set the desired touch and hold delay to Short, Medium, or Long to customize the length of time that is considered one touch. Default setting is SHORT.
- **Time to take action:** Select how long a message that asks you to take an action stays visible on the screen so that you have time to read it. This may not be supported by all apps.
- **Vibration & haptic strength:** Turn ON/OFF the ring vibration, notification vibration and touch feedback options that alert you to incoming calls, messages, and other notifications.
- **System navigation:** To use an accessibility feature, simply swipe up from the bottom of the screen with 2 fingers. This feature will also allow you to navigate through your phone with swiping motions.

Audio & On-screen Text

- **Mono audio:** Turn ON/OFF to select mono or stereo sound for your device. Default mode is stereo.
- **Audio balance:** Adjust the left/right audio output balance using the sound balance slide bar.
- **Hearing aids:** Improve the sound quality of your phone's audio so it works better when you are using hearing aids.
- **Caption preferences:** Show closed captions and subtitles for videos for the hearing impaired. You can select language, text size and caption style.

Experimental

- **High contrast text:** This feature locks the text color as either black or white, depending on the original text color, making it easier to read text on your device. This feature may not be supported by all functions of your device.
- **Shortcut from lock screen:** When a shortcut is turned ON, press both volume keys for 3 seconds to start the accessibility feature you select.

APPS

- Home screen > Swipe up

The Apps home screen displays all preloaded and downloaded apps. Some apps have a quick-access shortcut that can be easily accessed with a simple touch and hold of the app icon. Additionally, some apps provide usage information when you hold down the app icon. You can uninstall, disable, or hide apps from view automatically. Preloaded apps cannot be uninstalled. Disabled apps will be turned off and hidden.

Use Folders

You can create and name folders to help you organize App shortcuts on the home screen. If you delete a folder, the app shortcuts will return to your Apps list.

To create a folder:

1. From the Home screen touch/hold an app shortcut and drag it on top of another app shortcut until a highlighted circle is displayed.
2. Release the app shortcut to create a folder.

Play Store

Play Store is the app store for Android devices and serves as a digital media store, offering games, books, movies, television programs and more. Applications are available through the Play Store either free of charge or at a cost. You can organize app widgets and folders for applications you download on the Home screen as necessary to fit your needs.

Google Apps

Google Apps are a suite of web-based messaging, collaboration and productivity applications that are provided by Google as a service, rather than as software that you need to download and install. These apps can be used for personal, and business needs to create documents, store images, set calendars and more. Your files are securely stored on Google servers protected by your account password and can be accessed from any device.

Several Google Apps are pre-installed on your device and can be found in the Google folder on your Home screen.

- Google search engine
- Gmail
- YouTube
- YT Music
- Google Maps
- Google Drive
- Play Movies & TV
- Calendar

CALENDAR

► Home screen > Swipe up > Calendar

This is where you can create and schedule a goal, a reminder, or an event and set them for today, tomorrow, or for a specific date. You can view the calendar as a schedule, 1-day, 3-day, week, or one-month grid. You can add notes, comments and edit any entry as needed.

For additional convenience, the schedule view puts images and maps directly on your calendar so you can access them easily. Events from your Gmail account such as reservations for flights, restaurants, or other similar events, are automatically added to your calendar. You can change these preferences in Settings.

You can share your calendar with family, friends, and co-workers, so you can be sure not to miss or overlap any appointments or events. When your schedule is saved from the device to your Google account, it is automatically synced with your Google calendar. Once you sync your other devices with your Google calendar, all events that have been saved will appear on those devices also.

CAMERA

► Home screen > Camera

Rear camera resolution: 48MP + 8UW + 2MP

Front camera resolution: 16MP

Video recording resolution: 1080p x 1920p

The pictures and high-quality videos you take with the phone's camera are, by default, saved to your phone's Photos. If you have an optional memory card (not included) installed, you can select to save pictures and videos to the memory card to help keep memory space on your device available.

This device can support up to a **2TB** microSD card. Some memory cards may not be fully compatible.

Take a picture

You can take a picture using any of the ways listed below.

- Tap the capture icon.
- Press the Volume up or down key: Great option when you are taking selfies.

Options

➤ Camera > Top of screen

When you are ready to take a picture or video, simply view the subject on the screen and tap the capture/record icon. The camera will automatically adjust focus and lighting. To adjust the zoom manually, tap on the screen where you want the main-focus area to be and adjust zoom levels to your preference using the slide bar that appears.

- **HDR (High Dynamic Range):** Automatically corrects the backlight to produce a brighter and richer picture.
- **Flash:** Set to ON, OFF or AUTO to produce the lighting effect you want.
- **Effects:** Select from a series of pre-installed filters that apply artistic lighting effects to the image.
- **Settings:** Select the settings that best suit your imaging needs.

Modes

➤ Camera > Mode at bottom of screen

You can select a camera mode that suits your imaging needs. Once you tap on the mode name at the bottom of the screen, you can allow the camera to determine the ideal settings, or you can manually adjust the settings so that you get the results you want.

- **Video:** You can zoom in/out or take a photo while you are recording video.
- **Wide:** Capture a wider image area when taking a front-facing picture.
- **Auto:** Select a subject and tap on the screen where you want the main-focus area to be. The camera will automatically adjust the lighting. You can adjust the zoom level on the slide bar that appears.
- **Pro:** This mode allows you to manually control advanced settings like exposure, focus, white balance, ISO, and zoom.
- **Portrait:** Create an artistic portrait photo, with the main subject in focus and a blurred background. You can edit the image by applying lighting or color effects to the background.
- **Night:** Allows you to get the best results for images you are taking in dark conditions.
- **Beauty:** In selfie mode, this effect airbrushes your face, smooths, and brightens your skin.
- **Pano:** Create a linear image by pressing the capture icon as you move the device in a horizontal or vertical direction.
- **Selfie:** Switch to the front camera to take selfies. You will be able to select the effect and adjust the settings to best suit your needs.

Settings

► Camera > Select mode > Settings

Pictures

- **GPS location:** Attach a GPS location tag to the picture. Default setting is OFF.
- **Face Detection:** Detects any faces on your screen and automatically adjusts the focus and lighting of the image for best results.
- **Shutter sound:** Enable or disable the sound the shutter makes when you take a picture. Default setting is ON.
- **Countdown Timer:** You can set the timer to take a picture in 2, 5, or 10-second delays.
- **Picture size:** Set the resolution for your pictures and videos. Default is 12MP.
- **Picture quality:** Select the image quality that best suits your needs. Default setting is High.
- **Exposure:** Select the light exposure value for your image. Default is 0.
- **White balance:** Select the white balance type for your image. Default is Auto.
- **Selfie Flash:** Turn the flash ON/OFF for all selfies. Default is OFF.
- **Restore defaults:** Reset all camera settings to their default modes.

Video

- **GPS location:** Attach a GPS location tag to the video. Default setting is OFF.
- **Face Detection:** Detects any faces on your screen and automatically adjusts the focus and lighting of the video for best results.
- **Shutter sound:** Enable or disable the sound the shutter makes when you begin/end a video recording. Default setting is ON.
- **Video quality:** Select the video quality that best suits your needs. Default setting is HD 1080p.
- **Video duration:** Select the length of time that video will continuously film. Default is 10 minutes.
- **Noise reduction:** Reduce the amount of background noise that will be captured in your video.
- **Video Encoder:** Select a compression setting to convert your video to a digital format so that it is compatible with most types of web players and mobile devices. Default setting is H264.
- **Audio Encoder:** Convert the video's audio signal to a compressed digital format to make it compatible with most types of web players and mobile devices. Default setting is AAC.
- **Video Rotation:** Select the rotation angle for your video.
- **Time lapse:** Select the number of images you want to capture per second/hour in your video. When you play it back, the images are compressed together, so that it appears as a much faster sequence than the actual filming time.
- **Restore defaults:** Reset all camera settings to their default modes.

Photos

► Home Screen > Photos

Launching the Photos folder displays all the available visual images stored on your device. Images that are backed-up to Google Photos, can be separated into different albums to help you find them easily. Additionally, you will be able to add an image to a contact, select it as your wallpaper, or create a slideshow directly from the Photos folder.

Edit Pictures and Videos

► Photos > Tap picture or video > Tap Edit icon at bottom of image

You can view and manage photos and videos saved on your device. Tap on the image or video and select from various editing options shown in the edit menu bar. You will be able to keep the original image and save your edited image as a copy. Some image or video formats may not be supported.

Editing option include:

- Crop and/or rotate image
- Adjust lighting
- Select filter
- Add markups

Google Lens

Google Lens is a tool that allows your camera to use image recognition to identify and explore many things you interact with. You will be able to get information about landmarks, plants, animals, products, QR codes, labels, business cards and other objects.

To use Google Lens, just select a picture from your Photos and select the Lens icon at the bottom of the image. Google Assistant identifies the image and gives you information that you can use to learn specifics about the image, to take an action from suggestions presented, or to find similar products.

Google Lens can also be used to scan and auto-translate text, and to get definitions in most languages. To use it for smart text selection, just point your camera at the text you need, and copy/paste it into a new screen.

CONTACTS

► Home Screen > Swipe up > Contacts

You can create, edit, import, manage contacts in your device and sync them with your other devices. Contacts can be backed-up to Google Drive if you have a Google (Gmail) account, or you can back them up manually to a memory card (not included) if you have one installed.

You can designate a contact as a favorite for easy access and you can also create a widget for those you use most frequently.

Make a Contact widget

To create a widget for a contact previously stored in your device, press and hold an empty spot on the home screen, tap Widgets, then press and hold the Direct dial widget. Drag it to your home screen, then select the contact you want to assign to that widget.

DATA USAGE

► Settings > Network & internet > Mobile network

Your smartphone Service Plan includes data. There are several options to monitor how your data is being used, and to set limits and restrictions to conserve it. If you choose to log in to Wi-Fi networks, it is important that you connect to known, secure networks and set up passwords as necessary.

The Mobile network menu will allow you to:

- Turn Data Saver On or Off
- Set unrestricted data access for 3 apps
- Set or remove limits to data usage
- Monitor mobile data usage for your apps
- Check Wi-Fi data usage

DIGITAL WELLBEING AND PARENTAL CONTROLS

► Settings > Digital wellbeing and parental controls

You can monitor and manage your digital habits by getting a daily view of your digital usage on the Dashboard. You can also set your device to supervise your children's digital life.

Your Digital Wellbeing tools

- **Daily timer:** Tap the time value in the daily chart to see how long each app has been opened and used that day.
- **Notifications:** Tap to see how many notifications have been received from each app that day.
- **Unlocks:** Tap to see how many times each app has been opened that day.

Ways to disconnect

- **Dashboard:** Set a daily limit for how long each app can be used on your device that day. When the time limit is reached, the app is paused for the rest of the day.
- **Bedtime mode:** Once enabled, the screen converts to greyscale and all notification sounds will be muted. This feature helps you disconnect from your device and avoid interruptions during a scheduled period of time.
- **Focus mode:** Configure a schedule to avoid receiving notifications and other distractions from your phone during that time. You can select apps that you want to exclude from the schedule.

Reduce interruptions

- **Manage notifications:** Turn notifications ON/OFF or set the visual/sound alerts you receive for each app.
- **Do not disturb:** Set a schedule to silence the sounds and vibration of your device for all contacts and notifications. You can create a list of exceptions that will continue to send notifications.

Parental controls

Supervise your children's digital life with Google's Family Link app. You can choose apps, set content filters, keep an eye on screen time, and set screen time limits for them.

MULTIPLE USERS

- Settings > System > Advanced > Multiple users

You can share this device with other people by adding users. Each user has their own profile and they can customize the phone with the apps, wallpaper, accessibility features and other settings that fit their needs.

Any user will be able to update apps and adjust settings like Wi-Fi that are used by everyone. Updates and settings for shared functions will be applied to all user profiles.

NEARBY SHARE

- Settings > Connected devices > Connection preferences > Nearby Share

This platform enables reliable and easy sharing of your pictures, files, links and other content across devices that are running Android 6 and up even if they are from other manufacturers. Once Bluetooth and Location is turned ON for both devices, content will be shared via the method that the two devices recognize as fastest: Bluetooth, or Wi-Fi which will allow Nearby Share to work even if you are offline.

For added protection, you can set your preferred visibility to be seen by All Contacts, Some Contacts, or Hidden so that you never receive files that you didn't ask for.

OFFICE FEATURES

Printing

- Settings > Connected devices > Connection preferences > Printing

Connect to compatible Bluetooth printers to print images and documents. To install additional print service drivers, simply tap Add service and install the print driver from the Play store.

Split screen multi-tasking

- Recent apps > Icon on first app > Split screen > Tap second app

The Split screen function is a convenient way to multitask by using two apps at the same time. You will be able to open the apps in a top and a bottom window for access to both. In addition, you will be able browse the web or send a text message with the split screen feature enabled. This feature may not work with all apps.

VPN

- Settings > Network & internet > Advanced > VPN

A virtual private network (VPN) is a network that is constructed using public wires, usually the Internet, to connect remote users or regional offices to a company's private, internal network.

Set Up and Manage a VPN

To connect to a VPN, you will need the connection information from your VPN administrator, and you must set a secured screen lock. Use the VPN settings menu to add, edit, or delete a VPN connection to your device.

SCREENSHOTS

When you capture a screenshot, a Screenshots album will automatically be created in Photos where all screenshots will be saved.

To capture a screenshot, press and hold the Power button and the Volume DOWN key at the same time.

SECURITY

Screen Lock

► Settings > Security > Screen lock

It is recommended that you secure your device using a Screen lock. This added level of security helps prevent someone from accessing your device including your personal data, apps, and email accounts. There are a variety of screen lock types with different levels of security for your selection including a swipe, a pattern, a numeric PIN, a password, fingerprint, or face unlock.

In addition, you can set a Smart Lock to unlock your device automatically and keep it unlocked when you are in a trusted location or when trusted devices are detected.

Fingerprint recognition

► Settings > Security > Fingerprint

The fingerprint sensor on the back of the device can be used by the device to identify you. Before you use this function, you will need to register your fingerprint on the device. You will then be able to unlock the screen, view locked content, confirm a purchase or sign into an app that supports fingerprint ID. You will be able to register multiple fingerprints and delete them at any time.

Fingerprint data will be saved only to your phone and will not be backed-up.

Face Unlock

► Settings > Security > Face unlock

Face recognition is an added security option that will let you unlock the screen by simply raising your phone and looking at the screen. Before you enter your face scan, you will need to set a secure screen lock type and allow Face Unlock to take pictures and record video in order to complete the set-up process. Once you have completed the set-up, your phone will also show notifications on your lock screen when you are looking at it.

Face scans can be deleted or updated as necessary. The data used to recognize your face is kept private on your phone.

Google Play Protect

► Settings > Security > Google Play Protect

Google Play Protect runs a safety check on apps from the Play Store before you download them. You can configure Google Play Protect to regularly check installed apps and your device for security risks and threats. App updates are checked automatically, and you will receive a notification if any security threats are detected. Play Protect is ON by default.

Find My Device

► Settings > Security > Find My Device

Find My Device will help you locate your device and protect your data. You must have a Google (Gmail) account and turn Google location service ON in order to use this feature. If your phone is lost, you will be able to log in to your Gmail account and remotely perform various functions to help you keep your information secure and locate your phone.

Use the Find My Device feature to:

- Make your phone ring
- Send you the device's last location
- Lock/Unlock your phone
- Erase data
- Set a screen message
- Set guardians

App Pinning

► Settings > Security > Advanced > App pinning

Screen pinning allows you to pin an app to the screen and block usage of all other functions of the phone including calling, texting and other frequently used apps. This feature is very helpful if you want to lend your phone to another user, such as a child, so that they can only use the pinned app. For example, if you pin YouTube, it is the only function they will be able to use. However, the pinned app may open other apps and personal data may then be accessible. If you want to share your device with someone, it is best to set them up as a guest user.

When you want to return to regular usage mode, hold the Back and Recent Apps buttons at the same time for a few seconds. To unpin an app, you may need the authorized user's security PIN.

Wi-Fi

► Settings > Network & internet > Wi-Fi ON/OFF

Wi-Fi is a term used for a wireless network technology that provides wireless high-speed internet and network connections without using the data allocated to your service plan. When Wi-Fi is turned ON, your device automatically scans for available networks and displays them. You may be required to enter a password to connect.

When you select a public/unprotected network, you are automatically connected to that network. Connecting to a public Wi-Fi network can leave your personal data vulnerable, so it is important that you connect to known, secure networks and set up passwords as necessary.

Wi-Fi Direct

► Settings > Wi-Fi > Wi-Fi preferences > Advanced > Wi-Fi Direct

This feature uses Wi-Fi capability to share data between two or more Android devices even if they are from different manufacturers. You will not need to be connected to a Wi-Fi network.



HEALTH AND SAFETY INFORMATION

FCC ID#	2ABGH-R678EL
SAR Head	0.669 W/Kg
SAR Body	0.678 W/Kg
HAC rating	M4/T3

Before You Start

WARNING! Cancer and Reproductive Harm
www.P65Warnings.ca.gov

Important Safety Information

Keep the phone ("Product") away from dust, water, damp areas, precipitation and humidity. Dust, water, liquids, precipitation and humidity may cause overheating, electrical leakage, and/or Product failure. The Product, battery, charger and AC adapter are not waterproof. Keep them away from liquid, fuels and chemicals. If the Product gets wet, do not place the Product in an oven, microwave or dryer, as this will damage the Product and could cause a fire or explosion.

Only use the battery and charger approved by the manufacturer. Using other brands may cause battery leakage, overheating, explosion or even fire. Do not use the Product where it might cause danger. Do NOT text and drive.

Battery Use

Handle and store batteries properly to avoid injury or damage. Most battery issues arise from improper handling and, particularly, from the continued use of damaged batteries.

- Do not disassemble or open crush, bend or deform, puncture or shred
- Do not modify or remanufacture, attempt to insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard.
- Only use the battery for the system for which it is specified.
- Only use the battery with a charging system that has been qualified with the system per CTIA Certification Requirements for Battery System Compliance to IEEE 1725. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.
- Do not short circuit a battery or allow metallic conductive objects to contact battery terminals.
- Replace the battery only with another battery that has been qualified with the system per this standard, IEEE-Std-1725. Use of an unqualified battery may present a risk of fire, explosion, leakage or other hazard.
- Only authorized service providers shall replace battery. (If the battery is non-user replaceable).
- Promptly dispose of used batteries in accordance with local regulations.
- Battery usage by children should be supervised.
- Avoid dropping the phone or battery. If the phone or battery is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.
- Improper battery use may result in a fire, explosion or other hazard.
- The maximum operating temperature is 55°C.

Note: The battery shall only be serviced by the manufacturer.

CAUTION: Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries in accordance with local regulations.

Cleaning and Maintenance

The Product, the battery and the charger are not waterproof. Do not use them in places with high humidity like a bathroom and also avoid spilling any liquids on the Product, battery or charger. Use a soft cloth to clean the Product, the battery and the charger. Do not use alcohol, diluted liquid or benzene to clean the Product.

Disposal of Product and Batteries

Follow local regulations regarding disposal of mobile devices and batteries. In some areas, the disposal of these items in household or business trash may be prohibited. Please follow your local regulations and recycle Product if required. Batteries must be recycled or disposed of properly.

Certification Information (RoHS)

We at Orbic take our social responsibility seriously and are committed to the cause of serving our environment. It is in keeping with these commitments that we are proud to state that Orbic phones are RoHS compliant.

Hearing Aid Compatibility Information

This device supports hearing aid compatibility refer to the gift box label for the specific rating. This phone has been tested and rated for use with hearing aids for some of the wireless technologies it uses. However, there may be some newer technologies that have not been tested yet for use with hearing aids. It is important to try the different features of this phone thoroughly and in different locations, using your hearing aid or cochlear implant, to determine if you hear any interfering noise. Ask your service provider or the manufacturer of this phone for information on hearing aid compatibility. When some mobile phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise and phones also vary in the amount of interference they generate.

FCC SAR Warning

This model phone meets the government's requirements for exposure to radio waves.

This phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government: The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg. Tests for SAR are conducted using standard operating positions accepted by the FCC with the phone transmitting at its highest certified power level in all tested frequency bands. The SAR guideline includes a considerable safety margin designed to assure the safety of all persons regardless of age and health.

The FCC has granted an Equipment Authorization for this model phone with all reported SAR levels evaluated as in compliance with the FCC RF exposure guidelines. SAR information on this model phone is on file with the FCC and can be found under the Display Grant section of <http://www.fcc.gov/et/fccid> after searching on: FCC ID: 2ABGH-R678EL or at <http://www.orbic.us/>

For body worn operation, this phone has been tested and meets the FCC RF exposure guidelines for use with an accessory that contains no metal and positions the handset a minimum of 10 mm from the body. Use of other enhancements may not ensure compliance with FCC RF exposure guidelines. If you do not use a body-worn accessory and are not holding the phone at the ear, position the handset a minimum of 10 mm from your body when the phone is switched on.

Hearing Aid Compatibility HAC For Wireless Telecommunications Devices

THIS PHONE HAS A HAC RATING OF M4/T3 WHAT IS HEARING AID COMPATIBILITY?

The Federal Communications Commission has implemented rules and a rating system designed to enable people who wear hearing aids to more effectively use these wireless telecommunications devices. The standard for compatibility of digital wireless phones with hearing aids is set forth in American National Standard Institute (ANSI) standard C63.19. There are two sets of ANSI standards with ratings from one to four (four being the best rating): an "M" rating for reduced interference making it easier to hear conversations on the phone when using the hearing aid microphone, and a "T" rating that enables the phone to be used with hearing aids operating in the tele-coil mode thus reducing unwanted background noise.

HOW WILL I KNOW WHICH WIRELESS PHONES ARE HEARING AID COMPATIBLE?

The Hearing Aid Compatibility rating is displayed on the wireless phone box. A phone is considered Hearing Aid Compatible for acoustic coupling (microphone mode) if it has an "M3" or "M4" rating. A digital wireless phone is considered Hearing Aid Compatible for inductive coupling (tele-coil mode) if it has a "T3" or "T4" rating.

HOW WILL I KNOW IF MY HEARING AID WILL WORK WITH A PARTICULAR DIGITAL WIRELESS PHONE?
You'll want to try a number of wireless phones so that you can decide which works the best with your hearing aids. You may also want to talk with your hearing aid professional about the extent to which your hearing aids are immune to interference, if they have wireless phone shielding, and whether your hearing aid has a HAC ratio.

FCC Statement

This Product complies with Part 15 of the FCC Rules. Operation is subject to the following three conditions:
(1) This Product may not cause harmful interference, and
(2) This Product must accept any interference received, including interference that may cause undesired operation.
(3) Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE 1:

This Product has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This Product generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this Product does cause harmful interference to radio or television reception, which can be determined by turning the Product off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- To view device FCC ID on a device look at the label in the battery compartment, for devices without a battery door there is a E-label information available by selecting: Settings > About phone

NOTE 2:

Orbic or the manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to the Product. Such modifications could void the user's authority to operate the equipment.

Data transmission is always initiated by software, which is then passed down through the MAC, through the digital and analog baseband, and finally to the RF chip. Several special packets are initiated by the MAC. These are the only ways the digital baseband portion will turn on the RF transmitter, which it then turns off at the end of the packet. Therefore, the transmitter will be on only while one of the aforementioned packets is being transmitted. In other words, this device automatically discontinues transmission in case of either absence of information to transmit or operational failure.

ORBIC LIMITED WARRANTY WHO THIS WARRANTY COVERS

This 12 month limited warranty extends only to the original purchaser of this product within the United States. This warranty is not transferable. This warranty is conditioned upon the proper use of the Product.

WHAT THIS WARRANTY COVERS

Orbic offers you a limited warranty that extends for the first twelve (12) month period to the original purchaser from the date of original purchase with proof of purchase. Without valid proof of purchase, Orbic offers a limited warranty extending fifteen (15) months from date of manufacture, which is coded on the product label ("Warranty Period").

Should the Product, inbox accessories or any part during normal consumer usage and conditions be proven defective in material or workmanship that results in Product failure, such defect(s) will be repaired or replaced (with new or rebuilt parts) at Orbic's discretion, without charge for parts or labor directly related to the defect.

WHAT THIS WARRANTY DOES NOT COVER

1. Warranty claims outside of the Product warranty Period.
2. Damage or defects caused by using the Product other than in the normal course.
3. Defects or damages resulting from accidental, misuse, abnormal use, abnormal conditions, improper storage, unauthorized modifications, unauthorized repair, improper installation, or other acts which are not the fault of Orbic.
4. Defects or damage resulting from excessive force or use of a metallic object when pressing the touch screen.
5. Product with altered, defaced or removed serial number.
6. Damage resulting from use of accessories not approved by Orbic.
7. Damage from exposure to moisture, humidity, excessive temperature or extreme environment.
8. Liquid damage due to not properly sealed/locked accessories, ports and or battery latches of water resistance devices.
9. All surfaces and externally exposed parts that are scratched or damaged due to normal customer use.
10. All software, including operating system software, third-party software, applications, and all other software of any kind.
11. Damage caused by ordinary wear and tear of the Product.
12. Customer abuse or other physical abuse or mistreatment of Product as evidenced by:
 - a. Missing required faceplate;
 - b. Damaged LCD or Lens (e.g., the product is either broken, cracked, smashed, bleeding, etc.;
 - c. IMEI is unreadable electronically or due to missing or altered serial number, IMEI and/or reliance date label so as to affect readability;
 - d. Missing keys on keypad beyond normal wear and tear;
 - e. Unapproved Product modification;
 - f. Visible Product surface physical damage resulting in product being smashed, chewed, gouged, burned or melted;
 - g. Liquid damage as evidenced by submission in liquid or any other evidence of liquid ingress, including corrosion of any of the connections and noticeable excessive residue.

WHAT ARE THE LIMITS OF ORBIC'S LIABILITY

THIS LIMITED WARRANTY SETS OUT THE FULL EXTENT OF ORBIC'S RESPONSIBILITIES AND THE EXCLUSIVE REMEDY REGARDING THE PRODUCT. ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL ORBIC BE LIABLE FOR DAMAGES IN EXCESS OF THE PURCHASE PRICE OF THE PRODUCT OR FOR, WITHOUT LIMITATION, COMMERCIAL LOSS OF ANY SORT; LOSS OF USE, TIME, DATA, REPUTATION, OPPORTUNITY, GOODWILL, PROFITS, OR SAVINGS; INCONVENIENCE; INCIDENTAL, SPECIAL, CONSEQUENTIAL, OR PUNITIVE DAMAGES ARISING FROM THE USE OR INABILITY TO USE THE PRODUCT. SOME STATES AND JURISDICTIONS DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, OR THE DISCLAIMER OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS AND DISCLAIMERS MAY NOT APPLY TO YOU.

ORBIC MAKES NO WARRANTIES OR REPRESENTATIONS, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, AS TO THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE OR SUITABILITY OF ANY THIRD-PARTY SOFTWARE OR EQUIPMENT USED IN CONJUNCTION WITH THE PRODUCT, OR THE ABILITY TO INTEGRATE ANY SUCH SOFTWARE OR EQUIPMENT WITH THE PRODUCT DISTRIBUTED BY ORBIC OR OTHERWISE. RESPONSIBILITY FOR THE QUALITY, CAPABILITIES, OPERATIONS, PERFORMANCE AND

SUITABILITY OF ANY SUCH THIRD-PARTY SOFTWARE OR EQUIPMENT RESTS SOLELY WITH THE USER AND THE DIRECT VENDOR, OWNER OR SUPPLIER OF SUCH THIRDPARTY SOFTWARE OR EQUIPMENT.

Nothing in the Product instructions or information shall be construed to create an express warranty of any kind with respect to the Product. No agent, employee, dealer, representative or reseller is authorized to modify or extend this Limited Warranty or to make binding representations or claims, whether in advertising, presentations or otherwise, on behalf of Orbic regarding the Product or this Limited Warranty.

This Limited Warranty gives you specific legal rights and you may also have other rights that vary from state to state.

WHAT ARE THE PROCEDURES FOR RESOLVING DISPUTES?

ALL DISPUTES WITH ORBIC ARISING IN ANY WAY FROM THIS LIMITED WARRANTY OR THE SALE, CONDITION OR PERFORMANCE OF THE PRODUCT SHALL BE RESOLVED EXCLUSIVELY THROUGH FINAL AND BINDING ARBITRATION, AND NOT BY A COURT OR JURY. Any such dispute shall not be combined or consolidated with a dispute involving any other person's or entity's products or claim and, specifically, without limitation of the foregoing, shall not under any circumstances proceed as part of a class action. The arbitration shall be conducted before a single arbitrator, whose award may not exceed, in form or amount, the relief allowed by applicable law. The arbitration shall be conducted according to the American Arbitration Association (AAA) Commercial Arbitration Rules applicable to consumer disputes. This arbitration provision is entered pursuant to the Federal Arbitration Act. The laws of the State of New York, without reference to its choice of laws principles, shall govern the interpretation of the Limited Warranty and all disputes that are subject to this arbitration provision. The arbitrator shall decide all issues of interpretation and application of this arbitration provision and the Limited Warranty. This arbitration provision also applies to claims against Orbic's employees, representatives and affiliates if any such claim arises from the Product's sale, condition or performance.

HOW TO GET WARRANTY SERVICE

To obtain warranty service, please call the following telephone number from anywhere in the continental United States: 1-877-872-4555