

<b><u>Jayco Silverline Outback Service Sheet</u></b>		
<b>Vehicle Reg.</b>	<b>Estimated Kilometers.</b>	
<b><u>Item to Check</u></b>	<b><u>Result</u></b>	<b><u>Date</u></b>
<b><u>Airconditioner</u></b>		
Clean filter		
Check operation		
<b><u>Stove and Cooktop.</u></b>		
Check the oven and cook tops all work.		
Check the gas safety shut works when the lid is closed		
<b><u>Gas System</u></b>		
Check gas bottle cradle, bottles and regulators for security and damage.		
Check that the gas hoses are not leaking and are not perished		
Check condition of gas pipe lines.		
Test all shut off valves for operation.		
Refill gas bottles if required		
Check "O" rings on bottle fittings for servicability.		
<b><u>Diesel Heater</u></b>		
Check exhaust for restrictions, condition and security.		
Check inlet filter, inlet ducting for damage and security		
Diesel Heater ducting systems for damage and security		
Heater diesel tank, lines and filter		
Check the diesel heater unit is working correctly		
<b><u>Electric fans</u></b>		
Bathroom & bedroom Fan security, damage and operation		
<b><u>Refridgerator</u></b>		
Refridgerator doors for fit, damage and security		
Check condensate water drain for condition, security and restrictions.		
Check the fridge for operation		
<b><u>Toilet</u></b>		
Toilet chemicals are adequate		
Check Thetford cassette toilet for condition, etc.		
Check that the toilet flush mechanism works OK		
<b><u>Van Exterior</u></b>		
Check awning brackets, beams and fabric for condition and security. Check operation.		
Lubricate all locks & padlocks,		
Check the door and window seals for condition.		
Grab handles security and damage		
Hinges operation wear and damage		
Lubricate door hinges		
Full inspection of body components.		
Reflectors damage and cleanliness.		
<b><u>Van Interior</u></b>		
Floor delamination		
Damp check, check for water leaks.		

Internal and external vents for damage security and cleanliness.		
Inspect and lubricate cupboard catches		
Windows and fittings		
Check and lubricate windows if required		
Window winders and door locks.		
Check that the blinds all work		
Furniture operation and damage		
Bed frame for damage, hinges and struts for operation		
<b><u>Roof Top.</u></b>		
TV antenna for operation, wear, security and damage.		
TV antenna mechanism Lubricate.		
Check fibreglass roof		
Fridge vent on roof for cleanliness.		
Roof vents for operation, security and damage.		
Solarpanels for condition and security.		
Solarpanels for cleanliness.		
Airconditioner Damage and security.		
<b><u>Brakes</u></b>		
Grease ratchet on handbrake		
Hand brake operation		
Handbrake cable adjustment and effectiveness checked.		
Brake rods and linkages and cable		
Inspect or Change Brake Linings		
Check electric brake cables.		
Inspect or change Brake Magnets		
Adjust the brakes as necessary, not forgetting the handbrake mechanism		
<b><u>Chasis and associated Components.</u></b>		
Chassis rails, cross-members and A-frames checked for damage/fatigue.		
Check underside of caravan		
Lubricate moving parts on hitch assembly.		
Check safety chains & "D" shackles.		
Coupling bolts inspected and lubricated.		
Check operation of hitch coupling, and adjust if required.		
Coupling head for condition and security		
Inspect and check Hitch pin for servicability, and lub.		
Inspect tow vehicle Tow Bar assembly for condition & Security.		
Jockey Stand condition, lubrication and operation.		
Clamp condition, security and lubricated for ease of operation.		
Inspect and lubricate corner steadies		
Corner steadies for damage, security and wear.		
<b><u>Electrical.</u></b>		
Breakaway cable condition and security.		
Van trailer plug and wiring connections inspected for damage and security.		
Check that all external lights work correctly		

Check that all lights work inside the caravan		
Check 12V and USB sockets (where fitted)		
Charger/charging rate		
Check power is coming from tow vehicle.		
Check house batteries Security and condition.		
Check that the battery is still holding a charge		
Check 12V pump		
Mains 240v system all plugs and sockets.		
Check condition of both 240v 15A ext. leads		
<b><u>Safety</u></b>		
Fire extinguisher, shake, and note pressure.		
Fire alarms test and note battery date.		
Carbon monoxide alarm test and note battery date.		
First aid kit. Contents.		
<b><u>Suspension Assembly</u></b>		
Check suspension mounts, brackets and attachment bolts for wear, damage and security.		
Shock absorbers for operation, condition, damage and security.		
Grease 4x nipples on suspension wishbones.		
Check wishbone bushes for wear		
<b><u>Wheel Assemblies</u></b>		
Check wheel rims for damage, cracks and condition.		
Examine the tyres ensuring that they have not perished and are legal		
Tyres inspected for wear, cracking and imbedded objects.		
Check tyre pressures, incl. spare wheel		
<b><u>Water System General</u></b>		
Replace drinking water filter		
Check or clean mains water filter		
Check the water all the taps and showers work		
Water pump for operation, filter for leaks and cleanliness		
Water system for security, damage and leaks.		
Water Tank mountings and hoses inspected for integrity and protection.		
<b><u>Water Heater</u></b>		
Inspect and or replace the water heater anode 27mm or 1 1/16 socket required.		
Flush out the tank.		
Test pressure relief valve for operation.		
Water heater 240v operation		
Check the water heater is working properly on gas		
<b><u>Wheel Bearings</u></b>		
Remove the wheels and brake drums.		
Hub Bearings and oil seals, inspect, replace if required.		
Hubs inspected for wear and damage.		
Wheel nuts inspected, tightened, and threads relubricated.		