



RESEARCH PRODUCTS, INC.

OF ALABAMA

POST OFFICE BOX 705 • THEODORE, ALABAMA 36590

(251) 653-0031

## ALUMA BRITE METAL CLEANER

DIRECTIONS: ALUMA BRITE IS DESIGNED TO CLEAN AND DEOXIDIZE STAINLESS STEEL AND ALUMINUM. RESEARCH PRODUCTS RECOMMENDS USING KLEEN SOL CONCENTRATE PRIOR TO USING ALUMA BRITE TO REMOVE ALL GREASE, OIL, DIRT, AND GRIME. IN WARM WEATHER AND ON WARM SURFACES DILUTE 1 TO 9 WITH WATER OR AS NEEDED. APPLY TO SURFACE AND ALLOW AMPLE TIME FOR CHEMICAL REACTION TO TAKE PLACE. WHEN FINISHED RINSE OR WIPE ANY EXCESS MATERIAL, AND REPEAT IF NECESSARY.

### TYPICAL PROPERTIES

SPECIFIC GRAVITY .....	>1
APPEARANCE .....	CLOUDY LIQUID
BOILING POINT .....	212 DEGREES F.
FLASH POINT .....	NONE DEGREES F.
WATER SOLUBILITY .....	COMPLETE

### SAFETY DATA:

USE CHEMICAL RESISTANT SAFETY GLASSES OR FACE SHIELD WHEN USING THIS PRODUCT. USE PROTECTIVE RUBBER GLOVES IF PROLONGED EXPOSURE IS EXPECTED.

### TRANSPORTATION:

DOT SHIPPING NAME UN1760 CORROSIVE LIQUID NOS, (SULFURIC ACID), 8, PGIII

DOT HAZARD CLASS CORROSIVE

**CONSULT MATERIAL SAFETY DATA SHEET FOR FURTHER INFORMATION.**