

HOW TO REMOVE TRI-SURE® METAL TAB-SEAL® CAPS



To remove the metal Tab-Seal cap, use the Tri-Sure universal plug wrench. Place the pin of the plug wrench in the hole of one of the ears and pull the tool gently backwards. **Rock the tool from side to side, so that the beginning of the two score lines open up.** Now pull the tool backwards and use the leverage of the tool to fully break away the centre strip of the Tab-Seal cap.



To place the pin of the tool in the hole in the ear, the ear may have to be raised above the surface of the drum. Use the flat side, provided in the handle of the plug wrench to do this.



Attention: When removing metal or plastic Tab-Seal Caps always wear protective gloves!