



[www.scott-sports.com](http://www.scott-sports.com)

All rights reserved © 2014 SCOTT Sports SA  
SCOTT Sports SA | 17 Route du Crochet | 1762 Givisiez | Switzerland

Distribution: SSG (Europe) Distribution Center SA  
P.E.D Zone C1, Rue Du Kiell 60 | 6790 Aubange | Belgium

V4.3/19012015

# SCOTT WALKER

**BIKE OWNER'S MANUAL 2015**





[www.scott-sports.com](http://www.scott-sports.com)

Congratulations on the purchase of your new SCOTT Walker!

We are confident that the Walker will exceed your expectations for value, performance and ride quality.

**We strongly recommend you take the time to read this manual and familiarize yourself with this new toy.**

**Please also take time to ensure that your child understands the safety information contained in this manual.**

## CONTENTS

---

|                                |    |
|--------------------------------|----|
| General Introduction . . . . . | 04 |
| Safety . . . . .               | 04 |
| Before Riding . . . . .        | 05 |
| Before Every Ride . . . . .    | 05 |
| Maintenance . . . . .          | 06 |
| Care Instructions . . . . .    | 07 |
| Spare Parts . . . . .          | 07 |
| Warranty . . . . .             | 08 |

## GENERAL INTRODUCTION

Please ensure your SCOTT Walker is completely assembled by an authorized SCOTT dealer.

This is very important for optimum performance and safety.

This SCOTT Walker meets the standards of European Standard EN 71.

## SAFETY

**MAKE SURE TO WEAR  
SAFETY EQUIPMENT!  
DO NOT USE IN PUBLIC TRAFFIC!**

The **minimum age** for a child to use this Walker is **1 year old**.

The **maximum load** for a SCOTT Walker is **25kg/55lbs**.

Your child **must be supervised at all times** while riding the SCOTT Walker.

Your child must be instructed on how to use the SCOTT Walker in the right way and be made aware of any possible dangers.

This SCOTT Walker should be used with caution since skills are required to avoid falls or collisions causing injury to the user or third parties.

This SCOTT Walker shall only be used in a playground or similar safe area.

Do not use the SCOTT Walker in traffic, public roads, near stairs, steep descents or areas with open water (pools, ponds, etc).

Please make sure that your child wears clothing that is highly visible (bright colors, reflective details or fabrics, etc) and wears shoes that protect the foot and toes.

Gloves and knee/elbow protectors will also help to avoid bruises or injuries.

The best way to avoid head injuries is to wear a helmet that fits.

The helmet should meet safety standard EN1078 and should have a CE label or should match or exceed the national standards of your country. Choosing bright colors will help to improve visibility and safety. Wearing such a helmet should be a matter of course for all cyclists or children using bikes or Walkers.

In addition, the best way to instruct a child is to lead by example. So make sure you follow basic safety rules and have fun!

## BEFORE RIDING

Ensure the seat height is set so that when your child is sitting on the saddle, they can reach the ground with both feet.

The seat height can be adjusted using a 5mm allen key and by following these steps:

1. Loosen the seat post clamp bolt counterclockwise
2. Adjust the seat to the required height according to the need (upper or lower)
3. Align the saddle
4. Tighten the clamp bolt clockwise with a maximum torque of 5Nm/44 in/lbs

**Please always respect the minimum insert depth shown on the seatpost and do not pull out any further as this can loosen the seat post and cause injuries.**

Ensure that your child can reach the handlebar easily.

The handlebar/stem height should be adjusted so that when your child is sitting on the Walker, they can reach the handlebar easily.

The handlebar/stem height can be adjusted using a 13mm wrench key and by following these steps:

1. Loosen the stem bolt counterclockwise
2. Adjust the handlebar/stem to the required height
3. Align the handlebar/stem
4. Tighten the stem bolt clockwise with a maximum torque of 10Nm/88 in/lbs

**Please always respect the minimum insert depth shown on the stem and do not pull out any further as this can loosen the stem and cause injuries.**

## BEFORE EVERY RIDE

Traffic laws demand that one checks all functions that concern safety.

Therefore, before every ride, check the air pressure of the tires (shown on the sidewall of the tire) and ensure the nuts of the wheels are tightened properly.

Also make sure that the handlebar/stem and the seatpost/saddle are properly bolted.

## MAINTENANCE

In addition to the checks listed in the Safety section, please check your Walker regularly according to the following maintenance check list.

If you are ever in doubt, please contact your local SCOTT dealer to avoid potential damage or injury, and ensure your Walker continues to be safe and fun to ride.

### Maintenance Checklist:

| PART                 | DESCRIPTION  | OK |
|----------------------|--|----|
| General visual check | All parts without visible damage. Replace parts if necessary.<br>All screws, nuts and bolts tightened according to the recommended tightening torques.   |    |
| Saddle/seatpost      | Check for minimum insertion line (min.55mm!)<br>Saddle tightened on seatpost<br>Seatpost tightened in frame  |    |
| Handlebar/stem       | The play of the headset. If necessary re-adjust it<br>Check for minimum insertion (min. 65mm!)<br>Stem tightened on fork steerer<br>Bar tightened on stem<br>Handlebar grips are fixed to the handlebar<br>Easy to reach |    |
| Tires                | Profile ok<br>Air pressure on the tires according to the recommendation of the producer (shown on the sidewall of the tire)  |    |
| Wheels               | Spoke tension ok and equalized<br>Axle nuts/quick release tightened  |    |
| Reflectors           | Tight fixed and adjusted<br>Clean and without cracks   |    |

### Tightening Torques for SCOTT Walkers:

| PART               | MOUNTING BOLTS | MAX. TORQUE |
|--------------------|----------------|-------------|
| Stem               | M5             | 5.6-7.8 Nm  |
|                    | M6             | 9.8-13.7 Nm |
| Seatpost-seatclamp | M4             | 2.8-3.9 Nm  |
|                    | M5             | 5.6-7.8 Nm  |
|                    | M6             | 9.8-13.7 Nm |

## CARE INSTRUCTIONS

We recommend periodical care in order to keep your Walker functioning well and in good condition.

Doing so maintains the value of the Walker and helps to prevent corrosion or other damages.

- Clean using a soft brush, water and soft towel. Do not use a high pressure cleaner, otherwise bearings, colors or decals may become damaged
- Do not use aggressive cleaning additives
- Repair any damages as soon as possible
- Grease or oil all metal parts especially during winter use

Please use biodegradable bicycle cleaners and degreasers which are available from your local SCOTT dealer.

## SPARE PARTS

When buying spare parts we strongly recommend visiting your local SCOTT dealer as they will be best equipped with the knowledge, advice and specific parts that are correct for your Walker.

By doing so you can avoid using wrong or incorrectly installed parts that could damage your Walker or cause personal injuries.

Please only use original spare parts as only these can guarantee optimum function and safety while riding.

Never use adapter solutions on parts such as wheels, seat/seatpost, stem/handlebar!

## WARRANTY

### What is Covered?

This warranty covers defects in materials and workmanship at the time of transfer of risks in frames, swingarms and forks (provided it is a fork of SCOTT) on SCOTT branded bikes sold completely assembled by SCOTT or an authorized SCOTT dealer ("Product").

### How Long Does Coverage Last?

This voluntary manufacturer's warranty is limited to five years for frames and swingarms, respectively two years for forks, from the date of purchase of the Product and is limited to the first purchaser of the Product. Transfer of the Product from the first purchaser to another person terminates this limited warranty.

The limited warranty of five years for the frames and swingarms shall only be granted in case once a year a maintenance service has been effected according to maintenance requirements as set forth in the manual. The effected annual maintenance service shall be confirmed by stamp and signature. In case such an annual maintenance service has not been effected the warranty of five years for the frame shall be reduced to three years. Costs for maintenance and service have to be borne by the owner of the Product. On Gambler, Voltage Fr and Volt-X the warranty period is limited to two years.

Repaired or replaced Products are covered for the remainder of the original warranty period and subject to the conditions outlined in the original warranty, to the extent permitted by law.

Hereby SCOTT grants a worldwide voluntarily manufacturer's warranty. To the extent permitted by law and unless a shorter duration is stipulated by law, any warranties implied by law are limited in duration to maximum five, respectively two years, from the date of purchase of the Product and are limited to the first purchaser of the Product.

### What Will SCOTT Do?

SCOTT will replace by similar kind and quality or repair any defective Product, or will refund your purchase price (as evidenced by your tendered receipt of purchase of the Product), at SCOTT's option. You must pay charges in connection with replacement of any non-defective parts. In such a case, you will be alerted to the advisability of replacing non-defective parts, so you can pre-authorize the costs.

### What Does This Limited Warranty Not Cover?

This limited warranty does not cover defects which did not exist before the transfer of risks. This limited warranty does not cover Products used in rental operations. This limited warranty does not cover purchases of not completely assembled bikes. This limited warranty does not cover any defect caused by "wear and tear" (a complete list of all parts of "wear and tear" can be found in the manual), accident, neglect, improper handling, abuse, misuse, an act of God, improper assembly, non-compliance with recommended maintenance and care procedures, improper or incorrectly performed maintenance or repairs performed by someone other than an authorized SCOTT dealer, use of parts or devices not consistent with the Product, and alteration of the Product. All Products come with a manual; please carefully follow the instructions located there or affixed elsewhere to the Product. To the extent permitted by law, consequential and incidental damages are not recoverable under this limited warranty.

## WARRANTY

### How Do You Make a Claim Under This Limited Warranty?

To make a claim under this limited warranty, you must notify SCOTT of the claimed defect within the warranty period and timely return the Product to SCOTT at your expense for inspection. Please contact your authorized SCOTT dealer, call SCOTT's customer service or the national SCOTT distributor (dealer locator: [www.scott-sports.com](http://www.scott-sports.com)). All returned Products must be accompanied by proof of purchase (receipt) from an authorized SCOTT dealer or this limited warranty will not apply. In case of replacement or refund, returned Product becomes the property of SCOTT.

A protocol for the handing over of the Product (which you will find at the end of the manual) will remain in copy at the SCOTT dealer after acceptance and signature of the consumer. It is obligatory to show this protocol of handing over together with the defective part in case of a warranty claim given that it provides evidence of purchase or this limited warranty will not apply.

### How Do State Laws Affect Your Rights Under This Limited Warranty?

This limited warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

### Recommendation

We strongly recommend that you use only authorized SCOTT dealers for yearly maintenance services and for repairs, as improper or incorrectly performed maintenance or repairs voids this limited warranty. Costs for maintenance service have to be borne by the consumer.

|  <b>Bike Warranty Periods</b> |        |        |        |        |        |
|--|--------|--------|--------|--------|--------|
|  | Year 1 | Year 2 | Year 3 | Year 4 | Year 5 |
| SCOTT Bikes  |        |        |        |        |        |
| Gambler, Voltage FR, Volt-X  |        |        |        |        |        |
| Regular Warranty Period  |        |        |        |        |        |
| Option for prolongation according to maintenance intervals shown in manuals attached to bikes                      |        |        |        |        |        |