



# HARD SURFACE SANITIZING WIPES

## Citrus Scent



Hard Surface Sanitizing Wipes are convenient pre-moistened wipes that kill 99.9% of bacteria in just 15 seconds! No sprays, no sponges or rinsing required. The Hard Surface Sanitizing Wipes leave a light, clean citrus scent. The two in one action cleans and deodorizes in one easy step. Use on washable hard, nonporous surfaces as well as non food contact sanitizing areas.

EPA Registration Number: 6836-340-5741

# HARD SURFACE SANITIZING WIPES

## FEATURES & BENEFITS

- Kills 99.9% of bacteria in just 15 seconds!
- An effective way to clean and deodorize against odor-causing bacteria
- No rinsing required
- Eliminates odors on contact
- Leaves a light, clean scent
- Convenient, hassle free one-hand dispensing
- No sprays, no sponges no mess
- After use, just toss wipe away in garbage
- Reduce risk of cross contamination on hard non-porous surfaces
- Two in one action cleans and sanitizes in one easy step

## RESPONSIBLE CHEMISTRY

- Phosphate free
- Does not contain chlorine bleach or ammonia

## APPLICATIONS

Use Hard Surface Sanitizing Wipes on washable hard, nonporous surfaces of:

- Shopping cart handles, shower stalls and walls, tanning beds, door-knobs, equipment, garbage cans, glass, light switches, toilet seats, bathroom fixtures, bathroom counters, kitchen countertops and other hard nonporous surfaces made of: Acrylic, Formica®, glazed ceramic, metal, plastic (such as polystyrene or polypropylene), upholstery vinyl and plastic.

Use Hard Surface Sanitizing Wipes in non-food contact sanitizing use areas:

- Health clubs, gyms, grocery stores, weight rooms, exercise rooms, schools, transportations, airplanes, trains, automobiles, office buildings, dairies, meat processing plants, food processing areas, food handling areas, bars and restaurants.

Use Hard Surface Sanitizing Wipes to sanitize the hard, non-porous surfaces of personal protective equipment respirators, full face breathing apparatus.

## SPECIFICATION DATA

pH	7.0 – 10.0
Fragrance	Citrus
Specific Gravity @ 24°C/75°F	1.00
Density	8.32
Flash Point	> 100°C / => 212°F
Stability: Shelf @ 24°C/75°F	1 year minimum

## DIRECTIONS FOR USE

This product is not for use on medical device surfaces.

### TO CLEAN AND DEODORIZE

Wipe surface with wipe. Let air dry. Discard used wipe in trash. Do not flush.

### SANITIZING

To sanitize hard, non-porous, non-food contact surfaces; wipe surface, using enough wipes to allow treated surface to remain wet for 15 seconds for *Staphylococcus aureus*, *Klebsiella pneumoniae*, and *Campylobacter jejuni*. Let surface dry. For highly soiled surfaces, clean excess dirt first.

## RELATED PRODUCTS



FLOOR  
STAND  
#930700



STAND  
EXTENSION  
#930701



WALL  
BRACKET  
#930900



DISPENSING  
BUCKET  
#931000

## ORDERING INFORMATION\*



#109006



#109000

## ADDITIONAL RESOURCES

Scan the QR code to access this product's safety information and documentation.



\* Each canister contains 225 pre-moistened, 7" x 5.33" wipes. Each bag contains 1,000 pre-moistened, 7" x 5.33" wipes.

**SAFETY:** For institutional and industrial use only. Be sure to read all directions, precautionary and first aid statements on product labels before using this or any other Spartan product. If questions remain, consult your employer or a physician. Safety Data Sheets for all Spartan products are available from your authorized Spartan distributor and at [www.spartanchemical.com](http://www.spartanchemical.com). Workplace labels are available in English, Spanish, and French.

**GUARANTEE:** Spartan's modern manufacturing and laboratory control ensures uniform quality. If dissatisfied with performance of product, any unused portion may be returned for credit within 12 months of the date of manufacture.