

Characterization of Small Molecule Adsorption on Metal Oxide Colloidal Abrasives Used in Chemical-Mechanical Planarization (CMP) Slurries

Keri A. Martinez, Michael R. Stewart, Kristine M. Campbell,
Dean J. Campbell and Edward E. Remsen

Mund-Lagowski Department of Chemistry and Biochemistry
Bradley University


ACS Great Lakes Regional Meeting
Lisle, IL
May 2, 2019

Outline



- Introduction to Fluorescence Correlation Spectroscopy (FCS) - A Single-Molecule Spectroscopic Analysis Technique
- FCS Analysis of Dye Adsorption on Colloidal Silica and Alumina Abrasive Particles
- Application of Attenuated Total Internal Reflectance / Infrared Spectrometry (ATR/FTIR) for the Analysis of Molecular Adsorption
- ATR/FTIR Analysis of Small Molecule Adsorption on Thin Films of Colloidal Ceria and Silica Abrasive Particles
- Directions for Future Studies

Single-Molecule Spectroscopic Analysis

Fluorescence Correlation Spectroscopy (FCS)





In the focal volume:



$$\begin{aligned} V &= \pi r^2 h \\ &= 1.00 \mu\text{m}^3 \\ &= 1.00 \text{ fL} \end{aligned}$$

FCS Measurements: Intensity Fluctuation Autocorrelation Function, $G(\tau)$






Define the *normalized autocorrelation function*, $G(\tau)$:

$$G(\tau) = \frac{\langle \delta F(t) \cdot \delta F(t + \tau) \rangle}{\langle F(t) \rangle^2}$$


where: $F(t)$ is the intensity at time t

$\delta F(t)$ is the fluctuation in intensity at time t

$\delta F(t + \tau)$ is the fluctuation in intensity at time $t + \tau$



Evaluate the Diffusion Coefficient, D , and Number of Fluorophores, N



$$G(\tau) = \frac{1}{N} \frac{1}{1 + 4D_T \tau / r_0^2} \left[\frac{1}{1 + 4D_T \tau / (z_0/2)^2} \right]^{1/2}$$

τ is related to the *diffusion coefficient*, D :

$$\tau = r_0^2 / 4D$$

where: r_0^2 is the radius of focal volume ($\sim 0.5 \mu\text{m}$)

D is related to the *hydrodynamic diameter*, d :

$$D = kT / 3\pi\eta d \quad (\text{Stokes-Einstein equation})$$

where: k is the Boltzmann constant.


T is the absolute temperature.

η is the solvent viscosity.


$G(0)$ is related to the *average number of fluorophores in the focal volume*, N :

$$G(0) = 1 / N$$


Representative Fluorophores Commonly Employed for FCS Studies




R110, $\lambda_{\text{ex}} = 496 \text{ nm}$, $\lambda_{\text{em}} = 520 \text{ nm}$




OG 488, $\lambda_{\text{ex}} = 501 \text{ nm}$, $\lambda_{\text{em}} = 526 \text{ nm}$




Alexa 488, $\lambda_{\text{ex}} = 490 \text{ nm}$, $\lambda_{\text{em}} = 525 \text{ nm}$



Alexa 546, $\lambda_{\text{ex}} = 556 \text{ nm}$, $\lambda_{\text{em}} = 573 \text{ nm}$







Rhod B, $\lambda_{\text{ex}} = 553 \text{ nm}$, $\lambda_{\text{em}} = 627 \text{ nm}$





Nile Red, $\lambda_{\text{ex}} \sim 540 \text{ nm}$, $\lambda_{\text{em}} \sim 630 \text{ nm}$

FCS Analysis of Dye Adsorption on SiO₂ Abrasives¹



1. Jacobson, L.M.; Turner, D.K.; Wayman, A.E.; Rawat, A.K.; Carver, C.T.; Moinpour, M.; Remsen, E.E.
ECS J. Solid State Sci. Tech. **2015**, 4, P5053-P5057.





Comparison of Un-normalized and Normalized ACFs for Oregon Green 488 as a Function of Concentration



Comparison of Un-normalized and Normalized ACFs for Mixtures of Oregon Green 488 and Alpha Alumina





Comparison of Un-normalized and Normalized ACFs for Supernatants of Centrifuged Mixtures of Oregon Green 488 and Alpha Alumina




Characterization of Abrasive Particle Surface Chemistry and Molecular Interactions During Adsorption

Approach: Attenuated Total Reflectance / Fourier Transform Infrared Spectrometry (ATR/FTIR)




Dissociation Equilibria of Pyridine Carboxylic Acids


pyridine-2-carboxylic acid (picolinic acid)




pyridine-3-carboxylic acid (nicotinic acid)




pyridine-4-carboxylic acid (isonicotinic acid)



Fractional Composition of Pyridine-2-Carboxylic Acid (Picolinic Acid)



Infrared Spectra Indicate Picolinic Acid Adsorption to Ceria²



Assignment of IR spectra:





IR spectra were calculated using Density Functional Theory (B3LYP/6-311++G**).

Solvation was incorporated using the COSMO model; four explicit water molecules were also included.

Explicit water molecules bridged molecular hydrogen bonding sites.




Assignments were made by comparing with benzene, pyridine and pyridinium ion.

2. Marsh, J.L.; Wayman, A.E.; Smiddy, N.M.; Campbell, D.J.; Parker, J.C.; Bosma, W.B.; Remsen, E.E. *Langmuir* **2017**, 33, 13224-13233.




Carboxylate Binding Interactions with a Metal Oxide Film


Use benzoic acid as a model compound:




Analysis of Adsorption on Colloidal Silica Abrasive Particles




Desorption of SiO₂-CeO₂ Films on ATR Crystal



pH Stability of $\text{SiO}_2\text{-CeO}_2$ Films on ATR Diamond Crystal



IR Spectra of Tetramethylammonium (TMA) Ions Adsorbed to the SiO_2 Films on the SiO_2 - CeO_2 Bilayer




Spectrum A: 40 mM TMA, pH 6

Spectrum B: 40 mM TMA, pH 6, equilibrated with a dehydroxylated colloidal silica particle ($D_n = 44$ nm) film on the CeO_2 layer.

Spectrum C: 40 mM TMA, pH 6, equilibrated with a hydroxylated colloidal silica particle ($D_n = 39$ nm) film on the CeO_2 layer.

Langmuir Isotherms for TMA Ion Adsorption on Silica Films



Directions for Future Studies

- Using FCS and ATR/FTIR, quantitatively evaluate adsorption isotherms for CMP additive interactions with alumina (alpha and fumed) and zirconia abrasive particles
- Apply ATR/FTIR method to characterize the mode(s) of interaction of TMA with silica abrasive particles prepared by different synthetic methods to assess surface chemistry differences among different silica abrasives
- Extend ATR/FTIR method to characterize the mode(s) of interaction of CMP abrasives with alumina abrasive particles of different types (alpha, fumed, etc.) to assess surface chemistry differences among different alumina abrasives

Acknowledgements

Graduate Students: Keri Martinez, Ashley Wayman, Lauren Jacobson, Daniel Turner

Undergraduates: Michael Stewart, Kristine Campbell, Patrick Schneider, Nicole Smiddy,
Charles Ramia

Collaborators: Dean Campbell, Wayne Bosma, John Parker

Bradley University and the Mund Lagowski Dept. of Chemistry and Biochemistry

Cabot Microelectronics Corporation

Intel Corporation