


Instructions



Broken Key Extractor Set

No. EZ-6



INSTRUCTIONS

1. An assortment of both saw and spiral type blades are enclosed inside the handle.
2. Remove plastic cap, select blade, open collet and insert blade.
3. Tighten spiral blade with about 1 3/8" exposed.
4. For maximum grip on spiral type blade, pull against sharp edge as shown.
5. For maximum grip on saw type blade, push the blade all the way into opened collet, with the blade positioned at the bottom. Tighten firmly.



6. Always close collet when finished, so that blades will not be lost. Replace plastic cap.

REPLACEMENT BLADES

- | | |
|-----------|--|
| No. EZ-7A | 10 Saw Type Extractor Blades |
| No. EZ-7B | 10 Round Type Extractors,
.040" Standard Diameter |
| No. EZ-7C | 10 Round Type Extractors,
.050" Heavy Diameter |
| No. EZ-7D | 10 Piece Assortment, Consisting
of 4 of 7A, 4 of 7B, and 2 of 7C. |



100506 35T00-096-00