



Ligature Resistant Locks



**Ligature Resistant
Rx Series**

TownSteel is pleased to introduce the most complete line of Ligature Resistant Locks available today in the commercial contract hardware industry: ADA Ligature Resistant Levered Mortise Lock (MRX-L), ADA Ligature Resistant Arch Levered Mortise Lock (MRX-A), Levered Cylindrical Lock (TRX-L, HRX-L), Standard configuration Ligature Resistant Conical Knob Mortise Lock (MRX-K), and Conical Knob Cylindrical Lock (CRX-K). TownSteel also offers the only Ligature Resistant Rejuvenator Conical Knob lock retrofit trim set (RRX-K) which will retrofit most major brand mortise locks.



Contact us for more info.

Phone: 1-877-858-0888

Web: www.townsteel.com

Email: sales@townsteel.com

Ligature Resistant Series Family

Grade 1 Mortise Lock -Lever



MRX-E-L



MRX-S-L



MRX-S-L



MRX-A

Grade 1 Mortise Lock -Knob



MRX-E-K



MRX-S-K



MRX-S-K

Grade 1 Cylindrical Lock -Lever



HRX-L



TRX-L

Grade 1 Cylindrical Lock -Knob



CRX-K

Rejuvenator



RRX-E-K



RRX-S-K

Grade 1 Deadbolt




ADA (optional)



DRX

Ligature Resistant Locks

MRX-L ANSI Grade 1 Mortise Lock with Ligature Resistant Trim-Lever



- High quality stainless steel components
- Meets or exceeds all performance testing of ANSI A156.13 Grade 1 mortise locks
- Integral part of your Health/Safety and Accident Prevention programs
- Mortise is UL listed for a 3 hour fire door
- Clutching mortise
- Clutching function can be activated for I/S and / or O/S levers
- Outside clutching lever to protect lock against abuse and allow free rotation.
- Variety of mortise functions available to fit your unique security and safety requirements
- ADA turn piece, standard
- Tamper resistant mounting screws, standard
- Heavy duty escutcheon and sectional trim available
- Handing field reversible
- Schlage C keyway, standard
- Small Format 6 or 7 pin Interchangeable Core (SFIC) available
- 32D Finish

How To Order


Trim	MRX-E-L Ligature Resistant Lever Mortise-Escutcheon Trim MRX-S-L Ligature Resistant Lever Mortise-Sectional Trim
Function	Please Refer to Function Sheet
IC	IC
Example MRX-E-L-04-IC 1. Ligature Resistant Lever Mortise - Escutcheon Trim 2. Function 3. IC (optional)	

Important Note:

It is TownSteel's position that if any of our keyed locks are to be used less cylinder, whether I.C. or standard, and another manufacturer's cylinder is to be used in place of the TownSteel original manufacturer's cylinder, that a sample of that product be provided to TownSteel in advance for testing.



MRX-K ANSI Grade 1 Mortise Lock with Ligature Resistant Trim-Knob



- High quality stainless steel components
- Meets or exceeds all performance testing of ANSI A156.13 Grade 1 mortise locks
- Integral part of your Health/Safety and Accident Prevention programs
- Mortise is UL listed for a 3 hour fire door
- Variety of mortise functions available to fit your unique security and safety requirements
- Tamper resistant mounting screws, standard
- Heavy duty escutcheon and sectional trim available
- Schlage C keyway, standard
- Small Format 6 or 7 pin Interchangeable Core (SFIC) available
- 32D Finish



Important Note:


It is TownSteel's position that if any of our keyed locks are to be used less cylinder, whether I.C. or standard, and another manufacturer's cylinder is to be used in place of the TownSteel original manufacturer's cylinder, that a sample of that product be provided to TownSteel in advance for testing.

How To Order

Trim	MRX-E-K Ligature Resistant Mortise-Escutcheon Trim MRX-S-L Ligature Resistant Mortise-Sectional Trim
Function	Please Refer to Function Sheet
IC	IC
Example MRX-E-K-04-IC 1. Ligature Resistant Knob Mortise - Escutcheon Trim 2. Function 3. IC (optional)	



MRX-A ANSI Grade 1 Mortise Lock with Ligature Resistant Trim-Arch



- Designed for areas housing patients and individuals at risk.
- Meets or exceeds all performance testing of ANSI A156.13 Grade 1 mortise locks
- Mortise body is UL listed for a 3 hour fire door
- Ligature resistant, an integral part of your Health/Safety and Accident Prevention programs.
- 5 Point design: a 0.5mm diameter wire or greater cannot be attached to the lock from any direction (up, down, horizontal right, horizontal left or perpendicular to surface of the door).
- Heavy duty ligature resistant arch lever trim (requires handing).
- High quality stainless steel components.
- Tamper resistant security stainless steel mounting screws
- Variety of mortise functions available to fit your unique security and safety requirements.
- Horizontal or vertical trim mounting.
- ADA thumb turn, standard.
- Schlage C keyway, standard.
- Small format 6 or 7pin interchangeable Core (SFIC) available.
- US32D finish.

How To Order

Trim	MRX-A Ligature Resistant Mortise Arch Lever Trim
Function	Please Refer to Function Sheet
IC	Small Format IC Less Core (Optional)
LH	Left Hand Door

Example

MRX-A-04-IC-LH

1. MRX-A: Ligature Resistant Mortise Arch Lever Trim
2. 04: ANSI F-04 function
3. IC: Small format IC less core (Optional)
4. LH: Left hand door

Important Note:



It is TownSteel's position that if any of our keyed locks are to be used less cylinder, whether I.C. or standard, and another manufacturer's cylinder is to be used in place of the TownSteel original manufacturer's cylinder, that a sample of that product be provided to TownSteel in advance for testing.



Ligature Resistant Mortise Series

Functions*



*Levers rotate up and down freely in the locked or unlocked positions

Outside	Inside	Series/ Function	Type	ANSI No.	Function Description
		MRXL-01 MRXK-01	Passage or Closet	F01	Latch bolt operated by lever from either side at all times.
		MRXL-02 MRXK-02	Privacy or Bathroom	F02	Latch bolt operated by lever from either side. Dead bolt operated by turn from inside and emergency release from outside.
		MRXL-04 MRXK-04	Entry/ Office	F04	Latch bolt operated by lever from either side, except when outside lever is made inoperative by a push button rocker. When outside lever is locked, latch bolt is retracted by key from outside or by operating inside lever. ***Auxiliary dead latch.
		MRXL-05 MRXK-05	Classroom	F05	Latch bolt operated by lever from either side, except when outside lever is locked from outside by key. When outside lever is locked, latch bolt may be retracted by key, or by operating key and outside lever or by operating inside lever. ***Auxiliary dead latch.
		MRXL-07 MRXK-07	Storeroom or Closet	F07	Latch bolt operated by key from outside or by rotating inside lever. Outside lever is always inoperative. ***Auxiliary dead latch.
		MRXL-08 MRXK-08	Front Door or Corridor Lock	F08	Latch bolt operated by lever from either side, except when outside lever is made inoperative by a push button rocker. Dead bolt is operated by turn inside. Key outside operates both bolts.
		MRXL-12 MRXK-12	Dormitory or Exit	F12	Latch bolt operated by lever from either side, except when outside lever is made inoperative by a push button rocker. Dead bolt projected by key from outside and by turn from inside. Deadbolt retracted by key from outside and by turn from inside. Operating inside lever retracts both bolts and outside remains locked.
		MRXL-13 MRXK-13	Dormitory or Exit	F13	Latch bolt operated by lever from either side. Dead bolt projected by key from outside and thumb turn from inside. Operating inside lever retracts both bolts and unlocks outside.

Ligature Resistant Mortise Series

Functions




*Levers rotate up and down freely in the locked or unlocked positions

Outside	Inside	Series/ Function	Type	ANSI No.	Function Description
		MRXL-14	Store Door Lock	F14	Latch bolt operated by lever from either side. Dead bolt operated by key from either side.
		MRXL-15 MRXK-15	Hotel or Motel	F15	Latch bolt operated by key from outside or by rotating inside lever. Outside lever is always inoperative. Dead bolt operated by thumb turn from inside and all keys except emergency and display key are shut out. Operating inside lever retracts both bolts. ***Auxiliary dead latch.
		MRXL-19 MRXK-19	Privacy or Bathroom	F19	Latch bolt operated by lever from either side. Dead bolt operated by turn from inside and emergency release from outside. Operating inside lever retracts both bolts.
		MRXL-20 MRXK-20	Apartment/ Corridor	F20	Latch bolt operated by lever from either side, except when outside lever is made inoperative by push button rocker. Dead bolt projected by key from outside and by thumb turn from inside. Key outside operates both bolts. Operating inside lever retracts both bolts and outside remains locked. Latch bolt is deadlocked when outside lever is made inoperative or when the dead bolt is projected. When dead bolt is retracted, lever is unlocked by stop or mechanical means other than key.
		MRXL-22 MRXK-22	Privacy	F22	Latch bolt operated by lever from either side, except when outside lever is locked by inside turn. Operating inside lever, closing door or operating outside emergency release unlocks outside lever.
		MRXL-26 MRXK-26	Institutional Privacy	F26	Latch bolt operated by lever from either side except when outside lever is locked by turn inside. Latch bolt operated by key outside with override of turn inside when manually held in locked position. Operating inside lever or closing door unlocks outside lever. ***Auxiliary dead latch.
		MRXL-29 MRXK-29	Classroom Dead Lock	F29	Key from outside operates dead bolt. Turn from inside retracts but does not project dead bolt.
		MRXL-30 MRXK-30	Institutional	F30	Latch bolt operated by key either side. Both levers always inoperative. ***Auxiliary dead latch.

Ligature Resistant Mortise Series

Functions


**Levers rotate up and down freely in the locked or unlocked positions*

Outside	Inside	Series/ Function	Type	ANSI No.	Function Description
		MRXL-32 MRXK-32	Intruder Latch bolt	F32	Latch bolt operated by lever either side, except when outside lever is locked from inside or outside by key. When outside lever is locked, latch bolt is retracted by key from inside or outside or by operating inside lever. ***Auxiliary dead latch
		MRXL-33 MRXK-33	Intruder Dead bolt	F33	Latch bolt operated by lever either side, except when outside lever is locked from inside or outside by key. Dead bolt operated by key either side. Inside lever retracts both bolts and unlocks outside lever.
		MRXL-34 MRXK-34	Intruder Dead bolt	F34	Latch bolt operated by lever either side, except when outside lever is locked from inside or outside by key. Dead bolt operated by key either side. Operating inside lever retracts both bolts and unlocks outside. *** Auxiliary dead latch or latch bolt dead locked when dead bolt is thrown.
		MRXL-35 MRXK-35	Storeroom with Dead bolt	F35	Latch bolt operated by lever from either side, except when outside lever is made inoperative by a push button rocker. Dead bolt operated by key from either side.
		MRXL-46 MRXK-46	Institutional Privacy with key locked feature		Latch bolt operated by lever from either side except when outside lever is locked by turn inside or key outside. Latch bolt operated by key outside with override of turn inside when manually held in locked position. Operating inside lever or closing door unlocks outside lever. ***Auxiliary dead latch.
		MRXL-RF MRXK-RF	Female Privacy RF		Latch bolt operated by lever from either side except when outside lever is locked from outside by key or inside turn. When outside lever is locked latch bolt may be retracted by inside lever or outside lever when unlocked by key. Inside lever retracts the latch bolt but does not unlock the outside lever.
		MRXL-LTF MRXK-LTF	Female Privacy LTF		Latch bolt operated by lever from either side except when outside lever is locked from outside by key or inside turn. When outside lever is locked latch bolt may be retracted by inside lever or outside lever when unlocked by key. Operating the inside lever or closing the door unlocks the outside lever.

HRX-L ANSI Grade 1 Cylindrical Lock with Ligature Resistant Trim-Lever



- Design impedes ability to attach laces, cords, and lines to the lever set
- Enhances opportunity to reduce accidents in health care facilities, detention centers and other potential high risk areas
- Designed to be an integral part of your Accident Prevention and Safety Program
- Outside clutching lever to protect lock against abuse and allow free rotation.
- Cylindrical is UL listed for a 3 hour fire door
- ADA compliant
- Meet or exceed ANSI 156.2-4000 Grade 1 Standard
- Tamper resistant mounting screws, standard
- Schlage C keyway, standard
- Small Format 6 or 7 pin Interchangeable Core (SFIC) available
- 32D Finish



How To Order

Trim	HRX-L Ligature Resistant Lever Grade 1 Cylindrical Lock
Function	Please Refer to Function Sheet
IC	IC
Example HRX-L-81-IC 1. Ligature Resistant Lever Cylindrical 2. Function 3. IC (optional)	


Important Note:

It is TownSteel's position that if any of our keyed locks are to be used less cylinder, whether I.C. or standard, and another manufacturer's cylinder is to be used in place of the TownSteel original manufacturer's cylinder, that a sample of that product be provided to TownSteel in advance for testing.

TRX-L ANSI Grade 1 Cylindrical Lock with Ligature Resistant Trim-Lever



- Design impedes ability to attach laces, cords, and lines to the lever set
- Enhances opportunity to reduce accidents in health care facilities, detention centers and other potential high risk areas
- Designed to be an integral part of your Accident Prevention and Safety Program
- Outside clutching lever to protect lock against abuse and allow free rotation.
- Cylindrical is UL listed for a 3 hour fire door
- ADA compliant
- Meet or exceed ANSI 156.2-4000 Grade 1 Standard
- Tamper resistant mounting screws, standard
- Schlage C keyway, standard
- Small Format 6 or 7 pin Interchangeable Core (SFIC) available
- 32D Finish



How To Order

Trim	TRX-L Ligature Resistant Lever Grade 1 Cylindrical Lock
Function	Please Refer to Function Sheet
IC	IC

Example


TRX-L-81-IC

1. Ligature Resistant Lever Cylindrical
2. Function
3. IC (optional)

Important Note:

It is TownSteel's position that if any of our keyed locks are to be used less cylinder, whether I.C. or standard, and another manufacturer's cylinder is to be used in place of the TownSteel original manufacturer's cylinder, that a sample of that product be provided to TownSteel in advance for testing.

CRX-K ANSI Grade 1 Cylindrical Lock with Ligature Resistant Trim-Knob



All locks provided are non-handed and 3 hour UL fire listed. The latch and dead latch are sintered stainless steel. The lock chassis is heavy duty wrought steel construction. Springs are tensioned for knob use and provide long life and smooth operation. Knobs are of stainless steel construction. Locks meet all requirements for ANSI grade 1 series 4000 locks. Locks fit into a standard ANSI 161 door preparation. 32D Finish. Schlage C keyway, standard



Important Note:

It is TownSteel's position that if any of our keyed locks are to be used less cylinder, whether I.C. or standard, and another manufacturer's cylinder is to be used in place of the TownSteel original manufacturer's cylinder, that a sample of that product be provided to TownSteel in advance for testing.

How To Order







Trim	CRX-K Ligature Resistant Knob Grade 1 Cylindrical Lock
Function	Please Refer to Function Sheet
Example CRX-K-84	
1. Ligature Resistant Knob Cylindrical	_____
2. Function	_____




Ligature Resistant Cylindrical Series

Functions*

*Levers rotate up and down freely in the locked or unlocked positions

Outside	Inside	Series/ Function	Type	ANSI No.	Function Description
		CRXK-81 HRXL-81 TRXL-81	Entry / Office	F81	Turn/Push button locking. Pushing and turning button locks outside lever or knob requiring use of key until button is manually unlocked. Pushing button locks outside lever or knob until unlocked from outside by key or operating inside lever or knob. Dead locking latch bolt.
		CRXK-84 HRXL-84 TRXL-84	Classroom	F84	Deadlocking latch bolt operated by lever or knob from either side except when outside lever or knob is locked from outside by key. When outside lever or knob is locked, latch bolt is operated by key in outside lever or knob or operating inside lever or knob.
		CRXK-86 HRXL-86 TRXL-86	Storeroom	F86	Deadlocking latch bolt operated by key in outside lever or knob or operating inside lever or knob. Outside lever or knob is always non-active.
		CRXK-87 HRXL-87 CRXL-87	Asylum	F87	Deadlocking latch bolt operated by key in lever or knob from either side. Both levers or knobs always non-active.
		CRXK-75 HRXL-75 TRXL-75	Passage / Closet	F75	Latch bolt operated by lever or knob from either side at all times.
		CRXK-76 HRXL-76 TRXL-76	Privacy	F76	Latch bolt operated by lever or knob from either side. Outside lever or knob is locked by push button inside and unlocked by emergency release outside, operating inside lever or knob or closing door.
		CRXK-72 HRXL-72 TRXL-72	Double Dummy	F72	Dummy lever or knob for inside and outside.
		CRXK-110	Classroom Intruder	F110	Deadlocking Latch bolt operated by knob from either side except when outside knob is locked from the inside or outside by key. When outside knob is locked latch bolt is operated by inside knob or unlocked by key in outside or inside knob.

DRX ANSI Grade 1 Mortise Deadbolt Lock with Ligature Resistant Thumb Turn



DRX Series- Heavy duty commercial quality dead-bolt that provides a positive deterrent to forced entry. The health safety thumb turn design enhances opportunity to reduce accidents in health care facilities, detention centers and potential high risk areas. It is also designed to be an integral part of your Accident Prevention and Safety Program. Schlage C keyway, standard Small Format 6 or 7 pin Interchangeable Core (SFIC) available. 32D Finish. ADA Turn piece available



DRX Functions

ANSI F09		Deadbolt operated by key from outside and turn from inside turn retracts but does not project deadbolt
ANSI F07		Deadbolt operated by key from outside and turn from inside
ANSI F18		Deadbolt operated by turn from inside only, no trim on other side

How To Order

Trim	DRX Ligature Resistant Knob Deadbolt Lock
Function	F09, F07, F18
Example DRX-18-ADA	
1. Ligature Resistant Knob Deadbolt	_____
2. Function	_____
3. ADA Turn piece (Optional)	_____

Important Note:


It is TownSteel's position that if any of our keyed locks are to be used less cylinder, whether I.C. or standard, and another manufacturer's cylinder is to be used in place of the TownSteel original manufacturer's cylinder, that a sample of that product be provided to TownSteel in advance for testing.

RRX-K Ligature Resistant Knob Rejuvenator Retrofit Mortise Kit



- Heavy Duty Ligature Resistant Knob Retrofit kit
- Convert existing through bolt mortises to an Ligature Resistant Knob lock set
- Fits all major mortise brands*
- Heavy Duty Stainless steel trim
- Maintain existing Keyways and Cylinders
- Part of your environmental Green program to recycle rather than replace entire locksets
- Save costs on conversion to Ligature Resistant

*Fits- Arrow, Best, Corbin, PDQ, Marks, Sargent, Schlage, Falcon, Yale




How To Order

Trim	RRX-E-K Ligature Resistant Knob Rejuvenator - Escutcheon Trim RRX-S-K Ligature Resistant Knob Rejuvenator - Sectional Trim
T-Turn	TX - Ligature Resistant Thumb Turn
Example 1. Ligature Resistant Knob Rejuvenator- Escutcheon Trim 2. Thumb Turn RRX-E-K-TX	



VRH Ligature Resistant Hook





FEATURES

- Ideal for hospital, school and other institutions
- 14 gauge heavy duty 18-8 S, type-304 stainless steel backplate
- Stainless steel pivoting ball joint releases when over 10lbs of force applied
- Pivoting ball tension adjustable
- Surface mounted
- Furnished with tamper resistant #14 x 1 1/2" wood screws
- Available finish: Satin Stainless Steel (US32D)

TDS Ligature Resistant Door Switch

TDS Door Switch -Ligature Resistant Device for facilities housing patients at risk



Example of Basic Monitoring Keypad Console

BASIC MONITORING PANEL FEATURES

All wiring and alarm input/output devices are supervised to prevent tampering.

48 double door, 96 single door rooms available on single basic panel. Up to eight panels can be linked together to monitor a total of 384-788 rooms.

Keypad console audible indicator and two-line, 32 character LCD display alerts an alarm condition or system trouble at nurses' station.

Main panel provides an event log (history log) that can store up to 512 events. Logged events can be viewed on keypad console.

NEW ! Townsteel Door Switch

The TownSteel Door Switch is a patented design. (US Patent No. RE42,991)

For more information, please visit www.townsteel.com or call toll free at (877) 858-0888

Ligature Resistant Project References



MRX-L

- VA Medical Center, Murfreesboro, TN
- VA Medical Center, Nashville, TN
- VA Medical Center, Marion, IL
- VA Medical Center, Salt Lake City, UT
- VA Medical Center, Dayton, OH
- VA Hospital, Tampa, FL
- Forest View Hospital, Wyoming, MI
- Kingbrook Jewish Medical Center, Brooklyn, NY
- Capistrano Care Facility, San Juan Capistrano, CA
- Eastern L.I. Hospital, Greenport, NY
- New York Presbyterian Hospital, New York, NY
- Summit Ridge Hospital, Lawrenceville, GA
- VA Hospital, Tucson, AZ
- First Judicial District, Waterloo, IA
- Navy Medical Center Mental Health Bldg., San Diego, CA
- MSJ ER Psych Eval., Ashville, NC
- North Star Hospital, Anchorage, AK
- Pima Hospital, Tucson, AZ
- Johns Hopkins Hospital, Baltimore, MD
- Holly Hill Hospital, Raleigh, NC
- Jacobi Medical Center, Bronx, NY
- Meadows Hospital, Centre Hall, PA



DRX

- VA Central Alabama Medical Center, Montgomery, AL
- Charlotte Behavioral Health Care, Punta Gorda, FL



Other Ligature Resistant Products

- VA Medical Center, Marion, IL
- VA Medical Center, Murfreesboro, TN
- VA Medical Center, Jackson, MS
- Moberly Regional Hospital, Moberly, MO
- Dixie Regional Hospital, St. George, UT
- Fairfax Hospital, Falls Church, Virginia
- St. Elizabeth Medical Center, Youngstown, OH
- St. Joseph Medical Center, Towson, MD
- Carolina East Health Care, New Bern, NC
- Northern Westchester Hospital, Mt. Kisco, NY
- Abington Hospital, Abington, PA
- Central State Hospital, Milledgeville, GA
- East Central Georgia Regional Hospital, Augusta, GA
- St. Mary's Hospital, Richmond, VA
- Larue D. Carter Memorial, Indianapolis, IN
- Hoboken Hospital, Hoboken, NJ
- Clarks Summit State Hospital, Clarks Summit, PA
- Memorial Hospital, Stillwell, OK
- Thomas B Finan Center, Cumberland, MD
- Balboa Hospital, San Diego, CA
- Capistrano Care Facility, San Juan Capistrano, CA
- Four Winds Hospital, Saratoga Springs, NY
- Lutheran Social Services, Sioux Falls, SD
- Olean General Hospital, Olean, NY
- Kaiser Hospital, Los Angeles, CA
- Northwest GA Regional Hospital, Rome, GA
- Howard Community Hospital, Kokomo, IN
- Vanderbilt Hospital, Nashville, TN
- Friends Behavioural Health System, Philadelphia, PA
- Medical Center of McKinney & Wysong Campus, McKinney, TX
- Canyon Hills Center-Luth Social, Spearfish, SD
- Children's Hospital, Dallas, TX
- Sarasota Memorial Public Hospital, Sarasota, FL
- Lewis Gail Hospital, Salem, VA
- Nova House, Dayton, OH
- VA Hospital, Loma Linda, CA
- Harrisonburg-Rockingham Community Services Board, Harrisonburg, VA
- CPSA, Tucson, AZ
- Adventist Health, Rockville, MD
- North Memorial Med Center, Robbinsdale, MN
- Flushing Hospital Medical Center, Flushing, NY



MRX-K

- VA Hospital, North Chicago, IL
- University of Maryland Medical Center, Baltimore, MD
- NYP Adolescent Separation, New York, NY
- Gustavus Adolphus Home Jamestown, NY



HRX-L

- Southern Hills Hospital Las Vegas, NV
- St. Mary's Psych - Russellville, AR
- Freeman Hospital - Joplin, MO
- Jackson Healthcare System, Miami, FL
- Peachford Hospital, Atlanta, GA
- Wekiva Spring Mental Health Center - Jacksonville, FL
- Coney Island Hospital, Brooklyn, NY



CRX-K

- Aurora Health Care, Wauwatosa, WI
- South Oaks Hospital, Long Island, NY
- Terre Haute Regional Hospital, Terre Haute, IN
- Oswego Hospital, Oswego, NY
- Research Psychiatric Center, Kansas City, MO
- West Central Georgia Regional Hospital, Columbus, GA
- Sentara Norfolk Hospital, Virginia Beach, VA
- KMC-Sycamore Hospital, Miamisburg, OH
- Long Island South Oaks Manor, Amityville, NY



17901 Railroad Street , City of Industry, CA 91748

Toll Free: 877-858-0888 | Tel: 626-965-8917 | Fax: 626-965-8919

Web: www.townsteel.com Email: sales@townsteel.com