

**apuro**

## Heated Display Merchandiser

Instruction manual

**INDUSTRY  
KITCHENS**

[www.industrykitchens.com.au](http://www.industrykitchens.com.au) 1800 611 058



**Model:**  
**CD231-A / CD232-A**

## Safety Tips

- Position on a flat, stable surface.
- A service agent/qualified technician should carry out installation and any repairs if required. Do not remove any components on this product.
- Consult Local and National Standards to comply with the following:
  - Health and Safety at Work Legislation
  - Fire Precautions
  - Wiring Regulations
  - Building Regulations
- **Warning! Hot surface! Always wear safety gloves when placing or removing food.**
- This product is only designed to store food temporarily. Do not use for laboratory or industrial purposes.
- DO NOT use jet/pressure washers to clean the appliance.
- DO NOT use the appliance outside.
- DO NOT use the appliance to store medical supplies.
- DO NOT use electrical appliances inside the appliance (e.g. heaters, ice-cream makers etc.).
- DO NOT allow oil or fat to come into contact with the plastic components or door seal. Clean immediately if contact occurs.
- DO NOT store products on top of the appliance.
- Always carry, store and handle the appliance in a vertical position and move by holding the base of the appliance.
- Always switch off and disconnect the power supply to the appliance when not in use.
- Keep all packaging away from children. Dispose of the packaging in accordance to the regulations of local authorities.
- If the power cord is damaged, it must be replaced by an Apuro agent or a recommended qualified technician in order to avoid a hazard.



- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Apuro recommend that this appliance should be periodically tested (at least annually) by a Competent Person. Testing should include, but not be limited to: Visual Inspection, Polarity Test, Earth Continuity, Insulation Continuity and Functional Testing.

## Product Description

**CD231-A** - Apuro Heated Display Merchandiser 120Ltr

**CD232-A** - Apuro Heated Display Merchandiser 160Ltr

## Introduction

Please take a few moments to carefully read through this manual. Correct maintenance and operation of this machine will provide the best possible performance from your Apuro product.

## Pack Contents

The following is included:

- Apuro Heated Display Merchandiser
- Water Tray
- 3 x Shelves
- Instruction manual

Apuro prides itself on quality and service, ensuring that at the time of packaging the contents are supplied fully functional and free of damage.

Should you find any damage as a result of transit, please contact your Apuro dealer immediately.

## Installation

- Remove all packaging and dispose of it safely.
- Wipe all surfaces with a clean, damp cloth before use.
- Position the Merchandiser on a level and stable surface, insert the shelves on to the shelf supports, add water to the Water Tray if humidification is required, taking care not to overfill.
- There should be at least 100mm clearance on all sides, Do not place objects on top of the Merchandiser at any time.

## Operation

- Add water to the Water Tray if humidification is required, then place the Tray in position inside the Merchandiser.
- Connect the Merchandiser to electricity by inserting the plug into a socket, turn on supply at socket.
- Turn switch at the rear of the Merchandiser to the on position, this will start the heating element.
- Rotate the knob at the rear of the Merchandiser to set the temperature. The temperature in the Merchandiser can be read from the display on the lower front panel of the Merchandiser.
- The Merchandiser is now ready for food to be displayed and kept warm.
- Your Merchandiser has a lamp to illuminate the contents, this can be lit by using the switch next to the on/off switch at the rear of the Merchandiser.

## Cleaning, Care & Maintenance



**Always turn off and disconnect the appliance from the power supply before cleaning. Always allow the appliance to cool before emptying or cleaning.**

- Remove any food debris that is present in the Merchandiser after use.
- Clean the internal surfaces with a cloth that is damp with soapy water, or with a food safe cleaning agent.
- Dry thoroughly after cleaning making sure that no moisture is left in the Merchandiser.

## Troubleshooting

If your Apuro appliance develops a fault, please check the following table before making a call to the Helpline.

| Fault                                                    | Probable Cause              | Solution                                               |
|----------------------------------------------------------|-----------------------------|--------------------------------------------------------|
| Indicator Light does not come on & unit does not heat up | The unit is not switched on | Check the unit is plugged in correctly and switched on |
|                                                          | Plug and lead are damaged   | Call Apuro agent or qualified technician               |
|                                                          | Power supply                | Check power supply                                     |
|                                                          | Internal wiring fault       | Call Apuro agent or qualified technician               |
|                                                          | Thermostat has failed       | Call Apuro agent or qualified technician               |
| Indicator Light comes on but unit does not heat up       | Heating element has failed  | Call Apuro agent or qualified technician               |
|                                                          | Thermostat has failed       | Call Apuro agent or qualified technician               |
| Lamp does not light when switched on                     | The unit is not switched on | Check the unit is plugged in correctly and switched on |
|                                                          | Lamp has failed             | Replace lamp, call Apuro agent for replacement         |

## Technical Specifications

| Model          | Voltage           | Power | Current | Temperature range | Dimensions<br>H x W x D mm | Weight |
|----------------|-------------------|-------|---------|-------------------|----------------------------|--------|
| <b>CD231-A</b> | 220-240V~<br>50Hz | 1100W | 4.75A   | 30°C-90°C         | 686 x 678 x 568            | 35kg   |
| <b>CD232-A</b> | 220-240V~<br>50Hz | 1500W | 6.3A    | 30°C-90°C         | 686 x 856 x 568            | 43kg   |

## Electrical Wiring

The plug is to be connected to a suitable mains socket.

This appliance is wired as follows:

- Live wire (coloured brown) to terminal marked L
- Neutral wire (coloured blue) to terminal marked N
- Earth wire (coloured green/yellow) to terminal marked E

This appliance must be earthed.



If in doubt consult a qualified electrician.

Electrical isolation points must be kept clear of any obstructions. In the event of any emergency disconnection being required they must be readily accessible.

## Compliance

The product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority responsible for waste disposal in your area.

Apuro parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorities.



Apuro products have been approved to carry the following symbol:

**All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of Apuro.**  
**Every effort is made to ensure all details are correct at the time of going to press, however, Apuro reserves the right to change specifications without notice.**

# DECLARATION OF CONFORMITY

- Conformiteitsverklaring • Déclaration de conformité • Konformitätserklärung • Dichiarazione di conformità •  
• Declaración de conformidad • Declaração de conformidade

|                                                                                                                                                                                                                                                                                                                             |                                                                                                                                                                                                             |
|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Equipment Type • Uitrustingstype • Type d'équipement • Gerätetyp<br>• Tipo di apparecchiatura • Tipo de equipo • Tipo de equipamento                                                                                                                                                                                        | Model • Modèle • Modell • Modello<br>• Modelo • Mali                                                                                                                                                        |
| Heated Display Merchandiser - 120Ltr<br>Heated Display Merchandiser - 160Ltr                                                                                                                                                                                                                                                | CD231-A<br>CD232-A                                                                                                                                                                                          |
| Application of Territory Legislation & Council Directives(s)<br>Toepassing van Europese Richtlijn(en) •<br>Application de la/des directive(s) du<br>Conseil • Anwendbare EU-Richtlinie(n) •<br>Applicazione delle Direttive<br>• Aplicación de la(s) directiva(s) del<br>consejo • Aplicação de directiva(s) do<br>Conselho | Electrical Safety<br>EN 60335-1:2012 +A11:2014 +A13:2017<br>EN 60335-2-49:2003 +A1:2008 +A11:2012<br>EN 62233:2008<br><br>Electromagnetic Compatibility<br>EN 61000-6-1: 2007<br>EN 61000-6-1: 2007+A1:2011 |
| Producer Name • Naam fabrikant • Nom du producteur • Name des Herstellers<br>• Nome del produttore • Nombre del fabricante • Nome do fabricante                                                                                                                                                                             | Apuro                                                                                                                                                                                                       |

I, the undersigned, hereby declare that the equipment specified above conforms to the above Territory Legislation, Directive(s) and Standard(s).

Ik, de ondergetekende, verklaar hierbij dat de hierboven gespecificeerde uitrusting goedgekeurd is volgens de bovenstaande Richtlijn(en) en Standaard(en).

Je soussigné, confirme la conformité de l'équipement cité dans la présente à la / aux Directive(s) et Norme(s) ci-dessus  
Ich, der/die Unterzeichnende, erkläre hiermit, dass das oben angegebene Gerät der/den oben angeführten Richtlinie(n) und Norm(en) entspricht.

Il sottoscritto dichiara che l'apparecchiatura di sopra specificata è conforme alle Direttive e agli Standard sopra riportati.

El abajo firmante declara por la presente que el equipo arriba especificado está en conformidad con la(s) directiva(s) y estándar(es) arriba mencionadas.

Eu, o abaixo-assinado, declaro que o equipamento anteriormente especificado está em conformidade com a(s) anterior(es) Directiva(s) e Norma(s)

Date • Data • Date • Datum • Data •  
Fecha • Data

Signature • Handtekening • Signature  
• Unterschrift Firma • Firma •  
Assinatura

Full Name • Volledige naam • Nom et  
prénom • Vollständiger Name • Nome  
completo • Nombre completo • Nome  
por extenso

Position • Functie • Fonction • Position  
• Qualifica • Posición • Função

Producer Address • Adres fabrikant •  
Adresse du producteur • Anschrift des  
Herstellers • Indirizzo del produttore •  
Dirección del fabricante • Morada do  
fabricante

30<sup>th</sup> December 2020

DocuSigned by:

Ashley Hooper

B39382C9FD9C478...

Ashley Hooper

Technical & Quality Manager

Fourth Way,  
Avonmouth,  
Bristol,  
BS11 8TB  
United Kingdom

DocuSigned by:

Josie Holt

3582E210C4054DA...

Josie Holt

Commercial Manager/ Responsible  
Supplier

15 Bagdally Road,  
Campbelltown  
NSW 2560





**apuro**

CD231-A\_CD232-A\_A5\_v2\_20210106