

**MODEL: 354010 - CANCEL STATION**



354010

**FEATURES**

- One (1) Cancel button
- Flexible programming for cancellation of calls in a room
- Continuous supervision of station
- Plug-in connectors for easy service
- Optional antimicrobial Bio-seal to cover buttons and allow for easy disinfecting of the station

**SPECIFICATIONS**

**Power Required:** 6.25mA @18V

**Weight:** 0.2 lbs (0.8 kg)

**Size:** **W:** 3.1" (8 cm)

**H:** 4.25" (10.8 cm)

**D:** 0.6" (1.5 cm) in backbox; 0.5" (1.5 cm) off-wall

**Housing & Finish:** High-impact molded Cycoloy 2950 UL 94-5VB; light grey faceplate

**Controls/Indicators:** One (1) Cancel button

**Terminations:** Plug-on connector

**Backbox Requirement:** 1 gang (Non-gangable), 3 1/2" Deep

**DESCRIPTION**

The Cancel Station can be programmed to cancel some or all call priorities placed from a room. The Cancel Station is used in situations where the cancel button on the patient station or button station is too difficult to reach. It is normally located by the door just inside the patient room. The Cancel Station is connected to its associated corridor light or room controller and is continually supervised.

*Architect and Engineer (A&E) Specifications available online at: [customerconnection.rauland.com](http://customerconnection.rauland.com)  
Specifications subject to change without notice*

©Copyright 2008 Rauland-Borg Corporation Printed in USA Rev 08/2008