

**MODEL: 354016 - BED MANAGEMENT STATION**



354016

## SPECIFICATIONS

**Power Required:** 9.2mA @18VDC

**Weight:** 0.3 lbs (0.1 kg)

**Size:** **W:** 4.7" (11.9 cm)

**H:** 4.25" (10.9 cm)

**D:** 0.6" (1.5 cm) in back box; 0.5" (1.3 cm) off-wall

**Housing & Finish:** High-impact molded Cyclopol 2950 UL 94-5VB; light grey faceplate

**Controls/Indicators:** Four (4) push button for call activation, Four (4) Call-assurance LEDs, One (1) Cancel button

## DESCRIPTION

The Bed Management Station provides four (4) distinct call-in priorities: "Transport", "Cleaning Needed", "Cleaning in Progress" and "Bed Ready". These buttons can be customized for other types of calls such as "STAT Clean". The Bed Management station is used to notify Transport when a patient has been discharged. The station is also used to notify Environmental Services that a room / bed needs to be cleaned as well as providing the state of cleaning by indicating that cleaning is in progress or the bed is ready for another patient to be admitted. Cancellation of each button can be initiated by pressing the button again; pressing the Cancel button or the next button in sequence (pressing "Cleaning in Progress" can cancel "Cleaning Needed"). The Four Button Status Station is connected to its associated corridor light or domeless room controller and is continually supervised.

## FEATURES

- Four (4) call-in buttons with call assurance LED's
- Large back-lit buttons for easier activation
- Plug-in connectors for easy service
- Continuous supervision of station
- Optional antimicrobial Bio-seal to cover buttons and allow for easy disinfecting of the station

**Terminations:** Plug-on connector

**Backbox Requirements:** 1 gang (Non-gangable), 3-1/2" Deep. Please note station trims to 2 gang faceplate dimensions. Allow mounting trim area.

Two isolated output points (on back panel) are available that can be tied to any two buttons to activate another device with a button push.

*Architect and Engineer (A&E) Specifications available online at: [customerconnection.rauland.com](http://customerconnection.rauland.com)  
Specifications subject to change without notice*

©Copyright 2008 Rauland-Borg Corporation Printed in USA Rev 08/2008

USA-Mt.Prospect, IL  
Canada  
[www.rauland.com](http://www.rauland.com)

• 800-752-7725  
• 905-607-2335

• Fax 800-217-0977  
• Fax 905-607-3554



**Rauland-Borg Corporation**