

SF101C Audible-Visual Room Station

IL366 Specification Sheet

Tek-CARE NC110 Nurse Call System • Rev. 14 - 4/2022

Features

- " Simple, push-button calling
- " Call-placed indicator
- Cancel push button
- Call activates lamp on annunciator panel and corridor light
- Flame retardant (UL[®] 94V-0) plastic faceplate
- Corridor zone light capability

Description

The SF101C Audible-Visual Room Station incorporates push-button operation of call and cancel functions. A call is registered at the annunciator panel and on a corridor light or corridor zone light (if installed) when the call switch with integral call-placed LED is pushed. The call-placed LED will also illuminate. Calls are canceled by simply depressing the cancel button. The call-placed LED will also be extinguished. All station components are mounted on a rugged UL[®] 94V-0 plastic faceplate.

Listings



UL[®] 1069 Listed; UL[®] File Number E71599.

Specifications

Dimensions:	4.5"H × 2.75"W × 1.75"D (114 mm × 69 mm × 44 mm)
Connections:	Plug-in connectors
Construction:	Flame retardant (UL [®] 94V-0) plastic faceplate. Switches and electronic components are circuit board mounted
Housing:	Single-gang ring, or single-gang ring with dual-gang box



SF101C Audible-Visual Room Station

Required Components

Tek-CARE[®] NC110 Nurse Call System