

## MODEL: NCCNCLST — CANCEL STATION



NCCNCLST



### FEATURES

- Allows caregiver to remotely cancel a call from a bedside station
- One (1) large tactile membrane cancel button
- RJ connector for easy installation and service
- Supervised by associated control station
- ESD protected

### SPECIFICATIONS

**Power Required:** 14V @ 0.1A

**Weight:** ½ lbs. (.23 kg)

**Size:** W: 2¾" (6.9 cm)

H: 4½" (11.4 cm)

D: 2" (5.1 cm)

**Housing & Finish:** High-impact molded ABS94VO;  
light gray faceplate and insert

**Controls:** One (1) cancel touchpoint

**Terminations:** RJ Connector

**Backbox Requirements:** Steel City 58371 3/4R, Raco 561,  
or UL recognized equivalent

**Certification:** UL/C-UL 1069

### DESCRIPTION

The NCCNCLST – Cancel Station allows remote canceling of certain calls placed from bedside stations. The NCCNCLST will mimic the canceling operation of the NCSRS3 Staff Registration Station/Tracer<sup>®</sup> IR Automatic Staff Registration in that it will cancel calls placed from Pillow Speakers and/or Call Cords and any service requirement set in a room. The cancel station is used in situations where the cancel button on the bedside station is too difficult to reach due to equipment in a room for general patient calls. All 'cord out' type calls will still need to be canceled by pressing the cancel button on the bedside station.

This type of station is normally located by the door just inside the patient room.

Use only one NCCNCLST Cancel station with each control station. This station cannot be used with a NCSRS3 Staff Registration station in the same room.

### ASSOCIATED EQUIPMENT

**NCBSS1** — Single Bedside Station

**NCBSD2** — Dual Bedside Station

**NCCSPLIT4** — 1 to 4 Sub-Station Splitter

*Architects and Engineers Specifications available on disk. Specifications subject to change without notice.*

## Rauland-Borg Corporation

3450 West Oakton Street • Skokie, IL 60076-2958 • (847) 679-0900 • (847) 679-4106 Fax • www.rauland.com  
In Canada: 4025 Sladeview Crescent, Units 4-6 • Mississauga, ON CANADA L5L 5Y1 • (905) 607-2335 • (905) 607-3554 Fax

