

MODEL: R4K2JACK - SLIM DUAL ¼" JACK STATION



R4K2JACK

FEATURES

- Two (2) inputs for call cord or dry contact auxiliary alarms with call-assurance LEDs and Monitor LED
- Compatible with various dry contact ¼" jack-compatible medical instruments
- Cancel button
- Annunciate medical equipment alarms on pocket pagers, wireless phones, consoles, etc
- Each input can be configured as momentary or latched
- Programmable delay of call in
- Continuous supervision of station
- Optional antimicrobial Bio-seal to cover cancel button and allow for easy disinfecting of the station
- Annunciates cord-out
- No dummy plug required
- With optional SLIM speaker module, can be used as dual bed station.

SPECIFICATIONS

Power Required: 22mA @15VDC

Power Required when used with SLIM Speaker Module: 25mA @ 15VDC

Weight: 0.2 lbs. (0.09 kg)

Size: W: 3.2" (8.10 cm)

H: 4.25" (10.8 cm)

D: 0.80" (2 cm) in back box: 0.5" (1.3 cm) off-wall

Housing and Finish: High-impact molded Cycloy 2950 UL 94-5VB; light grey faceplate

Controls/Indicators: Two (2) ¼" jacks, One (1)

Call-Assurance LED, and One (1) Call-Assurance/Monitor LED, and One (1) Cancel button

Terminations: Plug-on connector

Backbox Requirement: 1-gang, Non-gangable W: 2.25" (5.7 cm) H: 4" (10.2 cm) D: 3.5" (8.9 cm)

Backbox Requirement when used with SLIM Speaker

Module: 3-gang, Non-gangable W: 5.5" (14 cm) H: 3.75" (9.5 cm) D: 3.5" (8.9 cm)

Certification: UL/C-UL 1069, FCC Part 15 Class B, IEC60601-1-2, Designed for compliance to IEC60601-1 and CE Marking (MDD), FDA Registered, and RoHS Compliant

DESCRIPTION

The Responder® 4000 SLIM Dual ¼" Jack Station provides the ability to place two unique call priorities from a single station. The station is typically installed in patient rooms to monitor medical equipment that is routinely used. The Dual Jack Station sends an alarm when error is detected from patient monitoring equipment. It is designed to annunciate and display at a console, light up the room corridor light as well as directly alert caregivers carrying wireless devices. Each ¼" jack is supervised, so if a piece of equipment is unplugged a call will be placed.

When used in conjunction with optional Responder® 4000

SLIM Speaker Module, the station can be used as dual bed station with CC200 or equivalent ¼" Call Cords to place call-ins. Cord Out signal is provided when a call cord is removed from its jack. The LED by the left jack turns green or yellow, providing monitor function, when the speaker is active.

The Dual Jack Station is connected to its associated corridor light and is continually supervised for station presence. Through programming, a "Trouble" message can annunciate at the associated console(s) when the station is removed from the system.

*Architect and Engineer (A&E) Specifications available online at: customerconnection.rauland.com
Specifications subject to change without notice*

©Copyright 2009 Rauland-Borg Corporation Printed in USA Rev 03/2009

USA-Mt.Prospect, IL
Canada
www.rauland.com

• 800-752-7725
• 905-607-2335

• Fax 800-217-0977
• Fax 905-607-3554



Rauland-Borg Corporation