

MODEL: R5KAUDPC - Pull Cord Station with Audio



R5KAUDPC



FEATURES

- Pull-cord for easy activation
- Large, easy to grab bell
- Call-in button provides an additional call-in priority with built-in call-assurance LED
- Monitor LED and Call-Assurance LED with Cancel button
- Monitor LED indicates audio activation
- Cancel button for localized call cancellation
- Continuous supervision of station
- Plug-in connectors for easy service
- Optional Bio-seal to cover buttons and allow for easy disinfecting of the station
- Surface mount for easy installation
- Mounting design accommodates a variety of single and dual gang backboxes

SPECIFICATIONS

Power Required: 15VDC @ 20mA

Weight: 6.2 oz (175 g)

Size: W: 4.71" (11.97cm)

H: 4.31" (10.96 cm)

D: 1.013" (2.573 cm)

Housing and Finish: Polycarbonate ABS, UL 94-5VA; light gray faceplate

Controls/Indicators: One (1) pull cord for call actuation, One (1) Push button for call actuation, Two (2) Call - assurance LED, One (1) Monitor LED, One (1) Cancel button

Terminations: Plug on connector, CAT 5 and CAT 6 compatible

Backbox Requirements: Surface mountable; compatible with European, North American, South American single and dual gang boxes.

Certifications: Designed for compliance to ANSI/UL 1069, IEC 60950, CE, RoHS / WEEE Compliant. Assembled in a U.S. FDA Registered facility.

DESCRIPTION

The Pull Cord station with Audio is an emergency pull cord station that provides the ability to place a unique call-in priority from a single station by pulling on its cord. In addition, a call can be placed from the push button on the station that can be customized to a unique call-in priority to function as a routine call or an emergency call. The Pull Cord station with Audio contains a speaker so that caregivers can speak directly with the patient in the bathroom if desired. The Pull-Cord station is typically located in bathrooms near the toilet. The Cancel button allows for cancellation of the call at the station. Unit may utilize remote Cancel button(s) for ease of nurse call cancel when pull

cord is mounted in an inaccessible location (e.g. ceiling).

The Pull-Cord station is connected to its associated corridor light or domeless room controller and is continually supervised.