

MODEL: R5K SINGLE PATIENT STATION W LIGHTING & AUDIO



R5KPS1LCA



FEATURES

- Single bed station with backlit Call button
- Built-in lighting module interface
- One (1) DIN input for pillow speaker or call cord
- Provides voice communication to patient bedside through the station speaker
- Monitor LED and (2) Call Assurance LEDs
- Annunciates cord-out
- Cancel button for station or room-wide cancel function
- Optional antimicrobial Bio-seal to cover pushbuttons
- Continuous supervision for station presence
- Surface mount for easy installation
- Mounting design accommodates a variety of single and dual gang backboxes

SPECIFICATIONS

Power Requirements: 15.5V DC @ 31 mA

Weight: 152 g (5.3 oz)

Size: W: 11.97 cm (4.71")

H: 10.96 cm (4.31")

D: 2.38 cm (0.94")

Housing and Finish: Polycarbonate ABS, UL 94-5VA; light gray faceplate.

Controls/Indicators: One (1) Call button, One (1) DIN receptacle, Two (2) Call Assurance LEDs, One (1) Monitor LED, and One (1) Cancel button.

DESCRIPTION

The R5KPS1LCA is a single bed station that provides voice communication to the nurse call system. It also includes a built-in lighting control to interface to a lighting control module. In addition, a separate pushbutton allows for staff to place an emergency call to the assigned console(s). Nurse call audio is provided through the station speaker while entertainment audio is provided through the pillow speaker. The bed station can interface with call cords and entertainment speakers to initiate calls and provide entertainment control.

Backbox Requirement: Surface mountable; compatible with European, North American, South American single and dual gang boxes.

Terminations: Plug on connectors, CAT 5 and CAT 6 compatible

Certifications: Designed for compliance to ANSI/UL 1069, IEC 60950, CE, RoHS / WEEE Compliant. Assembled in a U.S. FDA Registered facility.

The bed station is connected to its associated corridor light or domeless controller and is continuously supervised for station presence. If the pillow speaker or call cord is removed from the station, a Cord Out call is immediately annunciated on the covering console(s). In addition, a "Trouble" message will also annunciate at the covering console(s) if the station is removed from the system or becomes non-functional.