



### WNC-CC Series Call Cords

The standard WNC-CC Series Call Cords feature molded construction with an impact proof switch. The 1/4" phone jack can be plugged in to either the Single Patient Bedside Station or the Dual Patient Bedside Station. The permanent stainless steel security clip is used to fasten the call cord to the patient's bedding for easy access. The specialty WNC-CC Series Call Cords are available for patients who are unable to press a standard button.

### Architects' and Engineers' Specifications

The call cord shall be a WNC-CC series or approved equal. It shall feature heavy duty molded construction and an impact proof switch. It shall connect to the WNC-B5 Single Patient Bedside Station and WNC-B52 Dual Patient Bedside Station via a 1/4" phone jack . It shall additionally provide a permanent stainless steel security clip in order to fasten the call cord to the patient's bedding for easy access. Pressing the standard call cord button or specialty cord surface shall activate a call information display at the Console(s) as well as activate the associated corridor light and corridor zone light if installed.

### Features

- Large contoured button is easy for patients to operate
- Switch provides tactile feedback and an audible click
- Safe for use in oxygen environments
- Permanent stainless steel security clip
- 1/4" IEA standard phone jack