



Architects' and Engineers' Specifications

The room station shall be a wireless WNC-BS2 dual bed station and shall include a "Call Placed" indicator LED, "Cancel" button and two 1/4" jacks for call cord, bed exit or ventilator alarm connection. Each jack shall provide a unique ID that when activated, shall be separately identified at the console. If the call switch is pressed on either call cord or a call cord is accidentally removed from its jack, an alarm call will be registered at the console, corridor lamp, corridor zone lamp (if installed), and the station's "Call Placed" LED light indicator. In new construction the station shall be housed in a Carlon A52171D deep 4/S plastic back box with single gang plastic mud ring.

System Components

<u>Model No.</u>	<u>Description</u>
PC Server	Video Display Console PC
MV400	400 Console Master
MV200	200 Console Master
WNC-CC	Call Cord, 1/4" plug, 8 ft. length

WNC-BS2 Bed Room Station

The WNC-BS2 dual patient bedside station includes a "Call Placed" indicator LED, "Cancel" button and two 1/4" jacks for call cord, bed exit or ventilator alarm connection. Each jack provided a unique ID that is separately identified at the console when activated by the patient call cord, bed exit or ventilator. A call from a Bed Room Station activates a call information display at the Display Console and activates the corridor lamp and corridor zone lamp (if installed). Other actions which will result in a display and light indication include the following: pressing the call cord button or accidental removal of the call cord from the jack on the panel.

Specification

- Dimensions: Height: 4-1/2" (114mm)
Width: 2-3/4" (69mm)
Depth: 2-5/8" (66mm)
- Panel: Flame retardant GE Lexan faceplate (UL flame rating 94V0)
- Batteries: Two CR123A Lithium batteries
- Backbox: Carlon A52171D deep 4/S plastic back box with single gang plastic mud ring
- Surface Mount: Wiremold 2344 single gang enclosure (2-3/4" deep)
- Flush Mount: Single gang BB10L Cooper B-Line bracket

Features

- Two unique ID numbers register Bed A and Bed B
- Simple push button calling
- Call Placed indicator
- Call-reset push button
- Call automatically registers if call cord is removed
- Call is displayed with patient or device name at console
- Call activates Corridor Lamp and Corridor Zone Lamp (if installed).