



B9Creations

Professional 3D Printing Solutions

B9 Scan 350 Quick Start Guide

Go to b9c.com/scanner-quickstart

Where you can...

- ✓ Schedule factory startup assistance
- ✓ Schedule application training

In the Box



- ✓ B9 Scan 350
- ✓ Cable Bag
- ✓ Accessory Kit:
 - Working Plate
 - Calibration Plate
 - Scanning Spray
 - Spray Removal Brush
 - Blue Tack
 - Drivers (DVD's)
 - Samples
 - 1 Solitaire
 - 1 Halo
 - 1 Non-Parallel Band
 - 1 Loose Gem Stone

First Steps To Scanning

1. Unbox, plug in & power on scanner
2. Run B9Up software
3. Register your product
 - Requires internet
 - Activates warranty
4. Run calibration

Calibration

1. Install the calibration plate in the scanner
2. Open B9Up/Tools/Calibration
3. Push OK
4. Calibration will be completed in 5 minutes and push OK again

The calibration plate serial number needs to match the scanner serial number. If the calibration plate is damaged or lost, your B9 Scan 350 will need to be returned to the original manufacturer. Calibration frequency depends on use and will be covered in startup training.

Disclaimers

Attention: Please read this document before attempting to use the B9 Scan 350.

1. Do not update the B9 Scan 350's Windows OS. Updating factory operating system will lead to system errors.
2. Caution! Do not spray emeralds or porous stones with the laser scanning spray. The spray cannot be removed from the stones.
3. Do not place any sensitive or private information on the B9 Scan 350. Technical support is provided through remote access by the manufacturer. A technical support agent will be able to access the scanner and all information on it.
4. Keep packaging in case of return.