


Perform the Print Calibration Procedure


1. Press the [Machine Status] button on the Control Panel. The Machine Status screen will be displayed on the Touch Screen.
2. Select the [Tools] tab.
3. Select the [Troubleshooting] button.





4. Select [Calibration], then [Print Calibration], and then select [Next].




5. Follow the on-screen instructions to run the Print Calibration procedure. Press NEXT to print the calibration pages. This will print THREE pages on A4 plain paper.



6. Load the THREE printed calibration pages into the Document feeder as per the arrows on the sheets as below and press NEXT. This will now run the calibration routine.



7. This will then print the comparison pages of before calibration and after calibration - if you are happy with the result select APPROVE.



8. The device will then show that calibration has been successful, once the success screen appears select CLOSE to exit calibration mode.

