



LS&S, LLC  
145 River Rock Dr  
Buffalo, NY 14207-2172

model # 101073



## HANDLING INSTRUCTIONS

798TE



## Operating instruction

### Functions description


Talking time, alarm with different sound for choosing, snooze, hourly chime .

### Battery renewal

Open the battery cover and put two new AAA batteries to right position.

### Mode exchange

Press MODE to change the functional modes according to the following direction:



### To set time

Starting from time display mode, press MODE to enter time setting mode. Press MIN, HR to adjust minutes and hours respectively to the appropriate alarm time.

### To set Alarm time

Starting from time display mode, press MODE twice to enter alarm setting mode. AL symbol will display with blinking numerals. Press MIN, HR to adjust minutes and hours respectively to the appropriate alarm time.

### Choose the alarm sound and turn on or off the alarm

In normal time display, press HR button to choose the alarm sound and turn on or off the alarm. When setting with alarm sound, it will play the alarm sound and the alarm time is shown on the display, the alarm function is on, after playing the alarm sound, it returns to the

normal time display. When setting without alarm sound, alarm function is off, then it play "Di".

### Turn on/off hourly announcement

Starting from time display mode, press MIN to activate (see symbol) or deactivate hourly announcement (no symbol).

### Snooze function

When the alarm sounds, press TALKING to stop the alarm and start the snooze function. The alarm will sound again every five minutes after the snooze starts. The alarm sound will happen not more than six times.

### Listen to the alarm sound

In normal time display mode, press and hold TALKING button. It will play the alarm sound after talking the current time.

### Remarks

- Avoid exposing the clock to extreme temperature, water or severe shock.
- Avoid contacting with chemical medicine.
- Don't subject the clock to these conditions of high temperature, excessive humidity, dust, shock.
- Only use the fresh batteries. Don't use the old batteries or mix old and new one.
- Only professional can remove or repair the clock.