

# DOOR BOTTOM

*Automatic, Handed*



## About Door Bottom Seals:

Pemko Door Bottom Seals consist of a variety of solutions for sealing a door to the threshold or floor surface.

## About Automatic Door Bottoms:

Pemko Automatic Door Bottoms consist of an aluminum case which surrounds a movable drop bar seal. The drop bar seal is actuated by a plunger which contacts the jamb as the door is closing, forcing the drop bar seal down against the floor or threshold. Automatic Door bottoms are frequently used when an automatic door bottom is required to close over carpet.

- Low closing force.
- Provide excellent seals to keep out draft, dust, moisture, insects, fumes, light and sound.
- End plates provided for all mounting applications.
- Slotted holes for adjustment.



Seals  
Bottom  
of Door


## Product / Available Finishes:

|        |                                                                             |
|--------|-----------------------------------------------------------------------------|
| 412BSL | Extruded Bronze [Brass] Anodized Aluminum with Black Sponge Silicone insert |
| 412CSL | Clear Anodized Aluminum with Black Sponge Silicone insert                   |
| 412DSL | Dark Bronze Anodized Aluminum with Black Sponge Silicone insert             |
| 412GSL | Gold Anodized Aluminum with Black Sponge Silicone insert                    |
| 412SSL | Clad Stainless Steel with Black Sponge Silicone insert                      |

## Testing/Ratings:




## Tools Required:



## Parts Included in End Cap Kit:

### PARTS INCLUDED IN END PLATE KIT:

| NUMBER | DESCRIPTION | QUANTITY |
|--------|-------------|----------|
| 1      | Fasteners   | 2        |
| 2      | End Cap     | 1        |



## Installation Instructions:

All models may be reversed for left-or-right hand installations. Disassembly and reassembly of the mechanism is required to reverse the handing.

**WARNING: You must determine the hand and reverse the mechanism (if required) prior to cutting down the unit to fit the door.**

**REVERSE HANDING** (See figure 1)

1. Remove the small anchoring screw on the back of the unit.
2. Slide out the drop bar and plunger assemblies together.
3. Replace these assemblies in the opposite end.
4. Line up the hole in the end anchor with the pre-drilled hole in the case.
5. Replace the anchoring screw.




Figure 1 - Reversing the Mechanism

## CUT / INSTALL ADB

1. Cut ADB 1/8" less than the distance between the stops (without cutting gasketing insert).


NOTE: When cutting, make sure that the drop bar is flush with the case on the plunger side and that the gasketing insert projects at least 1/8".

**WARNING: ADB less than 24" CAN ONLY be cut down by 1/2".**

**WARNING: ADB 24" and over should NOT be cut down more than 2".**

**WARNING: ADB should ONLY be cut from non-plunger side.**

2. Adjust and trim the gasketing insert so that it projects at least 1/16" at each end of the drop bar and case.
3. Place the ADB so that the plunger contacts the stop (see Figure 2).



4. Fasten with mounting screws provided.
  - a) The actuation plunger should be located on the hinge side of the door.
  - b) The bottom of the ADB case should be installed flush with the door bottom.
5. For wood jambs, a #10 x 1/2" flat head screw is furnished for installation at the point where the plunger contacts the jamb to prevent indenting.
6. Screw the actuating plunger in or out as required until the gasketing insert just touches the sealing surface when the door is closed.

NOTE: Adjustment range is 1/8" min - 3/4" max

NOTE: Start with the plunger screwed in completely to avoid over adjustment or damage.

**WARNING: Do not over adjust the plunger. It is only necessary to lightly compress the insert gaskets against the sealing surface to provide proper sealing. Over adjustment can cause internal component failure voiding the warranty!**

**WARNING: Do NOT use power tools to adjust the ADB!**
7. Further adjustments may be required for uneven surfaces.

## End Plate Installation Instructions:

**PLEASE READ THESE INSTRUCTIONS THOROUGHLY BEFORE ATTEMPTING TO INSTALL END PLATES.**

1. The automatic door bottom must be correctly installed and adjusted in accordance with the installation instructions furnished with this product (see other side).
2. Make sure that the drop bar (part that contains the seal) does not project beyond the end of the case when the actuation plunger is depressed. If it does project beyond the case, it was improperly trimmed in the field. This condition can be corrected by removing the unit and trimming the excess.

**NOTE: Under no condition should the drop bar project beyond the edge of the case.**

3. Install the flat end plate on the lock edge of the door with the fasteners provided.



**ASSA ABLOY**

ASSA ABLOY, the global leader  
in door opening solutions

**UNITED STATES:**

MEMPHIS, TN  
Ph: 800.824.3018  
Fax: 800.243.3656

VENTURA, CA  
Ph: 800.283.9988  
Fax: 800.283.4050

**CANADA:**

VANCOUVER, BC  
Ph: 877.535.7888  
Fax: 877.535.7444

TORONTO, ON  
Ph: 877.535.7888  
Fax: 877.535.7444

**[www.pemko.com](http://www.pemko.com)**

© 2013 Pemko Manufacturing Co.  
412\_SL\_WEBINS  
Rev 3 - 12.17.13