


IMPORTANT INFORMATION



Read these instructions and the safety and installation portions of the barbecue instructions before beginning insulating liner install.


Countertops and cabinet faces made of combustible material, such as wood, Formica, and Corian, can extend up against the outside walls of the panels and be joined to the metal trim (approximately a 1/8" space) by a bead of silicone rated for 400°F or higher, as shown in Fig. 1-1. Never build over the insulating liner with combustible materials, as this will interfere with the support hanger, which is attached to the slide-in barbecue.

CAUTION: Do not extend countertop or cabinet face materials beyond the outside wall of the liner panels. Seal the 1/8" space to the metal trim with silicone sealer.

DO NOT ALLOW THE SUPPORT HANGER TO COME IN CONTACT WITH THE COUNTERTOP OR ANY COMBUSTIBLE SURFACE.

Enclosures built of wood or other combustible materials must include the proper space for the insulating liner. A support shelf or ledge below the countertop is not needed to support the barbecue and insulating liner. The two support hangers provided will support the liner and barbecue. A minimum of a 20" airspace from combustible material is required directly below the insulating liner.

GAS REQUIREMENTS



A rigid 1/2" or 3/4" black steel pipe should be used to conduct the gas supply into the enclosure for connection to the barbecue. A minimum 1 3/8" diameter hole is required in the barbecue support shelf (if provided) at the rear left corner, set in 4" from the left side and 5" from the rear, to line up with the hole in the insulating liner (see Fig. 1-2). Use a CSA approved stainless steel flex connector to link the barbecue to the gas line.

Never use a rubber hose to connect to the barbecue.

For pipe connections, use joint compounds that are resistant to all gasses on all male pipe fittings. Tighten each joint securely. Do not use pipe joint compound on flare fittings.

Check all connections for leaks with a soapy water solution prior to use.

INSTALLATION

1. Position the rear support hanger 2" from the back of the cut-out and 1/2" down from the level of the countertop. Fasten securely in place with flat head screws (not provided) into the sides on the enclosure.
2. Position the front support hanger 3" from the front of the enclosure. Secure into place with flat head screws into the sides of the enclosure.

Note: If you already have a non-combustible lower support shelf, follow the detailed instructions above. However, you do not need to secure the support hangers to the enclosure.

3. Place the insulating liner on top of the support hangers (as shown in Fig. 2-1). Place the insulating liner tightly against the back of the cabinet opening.

BARBECUE MODEL	LINER MODEL	ROUGH CABINET OPENING A X B X C (depth) x (width) x (height)
DELUXE	3100-50	19 1/2" X 28 1/4" X 13"
CUSTOM I	3130-50	21 1/2" X 29 5/8" X 13"
CUSTOM II	3125-50	25 1/2" X 29 5/8" X 13"
REGAL I	3150-50	21 1/2" X 35 5/8" X 13"
REGAL II	3175-50	25 1/2" X 35 5/8" X 13"
MONARCH	3188-50	25 1/2" X 41 1/4" X 13"
ELITE	3189-50	28 1/2" X 53 5/8" X 13"
PWR BURNER	3278-50	21 1/2" X 22 3/4" X 13"
INFERNO BURNER	3287-50	24 7/8" X 18 1/4" X 13"

Dimensions shown (A, B, and C) are for cabinet openings for barbecue and liner. The dimensions do not include additional allowance for countertops or cabinet facings (see Fig. 2-1).

WARNING: Use this insulating liner only with the matching barbecue as indicated in **Table 1**.

To install and operate the Fire Magic barbecue, please refer to the installation and operating instructions and safety precautions shipped with the barbecue unit.

Table 1 - Barbecue models

Insulating liner




Fig. 2-1