

# SEIKO

DEDICATED TO PERFECTION

## Premium Collection Watch Catalogue

2011-2012





SEIKO History.....	4
The SEIKO Website.....	6
About this Guide.....	7
Water Resistance Usage.....	8
Abbreviations.....	9
Sportura.....	10
Premier.....	12
Velatura.....	16
Arctura.....	19
Coutura.....	20
Kinetic.....	24
Solar.....	25
Alarm Chronograph.....	29
FC Barcelona Special Edition.....	31
Chronograph.....	32
Perpetual Calendar.....	34
Divers.....	35
130th Anniversary Special Edition.....	37
Automatic.....	38
Mens 100m Bracelet.....	40
Mens 50m Bracelet.....	41
Mens Dress Bracelet.....	43
Mens Dress Strap.....	44
Solar.....	45
Ladies 100m Bracelet.....	49
Ladies 50m Bracelet.....	50
Ladies Dress Bracelet.....	52
Ladies Dress Strap.....	53
Stopwatches.....	54
Product Information Matrix.....	56
Product Information Matrix – Stopwatch.....	62
SEIKO Kinetic.....	64
Solar.....	65
Operating Instructions.....	66
Contacts.....	84
Service Information.....	85
SEIKO Corporate.....	86
Index.....	87



- 1881** K. Hattori, predecessor of today's Seiko Holdings Corporation, established.
- 1892** Seikosha clock supply factory established; production of wall clocks begins.  
Seikosha builds the first pocket watch.
- 1913** Production of Laurel, the first wristwatch made in Japan begins.
- 1953** SEIKO sponsors Japan's first TV commercial.
- 1959** SEIKO commercializes quartz clocks for broadcasting use.
- 1964** SEIKO develops the portable quartz chronometer and Seiko serves as Official Timer for the "Games of the XVIII Olympiad" held in Tokyo.

- 1968** SEIKO achieves the highest ever score in the Geneva competition and is awarded the "best mechanical wrist chronometer".
- 1969** Introduction of cal. 6139, the world's first automatic chronograph watch equipped with both vertical clutch and column wheel.  
Introduction of the world's first quartz watch, "SEIKO Quartz Astron" cal. 3500.
- 1982** Introduction of the world's first TV watch cal. T001.
- 1988** Introduction of the world's first "Auto Quartz" watch cal. 7M42. (later renamed as "Kinetic").
- 1992** Introduction of 1/100th analogue quartz chronograph watch cal. 7T59.



**1999** Introduction of the world's first Spring Drive watch cal. 7R68 (hand winding).  
Introduction of the Ultimate Kinetic Chronograph cal. 9T82.

**2005** Introduction of the Kinetic Perpetual cal. 7D48.  
Introduction of the Spring Drive cal. 5R series (automatic winding).

**2006** Introduction of the world's first watch with electrophoresis display module cal. G510.  
Introduction of the Credor Spring Drive Sonnerie cal. 7R06.  
Suggested retail price: 15 million Japanese Yen.

**2007** Introduction of the Kinetic Direct Drive cal. 5D44.

Introduction of the Spring Drive Chronograph cal. 5R86 equipped with both vertical clutch and column wheel.

**2009** Introduction of the Chronograph Perpetual.

**2010** World's first EPD watch with an active matrix system.

**2011** SEIKO's 130th Anniversary

Served as Official Timer of the IAAF World Championships Daegu 2011.

The SEIKO website is designed to provide customers, retailers and consumers with instant access to information about SEIKO. Log onto [www.seiko.co.nz](http://www.seiko.co.nz) and click the following links to find out all there is to know about the world's leading watch manufacturer.

**Products** – Learn more about the SEIKO Premium Collection or explore the entire SEIKO product range.

**Support** – Designed with retailers in mind, this section provides service information, instruction manuals you can download and 'frequently asked questions' to aid in trouble shooting, procedures for sending back repairs for prompt and efficient service.

**About Us** – Discover SEIKO's history from humble beginnings in 1881 and the rise that carried SEIKO to new heights and international renown. Learn about corporate structure, global networks and SEIKO's extensive involvement in sports timing.

**Corporate** – This section outlines specialised services that include the printing of company logos on the dial of a watch or clock, engraving and personalised messages, as well as customised packaging and more.







SEIKO will continue to grow and evolve and so too will [www.seiko.co.nz](http://www.seiko.co.nz), so keep checking for regular updates.

Please send any comments you have to [info@seiko.co.nz](mailto:info@seiko.co.nz), all feedback is welcome.

**[www.seiko.co.nz](http://www.seiko.co.nz)**

BELOW ARE THE ABBREVIATIONS AND SYMBOLS YOU WILL FIND IN THIS CATALOGUE



- ADVERTISED MODEL** — Advertised model
-  — Solar
-  — New release model
-  — Stainless steel case
-  — Water resistance
-  — Titanium
-  — Mines approved

**SSC009P \$825** — Reference number and price

SOLAR ALARM CHRONOGRAPH — Watch type



SSWR (10BAR) XL — Case material (refer to Abbreviations page)

HARDEX GLASS — Glass type

M0FP218J0 — Band reference

V172 — Calibre Number

## WATER RESISTANCE USAGE

							
EVERYDAY LIFE (International Standard ISO 2281) Recommended Usage							
Splash Resistant	●	●	●	●	●	●	●
Rain Resistant	●	●	●	●	●	●	●
SWIMMING/WATERSPORTS (International Standard ISO 2281) Recommended Usage							
Water-related Work		●	●	●	●	●	●
Swimming		●	●	●	●	●	●
Watersports (Snorkelling, Surfing, etc)			●	●	●	●	●
DIVING (International Standard ISO 6425) Recommended Usage							
Scuba Diving						●	●
Saturation Diving							●



<b>AHC</b>	All Hard Coat case and back
<b>ASG</b>	All SEIKO Gold Plated case
<b>ALSGP</b>	All Light SEIKO Gold Colour Plated case
<b>ATI</b>	All Titanium case
<b>CE</b>	Ceramics
<b>FRP</b>	Fibre Reinforced Plastic
<b>GPDP</b>	Combined SGP and PDP middle with bezel and SS back
<b>GPHC</b>	Combined SGP and HC middle with bezel and SS back
<b>HC</b>	Hard Coating SS middle with bezel and SS back
<b>HC.SSHC</b>	HC bezel and middle with combined SS and HC back
<b>HGC</b>	Hard Gold Coating middle with bezel and SS back
<b>LSGP</b>	Light colour SGP
<b>MHC</b>	HC middle with SS bezel and back
<b>MSSGP</b>	SS bezel, combined SS and SGP middle and SS back
<b>MSSPCD</b>	SS bezel combined SS and plastic middle with SS back
<b>MSS.HC</b>	SS middle with HC bezel and back
<b>PDP</b>	Palladium plated middle with bezel and SS back
<b>SGP</b>	SEIKO Gold Colour Plate and Stainless Steel back
<b>SS</b>	Stainless Steel case
<b>SSGP</b>	Combined SS and SGP middle with bezel and SS back
<b>SSHC</b>	Combined SS and HC middle with bezel and SS back
<b>TGP.MGPHC</b>	SGP bezel, SGP and HC middle and SS back
<b>TGP.MSSGP</b>	SGP bezel, combined SS and SGP middle and SS back
<b>TGPDP</b>	Combined SGP and PDP bezel, SS middle and SS back
<b>TGPTI.TI</b>	Combined TI and SGP bezel, TI middle and TI back
<b>THC</b>	HC bezel, SS middle and SS back
<b>THC.BTI</b>	HC bezel, BTI (Bright Titanium) middle and BTI back
<b>THC.MHCPCDP</b>	HC bezel, combined HC and plastic middle with SS back
<b>THC.TIHCCE</b>	CE Outer Case, TI HC Inner Case
<b>THGMCETIHG</b>	HGC bezel, combined Ceramics, TI and HGC middle and combined Ceramics, TI and HGC back
<b>TI</b>	Titanium
<b>TPDP</b>	PDP bezel, SS middle and SS back
<b>TSGP</b>	Combined SS and SGP case and SS back
<b>TSSGP</b>	Combined SS and SGP bezel, SS middle and SS back
<b>TSSHC</b>	Combined SS and HC bezel, SS middle and SS back
<b>TTIHC.MTIHCDC.TI</b>	Ti & HC bezel, Ti & HC middle, Ti Back
<b>TTIHC.TI</b>	Combined TI and HC bezel, TI middle and TI back
<b>WR</b>	Water Resistant
<b>XL</b>	Lumibrite hands and hour markers



**SNAE75P \$1200**



ALARM CHRONOGRAPH, TSSHCWR, (10BAR), XL, SAPPHIRE GLASS,  
SPECIAL EDITION FC BARCELONA, SCREW DOWN CROWN,  
L01M013J0, 7T62



## KINETIC

Powered by the movement of the wearer. 6 month power storage with power reserve indicator.



**SKA511P \$1300**



KINETIC, THCWR, (20BAR) DIVERS, XL, SAPPHIRE GLASS,  
ONE WAY ROTATING BEZEL, SCREW DOWN CROWN & BUTTON,  
M0ND224J0, 5M62



**SKA511P-2 \$1250**



KINETIC, THCWR, (20BAR) DIVERS, XL, SAPPHIRE GLASS,  
ONE WAY ROTATING BEZEL, SCREW DOWN CROWN & BUTTON,  
R00F011J0, 5M62

## ALARM CHRONOGRAPH


Stopwatch measures 60 minutes in 1/5th of a second increments with split time facility. 12-hourly alarm. Dual time capability.



**SNAE69P \$999**



ALARM CHRONOGRAPH, TSSHCWR, (10BAR), XL, SAPPHIRE GLASS,  
SCREW DOWN CROWN,  
M0ND111J0, 7T62



**SNAE63P \$999**



ALARM CHRONOGRAPH, TSSHCWR, (10BAR), XL, SAPPHIRE GLASS,  
SCREW DOWN CROWN,  
M0ND111J0, 7T62



**SNAE67P \$999**



ALARM CHRONOGRAPH, TSSHC.HCWR, (10BAR), XL,  
SAPPHIRE GLASS, SCREW DOWN CROWN,  
L01M012M0, 7T62



KINETIC PERPETUAL

Powered by the movement of the wearer. 4 year power storage. Kinetic Perpetual goes to sleep after 24 hours of inactivity to awake within 4 years and automatically relay to the correct time. Perpetual Calendar adjusts automatically until February 2100, including leap years and short months. 24-hour hand, and months and leap year indicator.



**SNP042P \$1800**   
KINETIC PERPETUAL, TSGPWR, (10BAR), SAPPHIRE GLASS,  
MONB111C0, 7D48



**SNP041P \$1700**   
KINETIC PERPETUAL, SSWR, (10BAR), SAPPHIRE GLASS,  
MONB111J0, 7D48



**SNP039P \$1700**   
KINETIC PERPETUAL, SSWR, (10BAR), SAPPHIRE GLASS,  
MONB111J0, 7D48



**SNP044P \$1800**   
KINETIC PERPETUAL, ASGPWR, (10BAR), SAPPHIRE GLASS,  
L01J012K0, 7D48

KINETIC DIRECT DRIVE MOON PHASE

Powered by the movement of the wearer or by hand winding. 30 day power storage. Moon Phase, Calendar, Day of the week, 24 hour, and power reserve indicators.



**SRX003P \$2250**   
KINETIC DIRECT DRIVE MOON PHASE, SSWR (10BAR),  
SAPPHIRE GLASS,  
4A072JL, 5D88



**SRX004P \$2450**   
KINETIC DIRECT DRIVE MOON PHASE, SGPWR (10BAR),  
SAPPHIRE GLASS,  
4A071KL, 5D88

## AUTOMATIC OPEN HEART

Powered by the movement of the wearer, or by hand winding. 41 hour power reserve. 24-hour indicator. Semi-skeleton dial revealing the 'heart' of the watch.



**SSA024J \$1300**



AUTOMATIC, TSGPWR, (10BAR), XL, SAPPHIRE GLASS,  
M0NB111C0, 4R39



**SSA023J-2 \$1200**



AUTOMATIC, SSWR, (10BAR), XL, SAPPHIRE GLASS,  
L01J011J0, 4R39

## BIG CALENDAR CHRONOGRAPH

Stop watch measures 60 minutes in 1/5th of a second increments. Calendar. 24 hour hand.



**SPC058P \$1200**



CHRONOGRAPH, SSGPWR, (10BAR), SAPPHIRE GLASS,  
4A081LM, 7T04



**SPC057P \$1025**



CHRONOGRAPH, SSWR, (10BAR), SAPPHIRE GLASS,  
4A081JM, 7T04

## ANALOGUE

### – SMALL SECONDS DIAL

Hour and minute hand, with special seconds sub-dial.



**SRK021P \$775**



ANALOGUE, SSWR, (10BAR), SAPPHIRE GLASS,  
4A081JM, 6G28



PERPETUAL CALENDAR

Perpetual Calendar adjusts automatically until February 2100, including leap years and short months.



**SNQ116P \$850**    
PERPETUAL CALENDAR, SSGPWR, (10BAR), SAPPHIRE GLASS,  
4A081LM, 6A32



**SNQ117P \$775**    
PERPETUAL CALENDAR, SSWR, (10BAR), SAPPHIRE GLASS,  
4A081JM, 6A32



**SNQ118P \$850**    
PERPETUAL CALENDAR, ASGPWR, (10BAR), SAPPHIRE GLASS,  
4A071JM, 6A32

## ANALOGUE

Hour, minute and second hand. Calendar.



ADVERTISED MODEL

**SXDE02P \$850**ANALOGUE, TSGPWR, (10BAR), SAPPHIRE GLASS,  
MONE111C0, 7N82**SXDE04P \$899**ANALOGUE, ASGPWR, (10BAR), SAPPHIRE GLASS,  
MONE111K0, 7N82

## ANALOGUE – SMALL SECONDS DIAL

Hour and minute hand, with special seconds sub-dial.

**SRKZ86P \$1495**ANALOGUE, TSSGPWR, (10BAR), SAPPHIRE GLASS, 30 DIAMONDS,  
MOTHER OF PEARL DIAL, CABOCHON CROWN,  
30061LM, 6G28**SRKZ93P \$1395**ANALOGUE, SSWR, (10BAR), SAPPHIRE GLASS, 30 DIAMONDS,  
MOTHER OF PEARL DIAL, CABOCHON CROWN,  
30061JM, 6G28**SRKZ96P \$925**ANALOGUE, TSGPWR, (10BAR), SAPPHIRE GLASS,  
CABOCHON CROWN,  
30061LM, 6G28



### KINETIC DIRECT DRIVE

Powered by the movement of the wearer or by hand winding. 30 day power storage. Date and day of week.





**SRH006P \$2250**    
KINETIC DIRECT DRIVE, THC.MGPWR, (10BAR), XL, SAPPHIRE GLASS,  
4LJ7KB, 5D44

### CHRONOGRAPH

Stopwatch measures 12 hours in 1/20th of a second increments with split time facility. Calendar.




**SNDA59P \$1795**    
CHRONOGRAPH, THCWR, (20BAR), DIVERS, XL, SAPPHIRE GLASS,  
SCREW DOWN CROWN AND BUTTONS, ONE WAY ROTATING BEZEL,  
4A291JT, 7T92

### YACHTING TIMER

Stopwatch measures 12 hours in 1/5th of a second increments with split time. Preset Countdown Timers for 5, 6, & 10 minutes. Manual Set Countdown Timer up to 15 minutes. Automatic Start Stopwatch function after timer reaches zero. 2 Alarms – Single Time Alarm - one off 12 hour alarm. Regular Alarm – will sound at the same time everyday within a 24 hour period. Dual Time Capability.



**SPC049P \$1995**    
YACHTING TIMER, TTHC.MTIHICDC.TIWR, (20BAR), XL,  
SAPPHIRE GLASS, SCREW DOWN CROWN,  
4A0X1ML, 7T84



## ALARM CHRONOGRAPH

Stopwatch measures 60 minutes in 1/5th of a second increments with split time facility. 12-hourly alarm. Dual time capability.

**SNAE19P \$1350**

ALARM CHRONOGRAPH, THCWR, (10BAR), XL, SAPPHIRE GLASS,  
35L9JB, 7T62

**SNAE21P \$1400**

ALARM CHRONOGRAPH, TSS.MHCWR, (10BAR), XL,  
SAPPHIRE GLASS,  
35M0JB, 7T62

**SNAE17P \$1250**

ALARM CHRONOGRAPH, HCWR, (10BAR), XL, SAPPHIRE GLASS,  
SPECIAL EDITION 49'ER CLASS,  
ALJ7MB, 7T62

**SNAA93P \$1350**

ALARM CHRONOGRAPH, THCWR, (10BAR), XL, SAPPHIRE GLASS,  
35M0JB, 7T62

**SNAA92P \$1350**

ALARM CHRONOGRAPH, MSSGPWR, (10BAR), XL, SAPPHIRE GLASS,  
35L9LB, 7T62

**SNAA93P-2 \$1200**

ALARM CHRONOGRAPH, THCWR, (10BAR), XL, SAPPHIRE GLASS,  
4LT7JB, 7T62

# CHRONOGRAPH

Stopwatch measures 12 hours in 1/20th of a second increments with split time facility. Calendar.



**SNDZ38P \$2150**



CHRONOGRAPH, TSSGPWR, (10BAR), XL, SAPPHIRE GLASS,  
53 DIAMONDS, MOTHER OF PEARL DIAL,  
4A551LM, 7T92



**SNDZ37P \$2050**



CHRONOGRAPH, SSWR, (10BAR), XL, SAPPHIRE GLASS,  
53 DIAMONDS, MOTHER OF PEARL DIAL,  
4A551JM, 7T92



**SNDZ40P \$1395**



CHRONOGRAPH, TSSGPWR, (10BAR), XL, SAPPHIRE GLASS,  
11 DIAMONDS, MOTHER OF PEARL DIAL,  
4A551LM, 7T92

# ANALOGUE

Hour, minute and second hand. Calendar.



**SXDA20P \$1450**



ANALOGUE, TSSGPWR, (10BAR), XL, SAPPHIRE GLASS,  
36 DIAMONDS, MOTHER OF PEARL DIAL,  
35M6LB, 7N82



**SXDA19P \$1350**



ANALOGUE, SSWR, (10BAR), XL, SAPPHIRE GLASS,  
36 DIAMONDS, MOTHER OF PEARL DIAL,  
35M6JB, 7N82

## KINETIC PERPETUAL

Powered by the movement of the wearer. 4 year power storage. Kinetic Perpetual goes to sleep after 24 hours of inactivity to awake within 4 years and automatically relay to the correct time. Perpetual Calendar adjusts automatically until February 2100, including leap years and short months. 24-hour hand, and months and leap year indicator.



**SNP029P \$1750**



KINETIC PERPETUAL, SSWR (10BAR), XL, SAPPHIRE GLASS,  
4A571JM, 7D48

## KINETIC CHRONOGRAPH

Powered by the movement of the wearer. 5 month power storage. Stopwatch measures 45 minutes in 1/5th of a second increments. Calendar.



**SNL045P \$1650**



KINETIC CHRONOGRAPH, SSWR, (10BAR), XL, SAPPHIRE GLASS,  
4A571JM, 7L22

## ALARM CHRONOGRAPH

Stopwatch measures 60 minutes in 1/5th of a second increments with split time facility. 12-hourly alarm. Dual time capability.



**SNAD11P \$1350**



ALARM CHRONOGRAPH, HC.SSHCWR (10BAR), XL, SAPPHIRE GLASS,  
4A571MM, 7T62



**SNAD10P \$1350**



ALARM CHRONOGRAPH, SGPWR (10BAR), XL, SAPPHIRE GLASS,  
4A581PT, 7T62



## KINETIC PERPETUAL

Powered by the movement of the wearer. 4 year power storage. Kinetic Perpetual goes to sleep after 24 hours of inactivity to awake within 4 years and automatically relay to the correct time. Perpetual Calendar adjusts automatically until February 2100, including leap years and short months. 24-hour hand, and months and leap year indicator.



**SNP017P-9 \$1550**




KINETIC PERPETUAL, HCWR, (10BAR), XL, SAPPHIRE GLASS, CABOCHON CROWN, 35X6VB, 7D46



**SNP008P-9 \$1350**



KINETIC PERPETUAL, SSGPWR, (10BAR), XL, SAPPHIRE GLASS, CABOCHON CROWN, 34P0XB, 7D48



**SNP007P-9 \$1250**



KINETIC PERPETUAL, SSWR, (10BAR), XL, SAPPHIRE GLASS, CABOCHON CROWN, 34P0ZB, 7D48

## PERPETUAL CALENDAR


Perpetual Calendar adjusts automatically until February 2100, including leap years and short months.



**SNQ124P \$850**



PERPETUAL CALENDAR, TSSGPWR (10BAR), XL, SAPPHIRE GLASS, CABOCHON CROWN, M0NG111C0, 6A32  
MATCHING MODEL No. SXDC92P




**SNQ123P \$775**




PERPETUAL CALENDAR, SSWR (10BAR), XL, SAPPHIRE GLASS, CABOCHON CROWN, M0NG111J0, 6A32

## ALARM CHRONOGRAPH

Stopwatch measures 60 minutes in 1/5th of a second increments with split time facility. 12-hourly alarm. Dual time capability.

**SNAE70P \$1150**


ALARM CHRONOGRAPH, TGPHC.MHCVR, (10BAR), XL, SAPPHIRE GLASS, CABOCHON CROWN, M0NG112D0, 7T62

**SNAE57P-9 \$1100**


ALARM CHRONOGRAPH, TSSHCVR, (10BAR), XL, SAPPHIRE GLASS, CABOCHON CROWN, M0NG112E9, 7T62

**SNAE56P-9 \$999**

ALARM CHRONOGRAPH, TSSGPWR, (10BAR), XL, SAPPHIRE GLASS, CABOCHON CROWN, M0NG111C9, 7T62

**SNAE74P \$999**

ALARM CHRONOGRAPH, TSSGPWR, (10BAR), XL, SAPPHIRE GLASS, CABOCHON CROWN, M0NG111C0, 7T62

**SNAE73P \$899**

ALARM CHRONOGRAPH, SSWR, (10BAR), XL, SAPPHIRE GLASS, CABOCHON CROWN, M0NG111J0, 7T62

**SNAE34P \$999**

ALARM CHRONOGRAPH, TGPHCVR, (10BAR), XL, SAPPHIRE GLASS, CABOCHON CROWN, 34D6NB, 7T62

## ANALOGUE

Hour, minute and second hand. Calendar.



**SGED96P-9 \$775**



ANALOGUE, HCWR, (10BAR), XL, SAPPHIRE GLASS,  
CABOCHON CROWN, 35R7VB, 7N42  
MATCHING MODEL No. SXDA50P-9



**SGEB76P-9 \$625**




ANALOGUE, TSSGPWR, (10BAR), XL, SAPPHIRE GLASS,  
CABOCHON CROWN, 34D6XB, 7N42

## ANALOGUE

Hour, minute and second hand. Calendar.

**SXDE20P \$1100**


ANALOGUE, TSSGPWR, (10BAR), XL, SAPPHIRE GLASS,  
16 DIAMONDS, MOTHER OF PEARL DIAL, CABOCHON CROWN,  
M0NH111C0, 7N82

**SXDE19P \$995**


ANALOGUE, SSWR, (10BAR), XL, SAPPHIRE GLASS,  
16 DIAMONDS, MOTHER OF PEARL DIAL, CABOCHON CROWN,  
M0NH111J0, 7N82

**SXDE06P \$799**

ANALOGUE, TSGPHCWR, (10BAR), XL, SAPPHIRE GLASS,  
CABOCHON CROWN, M0NH112D0, 7N82

**SXDC94P \$825**

ANALOGUE, SGPWR, (10BAR), XL, SAPPHIRE GLASS,  
MOTHER OF PEARL DIAL, CABOCHON CROWN,  
M0NH111K0, 7N82

**SXDC92P \$799**

ANALOGUE, TSSGPWR, (10BAR), XL, SAPPHIRE GLASS,  
MOTHER OF PEARL DIAL, CABOCHON CROWN,  
M0NH111C0, 7N82  
MATCHING MODEL No. SNQ124P

**SXDE07P \$725**

ANALOGUE, SSWR, (10BAR), XL, SAPPHIRE GLASS,  
MOTHER OF PEARL DIAL, CABOCHON CROWN,  
M0NH111J0, 7N82

**SXDA48P-9 \$1295**

ANALOGUE, HCWR, (10BAR), XL, SAPPHIRE GLASS,  
CABOCHON CROWN, 20 DIAMONDS,  
35R8VB, 7N82

**SXDA50P-9 \$725**

ANALOGUE, HCWR, (10BAR), XL, SAPPHIRE GLASS,  
CABOCHON CROWN, 35R8VB, 7N82  
MATCHING MODEL No. SGDE96P-9




## KINETIC


Powered by the movement of the wearer. 6 month power storage with power reserve indicator.

**SKA371P \$875**

KINETIC, SSWR, (20BAR), DIVERS, XL, HARDEX GLASS,  
ONE WAY ROTATING BEZEL, SCREW DOWN CROWN,  
35J5JG, 5M62

**SKA371P-2 \$825**

KINETIC, SSWR, (20BAR), DIVERS, XL, HARDEX GLASS,  
ONE WAY ROTATING BEZEL, SCREW DOWN CROWN,  
4KR3JZ, 5M62

**SKA505P \$699**

KINETIC, THCWR, (10BAR), XL, HARDEX GLASS,  
M04P129J0, 5M62

**SKA489P \$599**

KINETIC, SSWR, (10BAR), HARDEX GLASS,  
M0GW111J0, 5M62

**SKA490P \$699**

KINETIC, TSGPWR, (10BAR), HARDEX GLASS,  
M0GW111C0, 5M62

**SKA465P \$650**

KINETIC, HCWR, (10BAR), XL, HARDEX GLASS,  
EXHIBITION CASE BACK,  
4A4N2MM, 5M62


**SKA463P \$550**

KINETIC, SSWR, (10BAR), XL, HARDEX GLASS,  
EXHIBITION CASE BACK,  
4A4N1JM, 5M62



## SOLAR ALARM CHRONOGRAPH


Powered by all light sources. 6 month power reserve. Stopwatch measures 60 minutes in 1/5th of a second increments with split time facility. 12-hourly alarm. Dual time capability.



SSC008P-2 \$950



SOLAR ALARM CHRONOGRAPH, SGPWR, (10BAR), XL,  
HARDLEX GLASS, ROTATING BEZEL, SLIDE RULE,  
MOFP218K0, V172



SSC011P \$899




SOLAR ALARM CHRONOGRAPH, SSWR, (10BAR), XL,  
HARDLEX GLASS, ROTATING BEZEL, SLIDE RULE,  
MOFP218C0, V172



SSC009P \$825




SOLAR ALARM CHRONOGRAPH, SSWR, (10BAR), XL,  
HARDLEX GLASS, ROTATING BEZEL, SLIDE RULE,  
MOFP218J0, V172



SSC009P-3 \$750



SOLAR ALARM CHRONOGRAPH, SSWR, (10BAR), XL,  
HARDLEX GLASS, ROTATING BEZEL, SLIDE RULE,  
L020012J0, V172



SSC013P \$750




SOLAR ALARM CHRONOGRAPH, SSWR, (10BAR), XL,  
HARDLEX GLASS, ROTATING BEZEL, SLIDE RULE,  
L020011J0, V172



SSC002P \$750



SOLAR ALARM CHRONOGRAPH, SSGPWR, (10BAR), XL,  
HARDLEX GLASS,  
M0BN211C0, V172



SSC003P \$650



SOLAR ALARM CHRONOGRAPH, SSWR, (10BAR), XL,  
HARDLEX GLASS,  
M0BN211J0, V172



SSC005P \$650



SOLAR ALARM CHRONOGRAPH, SSWR, (10BAR), XL,  
HARDLEX GLASS,  
M0BN211J0, V172

## SOLAR ANALOGUE

Powered by all light sources. 10 month power reserve. Instant start and low energy warning functions.

**SNE107P \$725**


SOLAR, SSWR, (20BAR) DIVERS, ONE WAY ROTATING BEZEL,  
SCREW DOWN CROWN, XL, HARDEX GLASS,  
M0FCC237J0, V158

**SNE107P-2 \$625**

SOLAR, SSWR, (20BAR) DIVERS, ONE WAY ROTATING BEZEL,  
SCREW DOWN CROWN, XL, HARDEX GLASS,  
DA3H1JR, V158

**SNE109P \$625**


SOLAR, SSWR, (20BAR) DIVERS, ONE WAY ROTATING BEZEL,  
SCREW DOWN CROWN, XL, HARDEX GLASS,  
DA3H1JR, V158

**SNE094P \$475**

SOLAR, SSGPWR, (10BAR), XL, HARDEX GLASS,  
M0C1111C0, V158

**SNE098P-9 \$475**

SOLAR, SSGPWR, (10BAR), XL, HARDEX GLASS,  
35C4XZ, V158

**SNE095P \$395**

SOLAR, SSWR, (10BAR), XL, HARDEX GLASS,  
35C4JZ, V158

**SNE093P \$395**

SOLAR, SSWR, (10BAR), XL, HARDEX GLASS,  
35C4JZ, V158



## SOLAR

Powered by all light sources. 10 month power reserve. Instant start and low energy warning functions.

**SNE090P \$550**


SOLAR, SGPWR, (10BAR), XL, HARDLEX GLASS,  
M0FE211K0, V157  
MATCHING MODEL No. SUT024P

**SNE088P \$525**

SOLAR, SSGPWR, (10BAR), XL, HARDLEX GLASS,  
M0FE211C0, V157  
MATCHING MODEL No. SUT022P

**SNE087P \$450**

SOLAR, SSWR, (10BAR), XL, HARDLEX GLASS,  
M0FE211J0, V157

**SNE134P \$625**

SOLAR, SGPWR, (10BAR), HARDLEX GLASS,  
M02M211K0, V157  
MATCHING MODEL No. SUT046P

**SNE132P \$599**

SOLAR, TSGPWR, (10BAR), HARDLEX GLASS,  
M02M211K0, V157  
MATCHING MODEL No. SUT044P

**SNE121P \$525**

SOLAR, SSWR, (10BAR), HARDLEX GLASS,  
M02M211J0, V157

**SNE131P \$525**

SOLAR, SSWR, (10BAR), HARDLEX GLASS,  
M02M211J0, V157  
MATCHING MODEL No. SUT043P

**SNE125P-9 \$625**

SOLAR, THCWR, (10BAR), HARDLEX GLASS,  
M02M212E9, V157  
MATCHING MODEL No. SUT041P-9

**SNE124P-9 \$599**

SOLAR, TSGPWR, (10BAR), HARDLEX GLASS,  
M02M217C9, V157  
MATCHING MODEL No. SUT040P-9

## SOLAR

Powered by all light sources.

SNE Series – 10 month power reserve. Instant start and low energy warning functions.

SUP Series – 12 month power reserve.



**SNE138P \$550**

SOLAR, SGPWR, (5BAR), HARDLEX GLASS,  
M0D7211K0, V157



**SNE128P-9 \$525**

SOLAR, TSGPWR, (5BAR), HARDLEX GLASS,  
M0D7211C9, V157



**SNE127P \$475**

SOLAR, SSWR, (5BAR), HARDLEX GLASS,  
M0D7211J0, V157



**SUP892P \$575**

SOLAR, SGPWR, (5BAR), HARDLEX GLASS,  
M0GW211K0, V115  
MATCHING MODEL No. SUP080P



**SUP893P \$550**

SOLAR, SSWR, (5BAR), HARDLEX GLASS,  
M0GW211K0, V115  
MATCHING MODEL No. SUP079P



## SOLAR ALARM CHRONOGRAPH

Powered by all light sources. 6 month power reserve. Stopwatch measures 60 minutes in 1/5th of a second increments with split time facility. 12-hourly alarm. Dual time capability.



**SSC008P-2 \$950**



SOLAR ALARM CHRONOGRAPH, SGPWR, (10BAR), XL,  
HARDLEX GLASS, ROTATING BEZEL, SLIDE RULE,  
MOFP218K0, V172



**SSC011P \$899**



SOLAR ALARM CHRONOGRAPH, SSWR, (10BAR), XL,  
HARDLEX GLASS, ROTATING BEZEL, SLIDE RULE,  
MOFP218C0, V172



**SSC009P \$825**



SOLAR ALARM CHRONOGRAPH, SSWR, (10BAR), XL,  
HARDLEX GLASS, ROTATING BEZEL, SLIDE RULE,  
MOFP218J0, V172



**SSC009P-3 \$750**



SOLAR ALARM CHRONOGRAPH, SSWR, (10BAR), XL,  
HARDLEX GLASS, ROTATING BEZEL, SLIDE RULE,  
LO20012J0, V172



**SSC013P \$750**



SOLAR ALARM CHRONOGRAPH, SSWR, (10BAR), XL,  
HARDLEX GLASS, ROTATING BEZEL, SLIDE RULE,  
LO20011J0, V172



**SSC002P \$750**



SOLAR ALARM CHRONOGRAPH, SSGPWR, (10BAR), XL,  
HARDLEX GLASS,  
MOBN211C0, V172



**SSC003P \$650**



SOLAR ALARM CHRONOGRAPH, SSWR, (10BAR), XL,  
HARDLEX GLASS,  
MOBN211J0, V172



**SSC005P \$650**



SOLAR ALARM CHRONOGRAPH, SSWR, (10BAR), XL,  
HARDLEX GLASS,  
MOBN211J0, V172




## ALARM CHRONOGRAPH

Stopwatch measures 60 minutes in 1/5th of a second increments with split time facility. 12-hourly alarm. Dual time capability.

**SNAE32P \$875**

ALARM CHRONOGRAPH, TSGPWR, (10BAR), SAPPHIRE GLASS,  
4A4Z1LM, 7T62

**SNAC43P \$775**


ALARM CHRONOGRAPH, SSWR, (10BAR), XL,  
CURVED HARDEX GLASS,  
4A711LM, 7T62

**SNAD89P \$750**

ALARM CHRONOGRAPH, THCWR, (10BAR), XL, HARDEX GLASS,  
4A321JM, 7T62

**SNAE35P \$675**

ALARM CHRONOGRAPH, THCWR, (10BAR), XL, HARDEX GLASS,  
L00C013J0, 7T62

**SNAE42P \$650**

ALARM CHRONOGRAPH, SSGPWR (10BAR), XL, HARDEX GLASS,  
M0C6211C0, 7T62

**SNAE43P \$599**

ALARM CHRONOGRAPH, SSCHWR, (10BAR), XL, HARDEX GLASS,  
M0C6211J0, 7T62

**SNAA02P-9 \$825**

ALARM CHRONOGRAPH, TSGPWR, (10BAR), XL, HARDEX GLASS,  
35C3XG, 7T62

**SNAE49P \$699**

ALARM CHRONOGRAPH, ATIWR, (10BAR), XL, HARDEX GLASS,  
M09P111C0, 7T62

**SNAE47P \$650**

ALARM CHRONOGRAPH, ATIWR (10BAR), XL, HARDEX GLASS,  
32B9MB, 7T62

## FC BARCELONA

SEIKO recently entered into a three year partnership with FC Barcelona, the most successful team in world football.

To commemorate this partnership a Special Edition Chronograph watch has been developed with true sports design.

This SEIKO Chronograph brandishes a unique jet black dial, and clear easy to read yellow stopwatch hands.

The FC Barcelona team logo is also placed on the dial along with a special engraved case back.

The watch comes with a Collector's Box stamped with the FC Barcelona Logo, and enclosed is a Team card with player images and signatures.



Inner box - closed



Inner box - opened



Front and back of card inside box



**SNDD23P \$550**

CHRONOGRAPH, SSWR (10BAR), XL, HARDEX GLASS,  
SPECIAL EDITION FC BARCELONA,  
M01M311J0, 7T92





## CHRONOGRAPH


SND Series – Stopwatch measures 12 hours in 1/20th of a second increments with split time facility. Calendar.

SNN Series – Stopwatch measures 60 minutes in 1/5th of a second increments with split time facility. Calendar.



**SND B21P \$699**

CHRONOGRAPH, THCWR, (10BAR), XL, HARDEX GLASS,  
4A0Z2JM, 7T92




**SND D07P \$625**

CHRONOGRAPH, SSWR, (10BAR), XL, HARDEX GLASS,  
M04P129C0, 7T92




**SND C99P \$599**

CHRONOGRAPH, THCWR, (10BAR), XL, HARDEX GLASS,  
M04P129J0, 7T92



**SND C81P \$499**

CHRONOGRAPH, SSWR, (10BAR), XL, HARDEX GLASS,  
M01M311J0, 7T92



**SND C85P \$499**

CHRONOGRAPH, SSHCWR, (10BAR), XL, HARDEX GLASS,  
M01M311J0, 7T92




**SND C89P-2 \$450**

CHRONOGRAPH, SSWR, (10BAR), XL, HARDEX GLASS,  
L01K013K0, 7T92



**SND 417P \$575**

CHRONOGRAPH, SSWR, (10BAR), XL, HARDEX GLASS,  
33L3JG, 7T92



**SNN 233P \$550**

CHRONOGRAPH, HCWR, (10BAR), XL, HARDEX GLASS,  
4A4M1MM, 7T94



**SNN 235P \$450**




CHRONOGRAPH, SSWR, (10BAR), XL, HARDEX GLASS,  
4A4M1JM, 7T94





## CHRONOGRAPH

Stopwatch measures 12 hours in 1/20th of a second increments with split time facility. Calendar.





**SND97P-9 \$799**     
CHRONOGRAPH, SSWR, (5BAR), XL, HARDEX GLASS,  
M0NJ111J9, 7T92






**SNDB71P \$595**    
CHRONOGRAPH, SSWR, (10BAR), XL, HARDEX GLASS,  
4A221LM, 7T92



**SNDB63P \$525**    
CHRONOGRAPH, SSWR, (10BAR), XL, HARDEX GLASS,  
4A221JM, 7T92





**SND37P \$475**    
CHRONOGRAPH, SSWR, (10BAR), XL, HARDEX GLASS,  
M0B9211J0, 7T92



**SND38P \$550**    
CHRONOGRAPH, SSGPWR, (10BAR), XL, HARDEX GLASS,  
M0B9211C0, 7T92



**SND31P \$425**    
CHRONOGRAPH, SSWR, (10BAR), XL, HARDEX GLASS,  
4LR2JE, 7T92

# PERPETUAL CALENDAR

Perpetual Calendar adjusts automatically until February 2100, including leap years and short months.



**SNQ102P-9 \$750**



PERPETUAL CALENDAR, TSGPWR, (10BAR), XL, HARDLEX GLASS,  
30251LX, 6A32  
MATCHING MODEL No. SXDB88P-9



**SNQ101P-9 \$675**



PERPETUAL CALENDAR, SSWR, (10BAR), XL, HARDLEX GLASS,  
30251JX, 6A32



**SNQ045P \$675**



PERPETUAL CALENDAR, HCWR, (10BAR), XL, HARDLEX GLASS,  
3363WG, 6A32


## SOLAR ANALOGUE

Powered by all light sources. 10 month power reserve. Instant start and low energy warning functions.



### SNE107P \$725

SOLAR, SSWR, (20BAR) DIVERS, XL, HARDEX GLASS,  
ONE WAY ROTATING BEZEL, SCREW DOWN CROWN,  
M0FCC237J0, V158



### SNE107P-2 \$625

SOLAR, SSWR, (20BAR) DIVERS, XL, HARDEX GLASS,  
ONE WAY ROTATING BEZEL, SCREW DOWN CROWN,  
DA3H1JR, V158



### SNE109P \$625

SOLAR, SSWR, (20BAR) DIVERS, XL, HARDEX GLASS,  
ONE WAY ROTATING BEZEL, SCREW DOWN CROWN,  
DA3H1JR, V158



## KINETIC

Powered by the movement of the wearer. 6 month power storage with power reserve indicator.



### SKA371P \$875

KINETIC, SSWR, (20BAR), DIVERS, XL, HARDEX GLASS,  
ONE WAY ROTATING BEZEL, SCREW DOWN CROWN,  
35J5JG, 5M62



### SKA371P-2 \$825

KINETIC, SSWR, (20BAR), DIVERS, XL, HARDEX GLASS,  
ONE WAY ROTATING BEZEL, SCREW DOWN CROWN,  
4KR3JZ, 5M62



### S23619J \$7900

PROFESSIONAL DIVER'S, THC.THCCEWR, (100BAR), XL,  
SAPPHIRE GLASS, ONE WAY ROTATING BEZEL,  
SCREW DOWN CROWN, R00D011N0, 7C46



## ANALOGUE

Hour, minute and second hand.  
Calendar and day of the week.



# AUTOMATIC


Powered by the movement of the wearer. Approximately 12 hours energy storage. Accuracy +/- 25 seconds a day average.



**SKZ325K \$950**



AUTOMATIC, THCWR, (20BAR) DIVERS, XL, HARDLEX GLASS, ONE WAY ROTATING BEZEL, SCREW DOWN CROWN, M0MT111J0, 7S36



**SKZ327K \$875**



AUTOMATIC, THCWR, (20BAR) DIVERS, XL, HARDLEX GLASS, ONE WAY ROTATING BEZEL, SCREW DOWN CROWN, R002031J0, 7S36



**SKZ330K \$950**



AUTOMATIC, THCMGPWR, (20BAR) DIVERS, XL, HARDLEX GLASS, ONE WAY ROTATING BEZEL, SCREW DOWN CROWN, R002031P0, 7S36



**SKX171KS \$695**



AUTOMATIC, SSWR, (20BAR), DIVER'S, XL, HARDLEX GLASS, ONE WAY ROTATING BEZEL, SCREW DOWN CROWN, 4D41JZ, 7S26

## 130TH ANNIVERSARY SPECIAL EDITION

A very special anniversary deserves a very special watch. The design of the new Special Edition SEIKO 5 Sports reflects an aesthetic that is quintessentially Japanese, the blossom of a cherry tree under a springtime moon. The pink gold of the bezel echoes the colour of the cherry blossom, while the deep grey of the case and bracelet echoes the soft darkness of the night under moonlight.

### AUTOMATIC

Powered by the movement of the wearer, or by manually winding the crown. Approximately 12 hours energy storage. Accuracy +/- 25 seconds per day.



**SRP148K \$699**



AUTOMATIC, TGP.MHCWR, (10BAR), XL, HARDEX GLASS,  
ROTATING BEZEL, EXHIBITION CASE BACK,  
M0GV611N0, 4R36



**SRP162K \$699**



AUTOMATIC, TGP.MHCWR, (10BAR), XL, HARDEX GLASS,  
EXHIBITION CASE BACK,  
M0N6113N0, 4R36



**SRP132K \$750**



AUTOMATIC, TGP.MHCWR, (10BAR), XL, HARDEX GLASS,  
WORLD TIME, ROTATING BEZEL, EXHIBITION CASE BACK,  
M0GV421N0, 4R36




**SRP172K \$699**



AUTOMATIC, TGP.MHCWR, (10BAR), XL, HARDEX GLASS,  
ONE WAY ROTATING BEZEL, EXHIBITION CASE BACK,  
M0GK611N0, 4R36

## AUTOMATIC

Powered by the movement of the wearer. Approximately 12 hours energy storage. Accuracy +/- 25 seconds a day average.

**SKZ325K \$950**

AUTOMATIC, THCWR, (20BAR) DIVERS, XL, HARDEX GLASS,  
ONE WAY ROTATING BEZEL, SCREW DOWN CROWN,  
M0MT111J0, 7S36

**SKZ327K \$875**

AUTOMATIC, THCWR, (20BAR) DIVERS, XL, HARDEX GLASS,  
ONE WAY ROTATING BEZEL, SCREW DOWN CROWN,  
R002031J0, 7S36

**SKZ330K \$950**

AUTOMATIC, THCMGPWR, (20BAR) DIVERS, XL, HARDEX  
GLASS, ONE WAY ROTATING BEZEL, SCREW DOWN CROWN,  
R002031P0, 7S36

**SKX171KS \$695**

AUTOMATIC, SSWR, (20BAR), DIVER'S, XL, HARDEX GLASS,  
ONE WAY ROTATING BEZEL, SCREW DOWN CROWN,  
4D41JZ, 7S26

**SNZE19K \$499**

AUTOMATIC, SSWR, (10BAR), XL, HARDEX GLASS  
ONE WAY ROTATING BEZEL, EXHIBITION CASE BACK,  
4K03JA, 7S36

**SNZG13K \$460**

AUTOMATIC, SSWR, (10BAR), XL, HARDEX GLASS,  
EXHIBITION CASE BACK,  
300Z1JM, 7S36

**SNZH06K \$595**

AUTOMATIC, TSSGPWR, (10BAR), XL, HARDEX GLASS,  
ONE WAY ROTATING BEZEL, EXHIBITION CASE BACK,  
301V1LM, 7S36

**SNZH03K \$525**

AUTOMATIC, SSWR, (10BAR), XL, HARDEX GLASS,  
ONE WAY ROTATING BEZEL, EXHIBITION CASE BACK,  
301V1JM, 7S36



# AUTOMATIC


# AUTOMATIC



**SKZ312J \$825**



AUTOMATIC, TSGPWR, (10BAR), XL, SAPPHIRE GLASS,  
302N1AM, 7S36



**SKZ290J \$695**




AUTOMATIC, TSGPWR, (10BAR), XL, SAPPHIRE GLASS,  
302M1FL, 7S36



**SNZH34K \$825**



AUTOMATIC, TSGPWR, (10BAR), XL, SAPPHIRE GLASS,  
EXHIBITION CASE BACK,  
30281CM, 7S36



**SNM048K \$725**



AUTOMATIC, TSGPWR, (10BAR), XL, SAPPHIRE GLASS,  
EXHIBITION CASE BACK,  
30261CM, 7S36



**SNM041K \$625**



AUTOMATIC, SSWR, (10BAR), XL, HARDLEX GLASS,  
EXHIBITION CASE BACK,  
30261CM, 7S36



**SNZE32K \$499**



AUTOMATIC, SGPWR, (5BAR), XL, HARDLEX GLASS,  
EXHIBITION CASE BACK,  
3368KG, 7S36



**SNZE30K \$499**



AUTOMATIC, SSWR, (5BAR), XL, HARDLEX GLASS,  
EXHIBITION CASE BACK,  
3368JG, 7S36





**SNZE35K \$399**




AUTOMATIC, SSWR, (5BAR), XL, HARDLEX GLASS,  
EXHIBITION CASE BACK,  
3368JG, 7S36

MENS 100M BRACELET





**SGGA62P \$495**    
ANALOGUE, SGPWR (10BAR), XL, SAPPHIRE GLASS,  
33X9KZ, 7N43



**SGGA61P \$460**    
ANALOGUE, SSWR (10BAR), XL, SAPPHIRE GLASS,  
33X9LZ, 7N43



**SGG719P \$460**    
ANALOGUE, TSGP (10BAR), XL, SAPPHIRE GLASS,  
33X9LZ, 7N43





**SGG717P \$399**     
ANALOGUE, SSWR, (10BAR), XL, SAPPHIRE GLASS,  
33X9JZ, 7N43





**SGG713P \$399**     
ANALOGUE, SSWR, (10BAR), XL, SAPPHIRE GLASS,  
33X9JZ, 7N43



**SGG715P \$399**    
ANALOGUE, SSWR (10BAR), XL, SAPPHIRE GLASS,  
33X9JZ, 7N43



**SGEE89P \$450**    
ANALOGUE, SSWR, (10BAR), XL, SAPPHIRE GLASS,  
35X1JE, 7N42

## MENS 50M BRACELET


**SGEF48P-9 \$899**


ANALOGUE, SGPWR, (5BAR), XL, HARDEX GLASS,  
CABOCHON CROWN,  
M0H311K9, 7N42  
MATCHING MODEL No. SXDC98P-9


**SGEE94P-9 \$899**


ANALOGUE, SSGPWR, (5BAR), XL, HARDEX GLASS,  
CABOCHON CROWN,  
4A5B1LX, 7N42  
MATCHING MODEL No. SXDC36P-9


**SKP382P \$850**


ANALOGUE, TSGPWR, (5BAR), XL, SAPPHIRE GLASS,  
M02P324C0, 7N39  
MATCHING MODEL No. SFQ824P


**SKP371P \$750**



ANALOGUE, SSWR, (5BAR), XL, SAPPHIRE GLASS,  
M0BV221C0, 7N39


**SKP369P \$650**



ANALOGUE, SSWR, (5BAR), XL, SAPPHIRE GLASS,  
M0BV221J0, 7N39


**SGEF46P \$550**



ANALOGUE, SGPWR, (5BAR), XL, SAPPHIRE GLASS,  
M0NA111K0, 7N42  
MATCHING MODEL No. SXDC82P


**SGEF45P \$499**


ANALOGUE, SSWR, (5BAR), XL, SAPPHIRE GLASS,  
M0NA111C0, 7N42  
MATCHING MODEL No. SXDC81P


**SGEF43P \$450**


ANALOGUE, SSWR, (5BAR), XL, SAPPHIRE GLASS,  
M0NA111J0, 7N42




**SGEF41P \$450**


ANALOGUE, SSWR, (5BAR), XL, SAPPHIRE GLASS,  
M0NA111J0, 7N42  
MATCHING MODEL No. SXDC77P





MENS 50M BRACELET



**SKT082P \$385**    
ANALOGUE, SGPWR, (5BAR), XL, HARDLEX GLASS,  
4620KZ, V742




**SKT074P-9 \$360**    
ANALOGUE, TSSGPWR, (5BAR), XL, HARDLEX GLASS,  
4916XZ, V742



**SKP366P \$750**



ANALOGUE, SGPWR, SAPPHIRE GLASS,  
4A4T1KM, 7N39



**SKP364P \$725**



ANALOGUE, TSGPWR, SAPPHIRE GLASS,  
4A4T1LM, 7N39



**SKK704P \$475**



ANALOGUE, SGPWR, SAPPHIRE GLASS, CABOCHON CROWN,  
35Z7KE, 7N32  
MATCHING MODEL No. SXDC24P



**SKK710P \$475**



ANALOGUE, SSGPWR, SAPPHIRE GLASS, CABOCHON CROWN,  
MOD7112C0, 7N32  
MATCHING MODEL No. SXDC58P



**SKK706P \$450**



ANALOGUE, SSGPWR, SAPPHIRE GLASS, CABOCHON CROWN,  
35Z7JE, 7N32  
MATCHING MODEL No. SXDC26P




**SKK705P \$399**



ANALOGUE, SSWR, SAPPHIRE GLASS, CABOCHON CROWN,  
35Z7JE, 7N32  
MATCHING MODEL No. SXDC25P

MENS DRESS STRAP



**SKP375P \$650**




ANALOGUE, HCWR, (5BAR), SAPPHIRE GLASS, CABOCHON CROWN,  
MOD7112C0, 7N32



**SKP373P \$599**



ANALOGUE, SSWR, (5BAR), SAPPHIRE GLASS,  
L00W011J0, 7N39



**SKP381P-2 \$599**



ANALOGUE, SSWR, (5BAR), SAPPHIRE GLASS,  
L01S012J0, 7N39



**SGG480PS \$360**



ANALOGUE, SGPWR, HARDEX GLASS,  
4E91KZ, 7N43



**SFP608P \$340**



ANALOGUE, SGPWR, HARDEX GLASS, CABOCHON CROWN,  
4LH9KB, 7N00  
MATCHING MODEL No. SXGN56P



**LADIES SOLAR 100M**


Powered by all light sources.

SUT Series – 2 months power reserve, instant start and low energy warning functions.

SUP Series – 12 months power reserve.

**SUT046P \$625**

SOLAR, SGPWR, (10BAR), HARDLEX GLASS,  
M0NL111K0, V187  
MATCHING MODEL No. SNE134P

**SUT044P \$599**

SOLAR, TSGPWR, (10BAR), HARDLEX GLASS,  
M0NL111C0, V187  
MATCHING MODEL No. SNE132P

**SUT043P \$525**

SOLAR, SSWR, (10BAR), HARDLEX GLASS,  
M0NL111J0, V187  
MATCHING MODEL No. SNE131P

**SUT041P-9 \$625**

SOLAR, HCWR, (10BAR), HARDLEX GLASS,  
M0NL112E9, V187  
MATCHING MODEL No. SNE125P-9

**SUT040P-9 \$599**

SOLAR, TSGPWR, (10BAR), HARDLEX GLASS,  
M0NL117C9, V187  
MATCHING MODEL No. SNE124P-9

**SUT024P \$550**

SOLAR, SGPWR, (10BAR), XL, HARDLEX GLASS,  
M0FD211K0, V187  
MATCHING MODEL No. SNE090P

**SUT022P \$525**

SOLAR, SSGPWR, (10BAR), XL, HARDLEX GLASS,  
M0NL112E9, V187  
MATCHING MODEL No. SNE088P

## LADIES SOLAR 50M

Powered by all light sources.

SUT Series – 2 months power reserve, instant start and low energy warning functions.

SUP Series – 12 months power reserve.



**SUT032P \$625**   
SOLAR, SGPWR, (5BAR), HARDLEX GLASS,  
M040227K0, V187



**SUT030P \$599**   
SOLAR, TSSGPWR, (5BAR), HARDLEX GLASS,  
M040221R0, V187



**SUT028P \$575**   
SOLAR, TSSGPWR, (5BAR), HARDLEX GLASS,  
M040227C0, V187



**SUT027P \$475**   
SOLAR, SSWR, (5BAR), HARDLEX GLASS,  
M040227J0, V187



**SUP068P \$550**   
SOLAR, SGPWR, (5BAR), HARDLEX GLASS,  
M05H222K0, V115



**SUP066P \$525**   
SOLAR, SSGPWR, (5BAR), HARDLEX GLASS, MOTHER OF PEARL DIAL,  
M05H222C0, V115



**SUP073P \$425**   
SOLAR, SSWR, (5BAR), HARDLEX GLASS,  
M05H222J0, V115



**SUT036P \$675**   
SOLAR, SGPWR, (5BAR), HARDLEX GLASS,  
M0F2212K0, V187



**SUT034P \$650**   
SOLAR, TGP.MSSGPWR, (5BAR), HARDLEX GLASS,  
M0F2211C0, V187






**SUT033P \$575**   
SOLAR, SSWR, (5BAR), HARDLEX GLASS,  
M0F2211J0, V187

## LADIES SOLAR 50M

Powered by all light sources.

SUP Series – 12 months power reserve.


**SUP072P \$599**SOLAR, SGPWR, (5BAR), HARDLEX GLASS, MOTHER OF PEARL DIAL  
M0FB212K0, V115**SUP070P \$575**SOLAR, SSGPWR, (5BAR), HARDLEX GLASS,  
M0FB212C0, V115**SUP075P \$525**SOLAR, SSWR, (5BAR), HARDLEX GLASS,  
M0FB212J0, V115**SUP022P \$499**SOLAR, SGPWR, (5BAR), HARDLEX GLASS,  
M05F222K0, V114**SUP027P \$499**SSWR, (5BAR), HARDLEX GLASS,  
MOTHER OF PEARL DIAL,  
M05F222C0, V114**SUP019P \$425**SOLAR, SSWR, (5BAR), HARDLEX GLASS,  
M05F222J0, V114**SUP026P \$499**SOLAR, SGPWR, (5BAR), HARDLEX GLASS,  
MOTHER OF PEARL DIAL  
M0F0212K0, V114**SUP024P \$475**SOLAR, SSGPWR, (5BAR), HARDLEX GLASS,  
M0F0212C0, V114**SUP080P \$575**SOLAR, SGPWR, (5BAR), HARDLEX GLASS,  
M0NM211K0, V115  
MATCHING MODEL No. SUP892P**SUP079P \$550**SOLAR, SSWR, (5BAR), HARDLEX GLASS,  
M0NM211C0, V115  
MATCHING MODEL No. SUP893P




## LADIES SOLAR DRESS

Powered by all light sources.

SUP Series – 12 months power reserve.

**SUP088P \$595**SOLAR, SGPWR, HARDEX GLASS, 22 SWAROVSKI CRYSTALS,  
M0AB212C0, V114**SUP052P \$575**SOLAR, SSGPWR, HARDEX GLASS, 22 SWAROVSKI CRYSTALS,  
M0AB212C0, V114**SUP086P-9 \$599**SOLAR, SGPWR, HARDEX GLASS, 22 SWAROVSKI CRYSTALS,  
MOTHER OF PEARL DIAL,  
M0AB212K9, V115**SUP084P-9 \$599**SOLAR, SSWR, HARDEX GLASS, 22 SWAROVSKI CRYSTALS,  
M0AB212C9, V115**SUP083P-9 \$525**SOLAR, SSWR, HARDEX GLASS, 22 SWAROVSKI CRYSTALS,  
MOTHER OF PEARL DIAL,  
M0AB212J9, V115**SUP032P \$475**SOLAR, SGPWR, HARDEX GLASS,  
M0G2122K0, V116**SUP030P \$475**SOLAR, SGPWR, HARDEX GLASS,  
M0G2122K0, V116**SUP028P \$475**SOLAR, SSGPWR, HARDEX GLASS,  
M0G2122C0, V116**SUP032P-2 \$399**SOLAR, SGPWR, HARDEX GLASS,  
L010011K0, V116

LADIES 100M BRACELET



**SXDC11P-9 \$850**  

ANALOGUE, SSWR, (10BAR), XL, HARDEX GLASS, 11 DIAMONDS,  
MOTHER OF PEARL DIAL,  
4A3E1JX, 7N82



**SXDB88P-9 \$695**  

ANALOGUE, TSGPWR, (10BAR), XL, HARDEX GLASS,  
MOTHER OF PEARL DIAL,  
4A3E1LX, 7N82  
MATCHING MODEL No. SNQ102P-9



**SXDB37P \$495**  

ANALOGUE, SSWR, (10BAR), XL, SAPPHIRE GLASS,  
4A9Y2LM, 7N82

LADIES 50M BRACELET



**SXDB54P \$925**  



ANALOGUE, TSSGPWR, (5BAR), HARDLEX GLASS,  
12 DIAMONDS, MOTHER OF PEARL, CABOCHON CROWN,  
4A361LM, 7N82



**SXDB56P \$875**  

ANALOGUE, TSGPWR (5BAR), HARDLEX GLASS,  
9 DIAMONDS, MOTHER OF PEARL, CABOCHON CROWN,  
4A361RM, 7N82



**SXDB58P \$795**  




ANALOGUE, SGPWR (5BAR), HARDLEX GLASS,  
9 DIAMONDS, MOTHER OF PEARL, CABOCHON CROWN,  
4A362KM, 7N82



**SXDA74P \$595**  




ANALOGUE, SGPWR, (5BAR), HARDLEX GLASS,  
4A361KM, 7N82



**SXDC98P-9 \$799**   

ANALOGUE, SGPWR, (5BAR), HARDLEX GLASS, CABOCHON CROWN,  
M0H4111K9, 7N82  
MATCHING MODEL No. SGFE48P-9




**SXDC36P-9 \$799**   

ANALOGUE, SSGPWR, (5BAR), HARDLEX GLASS, CABOCHON CROWN,  
4A5C1LX, 7N82  
MATCHING MODEL No. SGEE94P-9



**SFQ822P \$825**   

ANALOGUE, SGPWR, (5BAR), SAPPHIRE GLASS,  
M02R327K0, 7N00



**SFQ824P \$795**   

ANALOGUE, TSGPWR, (5BAR), SAPPHIRE GLASS,  
M02R327C0, 7N00  
MATCHING MODEL No. SKP382P



**SFQ827P \$725**   

ANALOGUE, SSWR, (5BAR), SAPPHIRE GLASS,  
M02R327J0, 7N00



## LADIES 50M BRACELET




**SXDC96P-9 \$699**   
 ANALOGUE, TSGPWR, (5BAR), HARDLEX GLASS,  
 MONK111C9, 7N82



**SXDE09P-9 \$650**   
 ANALOGUE, SSWR, (5BAR), HARDLEX GLASS, MOTHER OF PEARL DIAL,  
 MONK111J9, 7N82



**SXDC82P \$550**   
 ANALOGUE, SGPWR, (5BAR), SAPPHIRE GLASS,  
 M035337K0, 7N82  
 MATCHING MODEL No. SGEF46P



**SXDC81P \$499**   
 ANALOGUE, SSWR, (5BAR), SAPPHIRE GLASS,  
 M035337C0, 7N82  
 MATCHING MODEL No. SGEF45P



**SXDC77P \$450**   
 ANALOGUE, SSWR, (5BAR), SAPPHIRE GLASS,  
 M035337J0, 7N82  
 MATCHING MODEL No. SGEF41P



**SXDC32P \$599**   
 ANALOGUE, SGPWR, (5BAR), CURVED HARDLEX GLASS,  
 4A4W1KM, 7N82




**SXDC16P \$550**   
 ANALOGUE, TSGPWR, (5BAR), CURVED HARDLEX GLASS,  
 CABOCHON CROWN,  
 4A4L1JM, 7N82


LADIES DRESS BRACELET



**SXDB94P \$725**   
ANALOGUE, SGPWR, HARDLEX GLASS,  
MOTHER OF PEARL DIAL,  
4A3T1KM, 7N82



**SXDB96P \$675**   
ANALOGUE, TSGPWR, HARDLEX GLASS,  
4A3T1LM, 7N82




**SUJF63P \$595**   
ANALOGUE, HCWR, CURVED HARDLEX GLASS,  
4A432SM, 1N00



**SUJF60P \$499**   
ANALOGUE, SSGPWR, CURVED HARDLEX GLASS,  
4A432LM, 1N00




**SUJG16P-9 \$595**   
ANALOGUE, SSGPWR, HARDLEX GLASS, CABOCHON CROWN,  
2 DIAMONDS, MOTHER OF PEARL DIAL,  
4A3H1LX, 1N00




**SZZC40P-9 \$499**   
ANALOGUE, GPDWR, HARDLEX GLASS,  
44Y2XB, 2E20



**SXDC24P \$475**   
ANALOGUE, SGPWR, SAPPHIRE GLASS,  
CABOCHON CROWN,  
4AA11KM, 7N82  
MATCHING MODEL No. SKK704P



**SXDC58P \$475**   
ANALOGUE, SSGPWR, SAPPHIRE GLASS,  
CABOCHON CROWN,  
M0G6112C0, 7N82  
MATCHING MODEL No. SKK710P



**SXDC26P \$450**   
ANALOGUE, SSGPWR, SAPPHIRE GLASS,  
CABOCHON CROWN,  
4AA11JM, 7N82  
MATCHING MODEL No. SKK706P



**SXDC25P \$399**   
ANALOGUE, SSWR, SAPPHIRE GLASS,  
CABOCHON CROWN,  
4AA11JM, 7N82  
MATCHING MODEL No. SKK705P

## LADIES DRESS STRAP



**SXDA12P \$440**



ANALOGUE, SGPWR, SAPPHIRE GLASS, CABOCHON CROWN,  
4LG3KZ, 7N82



**SXDA16P \$440**



ANALOGUE, SGPWR, SAPPHIRE GLASS, CABOCHON CROWN,  
4LG5KZ, 7N82



**SUP032P-2 \$399**



SOLAR, SGPWR, HARDEX GLASS,  
L010011K0, V116



**SXGN56P \$340**



ANALOGUE, SGPWR, HARDEX GLASS, CABOCHON CROWN,  
4J42KB, 1N01  
MATCHING MODEL No. SFP608P



**SFQ830P \$340**



ANALOGUE, SGPWR, HARDEX GLASS, CABOCHON CROWN,  
4J38KB, 7N00



## STOPWATCHES



**S23571J \$1200**

PC, HARDEX GLASS,  
BZA08N, S149



**S23569J \$775**

PCWR, HARDEX GLASS,  
BZA02N, S143



**S23535P \$675**

PC, HARDEX GLASS,  
BZA04N, S351



**S23605P \$399**

APCWR (5BAR), ACRYLIC GLASS,  
DFY6JB, S058



**S23593J \$695**

APCWR (10BAR), HARDEX GLASS,  
BZA04N, S141



**S23603P \$340**

APCWR, ACRYLIC GLASS,  
DD83AD, S057



**S23601P \$299**

APCWR, ACRYLIC GLASS,  
DD83AD, S056



**S23589J \$145**

PCWR, ACRYLIC GLASS,  
4E22MB, W073



**S23547J \$199.95**

PC, GRIPSWITCH FOR S23571J,  
S149



# PRODUCT INFORMATION MATRIX

Model Number	Category	Page	Band Reference	Glass Type	Water Resistance (Metres)	Stone Set Type	Stone Set Qty	Special Crown	Special Dial	Lumbrite Hands	Lumbrite Hour Markers	Calibre	Battery Type	Battery Life/Power Reserve (Approx)
SZ3619J	Diver's	35	R00D011N0	Sapphire	1000D			Screw Down		•	•	7C46	SR43SW	5 Years
SFP608P	Men's Dress Strap	44	4LH9KB	Hardlex	WR			Cabochon				7N00	SR616SW	3 Years
SFQ822P	Ladies 50 Metre Bracelet	50	M02R327K0	Sapphire	50							7N00	SR616SW	3 Years
SFQ824P	Ladies 50 Metre Bracelet	50	M02R327C0	Sapphire	50							7N00	SR616SW	3 Years
SFQ827P	Ladies 50 Metre Bracelet	50	M02R327J0	Sapphire	50							7N00	SR616SW	3 Years
SFQ830P	Ladies Dress Strap	53	4J38KB	Hardlex	WR			Cabochon				7N00	SR616SW	3 Years
SGEB76P-9	Coutura	22	34D6XB	Sapphire	100			Cabochon		•	•	7N42	SR920SW	5 Years
SGED96P-9	Coutura	22	35R7VB	Sapphire	100			Cabochon		•	•	7N42	SR920SW	5 Years
SGEE89P	Men's 100 Metre Bracelet	40	35X1JE	Sapphire	100					•	•	7N42	SR920SW	5 Years
SGEE94P-9	Men's 50 Metre Bracelet	41	4A5B1LX	Sapphire	100			Cabochon				7N42	SR920SW	5 Years
SGEF41P	Men's 50 Metre Bracelet	41	M0NA111J0	Sapphire	50							7N42	SR920SW	5 Years
SGEF43P	Men's 50 Metre Bracelet	41	M0NA111J0	Sapphire	50							7N42	SR920SW	5 Years
SGEF45P	Men's 50 Metre Bracelet	41	M0NA111C0	Sapphire	50							7N42	SR920SW	5 Years
SGEF46P	Men's 50 Metre Bracelet	41	M0NA111K0	Sapphire	50							7N42	SR920SW	5 Years
SGEF48P-9	Men's 50 Metre Bracelet	41	M0H3111K9	Hardlex	50			Cabochon				7N42	SR920SW	5 Years
SGG480PS	Men's Dress Strap	44	4E91KZ	Hardlex	WR							7N43	SR920SW	5 Years
SGG713P	Men's 100 Metre Bracelet	40	33X9JZ	Sapphire	100					•	•	7N43	SR920SW	5 Years
SGG715P	Men's 100 Metre Bracelet	40	33X9JZ	Sapphire	100					•	•	7N43	SR920SW	5 Years
SGG717P	Men's 100 Metre Bracelet	40	33X9JZ	Sapphire	100					•	•	7N43	SR920SW	5 Years
SGG719P	Men's 100 Metre Bracelet	40	33X9LZ	Sapphire	100					•	•	7N43	SR920SW	5 Years
SGGA61P	Men's 100 Metre Bracelet	40	33X9LZ	Sapphire	100					•	•	7N43	SR920SW	5 Years
SGGA62P	Men's 100 Metre Bracelet	40	33X9KZ	Sapphire	100					•	•	7N43	SR920SW	5 Years
SKA371P	Kinetic	24	35J5JG	Hardlex	200D			Screw Down		•	•	5M62	N/A	6 Months
SKA371P	Diver's	35	35J5JG	Hardlex	200D			Screw Down		•	•	5M62	N/A	6 Months
SKA371P-2	Kinetic	24	4KR3JZ	Hardlex	200D			Screw Down		•	•	5M62	N/A	6 Months
SKA371P-2	Diver's	35	4KR3JZ	Hardlex	200D			Screw Down		•	•	5M62	N/A	6 Months
SKA463P	Kinetic	24	4A4N1JM	Hardlex	100					•	•	5M62	N/A	6 Months
SKA465P	Kinetic	24	4A4N2MM	Hardlex	100					•	•	5M62	N/A	6 Months
SKA489P	Kinetic	24	M0GW111J0	Hardlex	100							5M62	N/A	6 Months
SKA490P	Kinetic	24	M0GW111C0	Hardlex	100							5M62	N/A	6 Months
SKA505P	Kinetic	24	M04P129J0	Hardlex	100					•	•	5M62	N/A	6 Months
SKA511P	Sportura	11	M0ND224J0	Sapphire	200D			Screw Down		•	•	5M62	N/A	6 Months
SKA511P-2	Sportura	11	R00F011J0	Sapphire	200D			Screw Down		•	•	5M62	N/A	6 Months
SKK704P	Men's Dress Bracelet	43	35Z7KE	Sapphire	WR			Cabochon				7N32	SR920SW	5 Years
SKK705P	Men's Dress Bracelet	43	35Z7JE	Sapphire	WR			Cabochon				7N32	SR920SW	5 Years
SKK706P	Men's Dress Bracelet	43	35Z7JE	Sapphire	WR			Cabochon				7N32	SR920SW	5 Years
SKK710P	Men's Dress Bracelet	43	M0D7112C0	Sapphire	WR			Cabochon				7N32	SR920SW	5 Years
SKP364P	Men's Dress Bracelet	43	4A4T1LM	Sapphire	WR							7N39	SR920SW	5 Years
SKP366P	Men's Dress Bracelet	43	4A4T1KM	Sapphire	WR							7N39	SR920SW	5 Years
SKP369P	Men's 50 Metre Bracelet	41	M0BV221J0	Sapphire	50							7N39	SR920SW	5 Years
SKP371P	Men's 50 Metre Bracelet	41	M0BV221C0	Sapphire	50							7N39	SR920SW	5 Years
SKP373P	Men's Dress Strap	44	L00W011J0	Sapphire	50							7N39	SR920SW	5 Years
SKP375P	Men's Dress Strap	44	L00W011N0	Sapphire	50							7N39	SR920SW	5 Years
SKP381P-2	Men's Dress Strap	44	L01S012J0	Sapphire	50							7N39	SR920SW	5 Years
SKP382P	Men's 50 Metre Bracelet	41	M02P324C0	Sapphire	50							7N39	SR920SW	5 Years
SKT074P-9	Men's 50 Metre Bracelet	42	4916KZ	Hardlex	50					•	•	V742	SR920SW	5 Years
SKT082P	Men's 50 Metre Bracelet	42	4620KZ	Hardlex	50					•	•	V742	SR920SW	5 Years
SKX171KS	Diver's	36	4D41JZ	Hardlex	200D			Screw Down		•	•	7S26	N/A	24 Hours
SKX171KS	Automatic	38	4D41JZ	Hardlex	200D			Screw Down		•	•	7S26	N/A	24 Hours
SKZ290J	Automatic	39	302M1FL	Sapphire	10							7S36	N/A	24 Hours
SKZ312J	Automatic	39	302N1AM	Sapphire	100							7S36	N/A	24 Hours
SKZ325K	Diver's	36	M0MT111J0	Hardlex	200D			Screw Down		•	•	7S36	N/A	24 Hours
SKZ325K	Automatic	38	M0MT111J0	Hardlex	200D			Screw Down		•	•	7S36	N/A	24 Hours
SKZ327K	Diver's	36	R002031J0	Hardlex	200D			Screw Down		•	•	7S36	N/A	24 Hours
SKZ327K	Automatic	38	R002031J0	Hardlex	200D			Screw Down		•	•	7S36	N/A	24 Hours
SKZ330K	Diver's	36	R002031P0	Hardlex	200D			Screw Down		•	•	7S36	N/A	24 Hours
SKZ330K	Automatic	38	R002031P0	Hardlex	200D			Screw Down		•	•	7S36	N/A	24 Hours
SNA02P-9	Alarm Chronograph	30	35C3XG	Hardlex	10					•	•	7T62	SR627W	3 Years
SNA02P-9	Velatura	17	35L9LB	Sapphire	100					•	•	7T62	SR627W	3 Years
SNA093P	Velatura	17	35M0JB	Sapphire	100					•	•	7T62	SR627W	3 Years
SNA093P-2	Velatura	17	4LT7JB	Sapphire	100					•	•	7T62	SR627W	3 Years
SNA043P	Alarm Chronograph	30	4A711LM	Hardlex	100					•	•	7T62	SR927SW	3 Years
SNAD10P	Arctura	19	4A581PT	Sapphire	100					•	•	7T62	SR927W	3 Years
SNAD11P	Arctura	19	4A571MM	Sapphire	100					•	•	7T62	SR927W	3 Years
SNAD89P	Alarm Chronograph	30	4A321JM	Hardlex	100					•	•	7T62	SR927W	3 Years
SNAE17P	Velatura	17	4LJ7MB	Sapphire	100					•	•	7T62	SR927W	3 Years
SNAE19P	Velatura	17	35L9JB	Sapphire	100					•	•	7T62	SR927W	3 Years
SNAE21P	Velatura	17	35M0JB	Sapphire	100					•	•	7T62	SR927W	3 Years
SNAE32P	Alarm Chronograph	30	4A4Z1LM	Sapphire	100					•	•	7T62	SR927W	3 Years
SNAE34P	Coutura	21	34D6NB	Sapphire	100			Cabochon		•	•	7T62	SR927W	3 Years
SNAE35P	Alarm Chronograph	30	L00C013J0	Hardlex	100					•	•	7T62	SR927W	3 Years
SNAE42P	Alarm Chronograph	30	M0C6211C0	Hardlex	100					•	•	7T62	SR927W	3 Years
SNAE43P	Alarm Chronograph	30	M0C6211J0	Hardlex	100					•	•	7T62	SR927W	3 Years
SNAE47P	Alarm Chronograph	30	32B9MB	Hardlex	100					•	•	7T62	SR927W	3 Years
SNAE49P	Alarm Chronograph	30	M09P111C0	Hardlex	100					•	•	7T62	SR927W	3 Years
SNAE56P-2	Coutura	21	M0NG111C9	Sapphire	100			Cabochon		•	•	7T62	SR927W	3 Years
SNAE57P-9	Coutura	21	M0NG112E9	Sapphire	100			Cabochon		•	•	7T62	SR627W	3 Years
SNAE63P	Sportura	11	M0ND111J0	Sapphire	100			Screw Down		•	•	7T62	SR927W	3 Years
SNAE67P	Sportura	11	L01M012M0	Sapphire	100			Screw Down		•	•	7T62	SR927W	3 Years
SNAE69P	Sportura	11	M0ND111J0	Sapphire	100			Screw Down		•	•	7T62	SR927W	3 Years
SNAE70P	Coutura	21	M0NG111D0	Sapphire	100			Cabochon		•	•	7T62	SR927W	3 Years
SNAE73P	Coutura	21	M0NG111J0	Sapphire	100			Cabochon		•	•	7T62	SR927W	3 Years
SNAE74P	Coutura	21	M0NG111C0	Sapphire	100			Cabochon		•	•	7T62	SR927W	3 Years
SNAE75P	Sportura	10	L01M013J0	Sapphire	100				FC Barcelona	•	•	7T62	SR927W	3 Years
SND417P	Chronograph	32	33L3JG	Hardlex	100					•	•	7T92	SR927SW	3 Years
SND459P	Velatura	16	4A291JT	Sapphire	200			Screw Down		•	•	7T92	SR927SW	3 Years
SND821P	Chronograph	32	4A0Z2JM	Hardlex	100					•	•	7T92	SR927W	3 Years
SND863P	Chronograph	33	4A221JM	Hardlex	100					•	•	7T92	SR927W	3 Years



# PRODUCT INFORMATION MATRIX

Model Number	Hour/Min Hand	Hour/Min/Sec Hand	24 Hour Hand	Date	Day	Month	Moon Phase Indicator	Alarm	Stopwatch	Stopwatch Count	Light	Count Down Timer	Dual Time Capability	Tachymeter	Slide Rule	World Time	Analogous Display	Duo Display	Solar	Quartz	Kinetic	Kinetic Auto Relay	Kinetic Chronograph	Kinetic Perpetual	Kinetic Direct Drive	Perpetual Calendar	Automatic	Power Reserve Indicator	Hand Winding Capability
SZ3619J		•		•	•												•			•									
SFP608P	•																•			•									
SFQ822P	•																•			•									
SFQ824P	•																•			•									
SFQ827P	•																•			•									
SFQ380P	•																•			•									
SGEB76P-9		•		•													•			•									
SGED96P-9		•		•													•			•									
SGG89P		•		•													•			•									
SGEE94P-9		•		•													•			•									
SGEF41P		•		•													•			•									
SGEF43P		•		•													•			•									
SGEF45P		•		•													•			•									
SGEF46P		•		•													•			•									
SGEF46P		•		•													•			•									
SGG480PS		•		•	•												•			•									
SGG713P		•		•	•												•			•									
SGG715P		•		•	•												•			•									
SGG717P		•		•	•												•			•									
SGG719P		•		•	•												•			•									
SGGA61P		•		•	•												•			•									
SGGA62P		•		•	•												•			•									
SKA371P		•		•													•				•							•	
SKA371P		•		•													•				•							•	
SKA371P-2		•		•													•				•							•	
SKA371P-2		•		•													•				•							•	
SKA463P		•		•													•				•							•	
SKA465P		•		•													•				•							•	
SKA489P		•		•													•				•							•	
SKA490P		•		•													•				•							•	
SKA505P		•		•													•				•							•	
SKA511P		•		•													•				•							•	
SKA511P-2		•		•													•				•							•	
SKK704P		•		•													•				•								
SKK705P		•		•													•				•								
SKK706P		•		•													•				•								
SKK710P		•		•													•				•								
SKP364P	•			•													•				•								
SKP366P	•			•													•				•								
SKP369P	•			•													•				•								
SKP371P	•			•													•				•								
SKP373P	•			•													•				•								
SKP375P	•			•													•				•								
SKP381P-2	•			•													•				•								
SKP382P	•			•													•				•								
SKT074P-9		•		•													•				•								
SKT082P		•		•													•				•								
SKX171KS		•		•	•												•											•	
SKX171KS		•		•	•												•											•	
SKZ290J		•		•	•												•											•	
SKZ312J		•		•	•												•											•	
SKZ325K		•		•	•												•											•	
SKZ325K		•		•	•												•											•	
SKZ327K		•		•	•												•											•	
SKZ327K		•		•	•												•											•	
SKZ330K		•		•	•												•											•	
SKZ330K		•		•	•												•											•	
SKZ330K		•		•	•			•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNA92P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNA93P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNA93P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAC43P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAD10P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAD11P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAD89P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAE17P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAE19P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAE21P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAE32P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAE34P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAE35P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAE42P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAE43P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAE47P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAE49P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAE56P-9		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAE57P-9		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAE63P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAE67P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAE69P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAE70P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAE73P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAE74P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SNAE75P		•		•				•	•	60 minutes in 1/5th second increments			•	•			•			•									
SND417P		•		•				•	•	12 hours in 1/20th second increments																			

# PRODUCT INFORMATION MATRIX

Model Number	Category	Page	Band Reference	Glass Type	Water Resistance (Metres)	Stone Set Type	Stone Set Qty	Special Crown	Special Dial	Lumbrite Hands	Lumbrite Hour Markers	Calibre	Battery Type	Battery Life/Power Reserve (Approx)
SNDB71P	Chronograph	33	4A221LM	Hardlex	100					•	•	7T92	SR927W	3 Years
SNDC31P	Chronograph	33	4LR2JE	Hardlex	100					•	•	7T92	SR927W	3 Years
SNDC37P	Chronograph	33	MOB9211J0	Hardlex	100					•	•	7T92	SR927W	3 Years
SNDC38P	Chronograph	33	MOB9211C0	Hardlex	100					•	•	7T92	SR927W	3 Years
SNDC81P	Chronograph	32	M01M311J0	Hardlex	100					•	•	7T92	SR927W	3 Years
SNDC85P	Chronograph	32	M01M311J0	Hardlex	100					•	•	7T92	SR927W	3 Years
SNDC89P-2	Chronograph	32	L01K013J0	Hardlex	100					•	•	7T92	SR927W	3 Years
SNDC97P-9	Chronograph	33	MONJ111J9	Hardlex	50					•	•	7T92	SR927W	3 Years
SNDC99P	Chronograph	32	M04P129J0	Hardlex	100					•	•	7T92	SR927W	3 Years
SNDD07P	Chronograph	32	M04P129C0	Hardlex	100					•	•	7T92	SR927W	3 Years
SNDD23P	FC Barcelona	31	M01M311J0	Hardlex	100				FC Barcelona	•	•	7T92	SR927W	3 Years
SNDC37P	Velatura	18	4A551JM	Sapphire	100	Diamond	53		Mother Of Pearl	•	•	7T92	SR927SW	3 Years
SNDC38P	Velatura	18	4A551LM	Sapphire	100	Diamond	53		Mother Of Pearl	•	•	7T92	SR927SW	3 Years
SNDC40P	Velatura	18	4A551LM	Sapphire	100	Diamond	11		Mother Of Pearl	•	•	7T92	SR927SW	3 Years
SNE087P	Solar	27	MOFE211J0	Hardlex	100					•	•	V157	N/A	10 Months
SNE088P	Solar	27	MOFE211C0	Hardlex	100					•	•	V157	N/A	10 Months
SNE090P	Solar	27	MOFE211K0	Hardlex	100					•	•	V157	N/A	10 Months
SNE093P	Solar	26	35C4JZ	Hardlex	100					•	•	V158	N/A	10 Months
SNE094P	Solar	26	M0C1111C0	Hardlex	100					•	•	V158	N/A	10 Months
SNE095P	Solar	26	35C4JZ	Hardlex	100					•	•	V158	N/A	10 Months
SNE098P-9	Solar	26	35C4XZ	Hardlex	100					•	•	V158	N/A	10 Months
SNE107P	Solar	26	M0FCC237J0	Hardlex	200			Screw Down		•	•	V158	N/A	10 Months
SNE107P	Diver's	35	M0FCC237J0	Hardlex	200			Screw Down		•	•	V158	N/A	10 Months
SNE107P-2	Solar	26	DA3H1JR	Hardlex	200			Screw Down		•	•	V158	N/A	10 Months
SNE107P-2	Diver's	35	DA3H1JR	Hardlex	200			Screw Down		•	•	V158	N/A	10 Months
SNE109P	Solar	26	DA3H1JR	Hardlex	200			Screw Down		•	•	V158	N/A	10 Months
SNE109P	Diver's	35	DA3H1JR	Hardlex	200			Screw Down		•	•	V158	N/A	10 Months
SNE121P	Solar	27	M02M211J0	Hardlex	100							V157	N/A	10 Months
SNE124P-9	Solar	27	M02M217C9	Hardlex	100							V157	N/A	10 Months
SNE125P-9	Solar	27	M02M212E9	Hardlex	100							V157	N/A	10 Months
SNE127P	Solar	28	M0D7211J0	Hardlex	100							V157	N/A	10 Months
SNE128P-9	Solar	28	M0D7211C9	Hardlex	100							V157	N/A	10 Months
SNE131P	Solar	27	M02M211J0	Hardlex	100							V157	N/A	10 Months
SNE132P	Solar	27	M02M211C0	Hardlex	100							V157	N/A	10 Months
SNE134P	Solar	27	M02M211K0	Hardlex	100							V157	N/A	10 Months
SNE138P	Solar	28	M0D7211K0	Hardlex	100							V157	N/A	10 Months
SNL045P	Arctura	19	4A571JM	Sapphire	100					•	•	7L22	N/A	5 Months
SNM041K	Automatic	39	30261AM	Hardlex	100							7S35	N/A	24 Hours
SNM048K	Automatic	39	30261CM	Hardlex	100							7S35	N/A	24 Hours
SNN233P	Chronograph	32	4A4M1MM	Hardlex	100					•	•	7T94	SR927SW	5 Years
SNN235P	Chronograph	32	4A4M1JM	Hardlex	100					•	•	7T94	SR927SW	5 Years
SNP007P-9	Coutura	20	34P0ZB	Sapphire	100			Cabochon		•	•	7D48	N/A	4 Years
SNP008P-9	Coutura	20	34P0XB	Sapphire	100			Cabochon		•	•	7D48	N/A	4 Years
SNP017P-9	Coutura	20	35X6VB	Sapphire	100			Cabochon		•	•	7D46	N/A	4 Years
SNP029P	Arctura	19	4A571JM	Sapphire	100					•	•	7D48	N/A	4 Years
SNP039P	Premier	12	M0NB111J0	Sapphire	100							7D48	N/A	4 Years
SNP041P	Premier	12	M0NB111J0	Sapphire	100							7D48	N/A	4 Years
SNP042P	Premier	12	M0NB111C0	Sapphire	100							7D48	N/A	4 Years
SNP044P	Premier	12	L01012K0	Sapphire	100							7D48	N/A	4 Years
SNQ045P	Perpetual Calendar	34	3363WG	Hardlex	100					•	•	6A32	SR927SW	4 Years
SNQ101P-9	Perpetual Calendar	34	30251JX	Hardlex	100					•	•	6A32	SR927SW	4 Years
SNQ102P-9	Perpetual Calendar	34	30251LX	Hardlex	100					•	•	6A32	SR927SW	4 Years
SNQ116P	Premier	14	4A081LM	Sapphire	100							6A32	SR927SW	4 Years
SNQ117P	Premier	14	4A081JM	Sapphire	100							6A32	SR927SW	4 Years
SNQ118P	Premier	14	4A071KL	Sapphire	100							6A32	SR927SW	4 Years
SNQ123P	Coutura	20	M0NG111J0	Sapphire	100			Cabochon		•	•	6A32	SR927SW	4 Years
SNQ124P	Coutura	20	M0NG111C0	Sapphire	100			Cabochon		•	•	6A32	SR927SW	4 Years
SNZE19K	Automatic	38	4K03JA	Hardlex	100					•	•	7S36	N/A	24 Hours
SNZE30K	Automatic	39	3368JG	Hardlex	50					•	•	7S36	N/A	24 Hours
SNZE32K	Automatic	39	3368KG	Hardlex	50					•	•	7S36	N/A	24 Hours
SNZE35K	Automatic	39	3368JG	Hardlex	50					•	•	7S36	N/A	24 Hours
SNZG13K	Automatic	38	30021JM	Hardlex	100					•	•	7S36	N/A	24 Hours
SNZH03K	Automatic	38	301V1JM	Hardlex	100					•	•	7S36	N/A	24 Hours
SNZH06K	Automatic	38	301V1LM	Hardlex	100					•	•	7S36	N/A	24 Hours
SNZH34K	Automatic	39	30281CM	Hardlex	100							7S36	N/A	24 Hours
SPC049P	Velatura	16	4A0X1ML	Sapphire	200			Screw Down		•	•	7T84	SR927SW	3 Years
SPC057P	Premier	13	4A081JM	Sapphire	100							7T04	SR927SW	5 Years
SPC058P	Premier	13	4A081LM	Sapphire	100							7T04	SR927SW	5 Years
SRH006P	Velatura	16	4LJ7KB	Sapphire	100					•	•	5D44	N/A	1 Month
SRK021P	Premier	13	4A081JM	Sapphire	100							6G28	SR626SW	3 Years
SRK286P	Premier	15	30061LM	Sapphire	100	Diamond	30	Cabochon	Mother Of Pearl			6G28	SR626SW	3 Years
SRK293P	Premier	15	30061JM	Sapphire	100	Diamond	30	Cabochon	Mother Of Pearl			6G28	SR626SW	3 Years
SRK296P	Premier	15	30061LM	Sapphire	100			Cabochon				6G28	SR626SW	3 Years
SRP132K	130th Anniversary Special Edition	37	M0GV421N0	Hardlex	100					•	•	4R36	N/A	24 Hours
SRP148K	130th Anniversary Special Edition	37	M0GV611N0	Hardlex	100					•	•	4R36	N/A	24 Hours
SRP162K	130th Anniversary Special Edition	37	M0NG113N0	Hardlex	100					•	•	4R36	N/A	24 Hours
SRP172K	130th Anniversary Special Edition	37	M0GK611N0	Hardlex	100					•	•	4R36	N/A	24 Hours
SRX003P	Premier	12	4A072JL	Sapphire	100							5D88	N/A	1 Month
SRX004P	Premier	12	4A071KL	Sapphire	100							5D88	N/A	1 Month
SSA023J-2	Premier	13	L01J011J0	Sapphire	100							4R39	N/A	24 Hours
SSA024J	Premier	13	M0NB111C0	Sapphire	100							4R39	N/A	24 Hours
SSC002P	Solar	25	M0BN211C0	Hardlex	100					•	•	V172	N/A	6 Months
SSC002P	Alarm Chronograph	29	M0BN211C0	Hardlex	100					•	•	V172	N/A	6 Months
SSC003P	Solar	25	M0BN211J0	Hardlex	100					•	•	V172	N/A	6 Months
SSC003P	Alarm Chronograph	29	M0BN211J0	Hardlex	100					•	•	V172	N/A	6 Months
SSC005P	Solar	25	M0BN211J0	Hardlex	100					•	•	V172	N/A	6 Months
SSC005P	Alarm Chronograph	29	M0BN211J0	Hardlex	100					•	•	V172	N/A	6 Months
SSC008P-2	Solar	25	M0FP218K0	Hardlex	100					•	•	V172	N/A	6 Months

# PRODUCT INFORMATION MATRIX

Model Number	Hour/Min Hand	Hour/Min/Sec Hand	24 Hour Hand	Date	Day	Month	Moon Phase Indicator	Alarm	Stopwatch	Stopwatch Count	Light	Count Down Timer	Dual Time Capability	Tachymeter	Slide Rule	World Time	Analogue Display	Duo Display	Solar	Quartz	Kinetic	Kinetic Auto Relay	Kinetic Chronograph	Kinetic Perpetual	Kinetic Direct Drive	Perpetual Calendar	Automatic	Power Reserve Indicator	Hand Winding Capability
SNDB71P	•	•	•	•				•	•	12 hours in 1/20th second increments							•			•									
SNDC31P	•	•	•	•				•	•	12 hours in 1/20th second increments							•			•									
SNDC37P	•	•	•	•				•	•	12 hours in 1/20th second increments							•			•									
SNDC38P	•	•	•	•				•	•	12 hours in 1/20th second increments				•			•			•									
SNDC81P	•	•	•	•				•	•	12 hours in 1/20th second increments							•			•									
SNDC85P	•	•	•	•				•	•	12 hours in 1/20th second increments							•			•									
SNDC89P-2	•	•	•	•				•	•	12 hours in 1/20th second increments							•			•									
SNDC97P-9	•	•	•	•				•	•	12 hours in 1/20th second increments							•			•									
SNDC99P	•	•	•	•				•	•	12 hours in 1/20th second increments				•			•			•									
SNDD07P	•	•	•	•				•	•	12 hours in 1/20th second increments				•			•			•									
SNDD23P	•	•	•	•				•	•	12 hours in 1/20th second increments							•			•									
SNZ237P	•	•	•	•				•	•	12 hours in 1/20th second increments							•			•									
SNZ238P	•	•	•	•				•	•	12 hours in 1/20th second increments							•			•									
SNZ240P	•	•	•	•				•	•	12 hours in 1/20th second increments							•			•									
SNE087P	•	•															•		•										
SNE088P	•	•															•		•										
SNE090P	•	•															•		•										
SNE093P	•	•	•	•													•		•										
SNE094P	•	•	•	•													•		•										
SNE095P	•	•	•	•													•		•										
SNE098P-9	•	•															•		•										
SNE107P	•	•	•	•													•		•										
SNE107P	•	•	•	•													•		•										
SNE107P-2	•	•	•	•													•		•										
SNE107P-2	•	•	•	•													•		•										
SNE109P	•	•	•	•													•		•										
SNE109P	•	•	•	•													•		•										
SNE121P	•	•															•		•										
SNE124P-9	•	•															•		•										
SNE125P-9	•	•															•		•										
SNE127P	•	•															•		•										
SNE128P-9	•	•															•		•										
SNE131P	•	•															•		•										
SNE132P	•	•															•		•										
SNE134P	•	•															•		•										
SNE138P	•	•	•	•													•		•										
SNL045P	•	•	•					•	•	45 minutes in 1/5th second increments							•			•		•							
SNM041K	•	•															•										•		
SNM048K	•	•															•										•		
SNN233P	•	•						•	•	60 minutes in 1/5th second increments							•			•									
SNN235P	•	•						•	•	60 minutes in 1/5th second increments							•			•									
SNP007P-9	•	•	•	•		•											•					•		•	•	•			
SNP008P-9	•	•	•	•		•											•					•		•	•	•			
SNP017P-9	•	•	•	•		•											•					•		•	•	•			
SNP029P	•	•	•	•		•											•					•		•	•	•			
SNP039P	•	•	•	•		•											•					•		•	•	•			
SNP041P	•	•	•	•		•											•					•		•	•	•			
SNP042P	•	•	•	•		•											•					•		•	•	•			
SNP044P	•	•	•	•		•											•					•		•	•	•			
SNP044P	•	•															•			•						•			
SNP044P	•	•															•			•						•			
SNQ116P	•	•															•			•						•			
SNQ117P	•	•															•			•						•			
SNQ118P	•	•															•			•						•			
SNQ123P	•	•															•			•						•			
SNQ124P	•	•															•			•						•			
SNZE19K	•	•	•	•													•										•		
SNZE30K	•	•	•	•													•										•		
SNZE32K	•	•	•	•													•										•		
SNZE35K	•	•	•	•													•										•		
SNZG13K	•	•	•	•													•										•		
SNZH03K	•	•	•	•													•										•		
SNZH06K	•	•	•	•													•										•		
SNZH34K	•	•	•	•													•										•		
SPC049P	•	•					•	•	•	12 hours in 1/5th second increment		•	•				•			•									
SPC057P	•	•	•					•	•	60 minutes in 1/5th second increments							•			•									
SPC058P	•	•	•					•	•	60 minutes in 1/5th second increments							•			•									
SRH006P	•	•	•	•													•							•			•	•	
SRK021P	•																•			•									
SRK286P	•																•			•									
SRK293P	•																•			•									
SRK296P	•																•			•									
SRP132K	•	•	•	•											•		•									•	•		
SRP148K	•	•	•	•													•									•	•		
SRP162K	•	•	•	•													•									•	•		
SRP172K	•	•	•	•													•									•	•		
SRX003P	•	•	•	•		•											•							•			•		
SRX004P	•	•	•	•		•											•							•			•		
SSA023J-2	•	•															•									•	•		
SSA024J	•	•															•									•	•		
SSC002P	•	•					•	•	•	60 minutes in 1/5th second increments			•				•			•									
SSC002P	•	•					•	•	•	60 minutes in 1/5th second increments			•				•			•									
SSC003P	•	•					•	•	•	60 minutes in 1/5th second increments			•				•			•									
SSC003P	•	•					•	•	•	60 minutes in 1/5th second increments			•				•	</											



# PRODUCT INFORMATION MATRIX

Model Number	Category	Page	Band Reference	Glass Type	Water Resistance (Metres)	Stone Set Type	Stone Set Qty	Special Crown	Special Dial	Lumbrite Hands	Lumbrite Hour Markers	Calibre	Battery Type	Battery Life/Power Reserve (Approx)
SSC008P-2	Alarm Chronograph	29	MOFP218K0	Hardlex	100					•	•	V172	N/A	6 Months
SSC009P	Solar	25	MOFP218J0	Hardlex	100					•	•	V172	N/A	6 Months
SSC009P	Alarm Chronograph	29	MOFP218J0	Hardlex	100					•	•	V172	N/A	6 Months
SSC009P-3	Solar	25	L020012J0	Hardlex	100					•	•	V172	N/A	6 Months
SSC009P-3	Alarm Chronograph	29	L020012J0	Hardlex	100					•	•	V172	N/A	6 Months
SSC011P	Solar	25	MOFP218C0	Hardlex	100					•	•	V172	N/A	6 Months
SSC011P	Alarm Chronograph	29	MOFP218C0	Hardlex	100					•	•	V172	N/A	6 Months
SSC013P	Solar	25	L020011J0	Hardlex	100					•	•	V172	N/A	6 Months
SSC013P	Alarm Chronograph	29	L020011J0	Hardlex	100					•	•	V172	N/A	6 Months
SUJF60P	Ladies Dress Bracelet	52	4A432LM	Hardlex	WR							1N00	SR516SW	3 Years
SUJF63P	Ladies Dress Bracelet	52	4A432SM	Hardlex	WR							1N00	SR516SW	3 Years
SUJG16P-9	Ladies Dress Bracelet	52	4A3H1LX	Hardlex	WR	Diamond	2	Cabochon	Mother Of Pearl			1N00	SR516SW	3 Years
SUP019P	Solar	47	MO5F222J0	Hardlex	50							V114	N/A	12 Months
SUP022P	Solar	47	MO5F222K0	Hardlex	50							V114	N/A	12 Months
SUP024P	Solar	47	MOF0212C0	Hardlex	50							V114	N/A	12 Months
SUP026P	Solar	47	MOF0212K0	Hardlex	50							V114	N/A	12 Months
SUP027P	Solar	47	MO5F222C0	Hardlex	50							V114	N/A	12 Months
SUP028P	Solar	48	MOG2122C0	Hardlex	WR							V116	N/A	12 Months
SUP030P	Solar	48	MOG2122K0	Hardlex	WR							V116	N/A	12 Months
SUP032P	Solar	48	MOG2122K0	Hardlex	WR							V116	N/A	12 Months
SUP032P-2	Solar	48	L010011K0	Hardlex	WR							V116	N/A	12 Months
SUP032P-2	Ladies Dress Strap	53	L010011K0	Hardlex	WR							V116	N/A	12 Months
SUP052P	Solar	48	MOAB212C0	Hardlex	WR	Swarovski Crystals	22					V114	N/A	12 Months
SUP066P	Solar	46	MO5H222C0	Hardlex	50							V115	N/A	12 Months
SUP068P	Solar	46	MO5H222K0	Hardlex	50							V115	N/A	12 Months
SUP070P	Solar	47	MOFB212C0	Hardlex	50							V115	N/A	12 Months
SUP072P	Solar	47	MOFB212K0	Hardlex	50							V115	N/A	12 Months
SUP073P	Solar	46	MO5H222J0	Hardlex	50							V115	N/A	12 Months
SUP075P	Solar	47	MOFB212J0	Hardlex	50							V115	N/A	12 Months
SUP079P	Solar	47	MONM211C0	Hardlex	50							V115	N/A	12 Months
SUP080P	Solar	47	MONM211K0	Hardlex	50							V115	N/A	12 Months
SUP083P-9	Solar	48	MOAB212J9	Hardlex	WR	Swarovski Crystals	22		Mother Of Pearl			V115	N/A	12 months
SUP084P-9	Solar	48	MOAB212C9	Hardlex	WR	Swarovski Crystals	22					V115	N/A	12 months
SUP086P-9	Solar	48	MOAB212K9	Hardlex	WR	Swarovski Crystals	22		Mother Of Pearl			V115	N/A	12 months
SUP088P	Solar	48	MOAB212C0	Hardlex	WR	Swarovski Crystals	22					V114	N/A	12 Months
SUP892P	Solar	28	MOGW211K0	Hardlex	100							V115	N/A	12 Months
SUP893P	Solar	28	MOGW211C0	Hardlex	100							V115	N/A	12 Months
SUT022P	Solar	45	MOFD211C0	Hardlex	100					•	•	V187	N/A	2 Months
SUT024P	Solar	45	MOFD211K0	Hardlex	100					•	•	V187	N/A	2 Months
SUT027P	Solar	46	MO40227J0	Hardlex	50							V187	N/A	2 Months
SUT028P	Solar	46	MO40227C0	Hardlex	50							V187	N/A	2 Months
SUT030P	Solar	46	MO40221R0	Hardlex	50							V187	N/A	2 Months
SUT032P	Solar	46	MO40227K0	Hardlex	50							V187	N/A	2 Months
SUT033P	Solar	46	MOFZ211J0	Hardlex	50							V187	N/A	2 Months
SUT034P	Solar	46	MOFZ211C0	Hardlex	50							V187	N/A	2 Months
SUT036P	Solar	46	MOFZ212K0	Hardlex	50							V187	N/A	2 Months
SUT040P-9	Solar	45	MONL117C9	Hardlex	100							V187	N/A	2 Months
SUT041P-9	Solar	45	MONL112E9	Hardlex	100							V187	N/A	2 Months
SUT043P	Solar	45	MONL111J0	Hardlex	100							V187	N/A	2 Months
SUT044P	Solar	45	MONL111C0	Hardlex	100							V187	N/A	2 Months
SUT046P	Solar	45	MONL111K0	Hardlex	100							V187	N/A	2 Months
SXDA12P	Ladies Dress Strap	53	4LG3KZ	Sapphire	WR			Cabochon				7N82	SR621SW	2 Years
SXDA16P	Ladies Dress Strap	53	4LG5KZ	Sapphire	WR			Cabochon				7N82	SR621SW	2 Years
SXDA19P	Velatura	18	35M6JB	Sapphire	100	Diamond	36		Mother Of Pearl	•	•	7N82	SR621SW	2 Years
SXDA20P	Velatura	18	35M6LB	Sapphire	100	Diamond	36		Mother Of Pearl	•	•	7N82	SR621SW	2 Years
SXDA48P-9	Coutura	23	35R8VB	Sapphire	100	Diamond	20	Cabochon		•	•	7N82	SR621SW	2 Years
SXDA50P-9	Coutura	23	35R8VB	Sapphire	100			Cabochon		•	•	7N82	SR621SW	2 Years
SXDA74P	Ladies 50 Metre Bracelet	50	4A361KM	Hardlex	50							7N82	SR621SW	2 Years
SXDB37P	Ladies 100 Metre Bracelet	49	4A9Y2LM	Sapphire	100					•	•	7N82	SR621SW	2 Years
SXDB54P	Ladies 50 Metre Bracelet	50	4A361LM	Hardlex	100	Diamond	12	Cabochon	Mother Of Pearl			7N82	SR621SW	2 Years
SXDB56P	Ladies 50 Metre Bracelet	50	4A361RM	Hardlex	50	Diamond	9	Cabochon	Mother Of Pearl			7N82	SR621SW	2 Years
SXDB58P	Ladies 50 Metre Bracelet	50	4A362KM	Hardlex	100	Diamond	9	Cabochon	Mother Of Pearl			7N82	SR621SW	2 Years
SXDB88P-9	Ladies 100 Metre Bracelet	49	4A3E1LX	Hardlex	100				Mother Of Pearl	•	•	7N82	SR621SW	2 Years
SXDB94P	Ladies Dress Bracelet	52	4A3T1KM	Hardlex	WR				Mother Of Pearl			7N82	SR621SW	2 Years
SXDB96P	Ladies Dress Bracelet	52	4A3T1LM	Hardlex	WR							7N82	SR621SW	2 Years
SXDC11P-9	Ladies 100 Metre Bracelet	49	4A3E1JX	Hardlex	100	Diamond			Mother Of Pearl	•	•	7N82	SR621SW	2 Years
SXDC16P	Ladies 50 Metre Bracelet	51	4A4L1JM	Hardlex	50			Cabochon				7N82	SR621SW	2 Years
SXDC24P	Ladies Dress Bracelet	52	4AA11KM	Sapphire	WR			Cabochon				7N82	SR621SW	2 Years
SXDC25P	Ladies Dress Bracelet	52	4AA11JM	Sapphire	WR			Cabochon				7N82	SR621SW	2 Years
SXDC26P	Ladies Dress Bracelet	52	4AA11JM	Sapphire	WR			Cabochon				7N82	SR621SW	2 Years
SXDC32P	Ladies 50 Metre Bracelet	51	4A4W1KM	Hardlex	50							7N82	SR621SW	2 Years
SXDC36P-9	Ladies 50 Metre Bracelet	50	4A5C1LX	Hardlex	50			Cabochon				7N82	SR621SW	2 Years
SXDC58P	Ladies Dress Bracelet	52	MOG6112C0	Sapphire	WR			Cabochon				7N82	SR621SW	2 Years
SXDC77P	Ladies 50 Metre Bracelet	51	MO35337J0	Sapphire	50							7N82	SR621SW	2 Years
SXDC81P	Ladies 50 Metre Bracelet	51	MO35337C0	Sapphire	50							7N82	SR621SW	2 Years
SXDC82P	Ladies 50 Metre Bracelet	51	MO35337K0	Sapphire	50							7N82	SR621SW	2 Years
SXDC92P	Coutura	23	MONH111C0	Sapphire	100			Cabochon		•	•	7N82	SR621SW	2 Years
SXDC94P	Coutura	23	MONH111K0	Sapphire	100			Cabochon		•	•	7N82	SR621SW	2 Years
SXDC96P-9	Ladies 50 Metre Bracelet	51	MONK111C9	Hardlex	50					•	•	7N82	SR621SW	2 Years
SXDC98P-9	Ladies 50 Metre Bracelet	50	MOBW311C0	Hardlex	50			Cabochon				7N82	SR621SW	2 Years
SXDE02P	Premier	15	MON1111C0	Sapphire	100							7N82	SR621SW	2 Years
SXDE04P	Premier	15	MON1111K0	Sapphire	100				Mother Of Pearl			7N82	SR621SW	2 Years
SXDE06P	Coutura	23	MONH112D0	Sapphire	100			Cabochon		•	•	7N82	SR621SW	2 Years
SXDE07P	Coutura	23	MONH111J0	Sapphire	100			Cabochon		•	•	7N82	SR621SW	2 Years
SXDE09P-9	Ladies 50 Metre Bracelet	51	MONK111J9	Hardlex	50				Mother Of Pearl	•	•	7N82	SR621SW	2 Years
SXDE19P	Coutura	23	MONH111J0	Sapphire	100	Diamond	16	Cabochon		•	•	7N82	SR621SW	2 Years
SXDE20P	Coutura	23	MONH111C0	Sapphire	100	Diamond	16	Cabochon		•	•	7N82	SR621SW	2 Years
SXGN56P	Ladies Dress Strap	53	4J42KB	Hardlex	WR			Cabochon				1N01	SR521SW	2 Years
SZZC40P-9	Ladies Dress Bracelet	52	44Y2XB	Hardlex	WR							2E20	SR521SW	3 Years

## PRODUCT INFORMATION MATRIX

[illegible]


## PRODUCT INFORMATION MATRIX – STOPWATCH

Model Number	Page	Case Material	Band/Neck Strap Ref No.	Glass Type	Water Resistance (Metres)	Calibre	Battery Type	Battery Life/Power Reserve (Approx)	Time/Calendar Function	Stopwatch Count	Lap
S23535P	54	PC	BZA04N	HARDLEX		S351	CR2032	3 YEARS	•	100 HOURS IN 1 SECOND INCREMENTS	999
S23547J	54	PC	N/A	N/A		N/A	N/A	N/A	N/A	N/A	N/A
S23569J	54	PC	BZA02N	HARDLEX	WR	S143	CR2431	4 YEARS	•	10 HOURS IN 1/100TH SECOND INCREMENTS	999
S23571J	54	PC	BZA08N	HARDLEX		S149	CR2430	3 YEARS	•	1 HOUR IN 1/100TH SECOND INCREMENTS	999
S23589J	54	PC	4E22MB	ACRYLIC	WR	W073	CR2025	2 YEARS	•	100 HOURS IN 1/100TH SECOND INCREMENTS	99
S23593J	54	APC	BZA04N	HARDLEX	100	S141	CR2430	3 YEARS	•	10 HOURS IN 1/100TH SECOND INCREMENTS	300
S23601P	54	APC	DD83AD	ACRYLIC	50	S056	CR2032	3 YEARS	•	100 HOURS IN 1/100TH SECOND INCREMENTS	999
S23603P	54	APC	DD83AD	ACRYLIC	50	S057	CR2033	4 YEARS	•	100 HOURS IN 1/100TH SECOND INCREMENTS	999
S23605P	54	APC	DFY6JB	ACRYLIC	50	S058	CR2032	3 YEARS	•	100 HOURS IN 1/100TH SECOND INCREMENTS	999



## PRODUCT INFORMATION MATRIX – STOPWATCH

Model Number	Split	Memory	Countdown Timer	Other Functions
S23535P	999		100 HOURS IN 1 SECOND INCREMENTS	TIME CALCULATION, SPECIALTY TIMER FUNCTIONS FOR AUDIO AND VIDEO PRODUCTION ENVIRONMENTS
S23547J	N/A	N/A	N/A	REMOTE GRIPSWITCH FOR S23571J
S23569J	999	300 LAP/SPLIT		PRINTER CONNECTIVITY, MEMORY CAPACITY INDICATOR
S23571J	999	300 LAP/SPLIT		BUILT IN PRINTER, MEMORY CAPACITY INDICATOR, AUTO START FUNCTION, GRIP SWITCH CONNECTABILITY
S23589J	99	10 LAP/SPLIT	N/A	
S23593J	300	100 LAP/SPLIT	N/A	STROKES PER MINUTE 9 PLACE MEMORY, MEMORY CAPACITY INDICATOR
S23601P	999	100 LAP/SPLIT	N/A	AUTOMATIC BATTERY SAVE SHUT OFF
S23603P	999	100 LAP/SPLIT	TWO-CHANNEL COUNTDOWN TIMERS IN DECIMAL SYSTEM WITH AUTO REPEAT FUNCTION ACCOMPANIED WITH DIFFERENT ALARM SOUND TONES EACH CHANNEL CAN BE SET FROM 10 SECONDS UP TO 99 HOURS 59 MINUTES AND 59 SECONDS THE NUMBER OF TIMES THAT THE TIMERS REPEAT THEIR COUNTDOWN CYCLES CAN BE SET FROM 1 TO 100 TIMES.	AUTOMATIC BATTERY SAVE SHUT OFF
S23605P	999	100 LAP/SPLIT	2 X EACH CHANNEL CAN BE SET FOR FROM 10 SECONDS UP TO 99 HOURS 59 MINUTES AND 59 SECONDS (DOUBLE REPEAT)	LIGHT, AUTOMATIC BATTERY SAVE SHUT OFF



**Oscillating Weight**

Movement of the wearer rotates the oscillating weight.

**Rotor**

Transforms every movement of the oscillating weight into a magnetic charge.

**Rechargeable Long-Life Battery**

Stores the generated electrical energy.

**Generating Electricity**

The natural movement of your body is sensitively transformed into electrical energy.

**Storing Electricity**

A high performance long-life **rechargeable** battery stores the energy to power the watch.

**Utilising Electricity**


Advanced electronic circuitry ensures that the energy is converted with optimum efficiency into a quartz signal.

**Circuit Block**

Controls voltage and amperage. And by quartz oscillation, it produces a precise watch signal.

# SEIKO SOLAR



## No Battery Change Required



**SEIKO. Solar watch experts since 1977**

### KINETIC (5M62/5M54)

- Hour, minute and second hands.
- Calendar (Date).
- Day indicator (5M54).
- Automatic Power Generator.
- Energy Depletion Forewarning.
- Overcharge Prevention Function.
- 6 Month Power Storage.



#### HOW TO START THE WATCH

When using the watch for the first time be sure to charge the Rechargeable Battery sufficiently by swinging the watch from side to side before setting the time and other functions.

1. Swing the watch side to side at a rate of twice per second.
2. After the watch is swung for approx. 2 to 3 minutes, and the second hand begins to move in one-second intervals there is about six hours of power available. It is not necessary to charge the rechargeable battery fully before you wear the watch. While the watch is on your arm, the Automatic Power Generator will ensure constant operation.

**Notes:** 1. To charge the rechargeable battery efficiently, swing the watch from side to side, making an arc of about 20cm. 2. No additional benefit is obtained by swinging the watch more quickly or with greater vigor. 3. When the watch is swung, the oscillating weight in the generating system rotates to drive the mechanism. As it rotates, it creates a sound: this is not a malfunction.

#### HOW TO SET TIME

The Seiko Kinetic series of watches are basic analogue and can be set the same as any 2 or 3 hand watch.

1. Pull out the crown to the second click.
2. Turn the crown to set hour and minute hands.
3. Push crown back to normal position.

**Notes:** 1. When setting the hour hand, check that AM/PM is correctly set. The watch is so designed that the calendar/day changes once in 24 hours. Turn the hands past the 12 o'clock marker to determine whether the watch is set for the AM or PM period. If the calendar/day changes, the time is set for the AM period. If the calendar/day does not change, the time is set for the PM period. 2. When setting the minute hand, advance it 4 to 5 minutes ahead of the desired time and then turn it back to the exact time.

#### POWER RESERVE INDICATOR

By pressing Button A once when the second hand is in 12 position the watch can indicate how much power is stored in the rechargeable battery.


If the second hand advances to the;

- 1 position the watch has between approximately 1 and 7 days.
- 2 position the watch has between 7 days and 1 month.
- 4 position the watch has between 1 and 4 months.
- 6 position the watch has between 4 and 6 months.



## KINETIC PERPETUAL (7D46/7D48)

- Hour, minute and second hands.
- Calendar (Date).
- Automatic Power Generator.
- Automatic Energy Saving Function.
- Time Relay Function.
- Perpetual Calendar.
- Energy Depletion Forewarning Function.
- Overcharge Prevention Function.
- 4 Year Power Storage.



### HOW TO START THE WATCH

When using the watch for the first time be sure to charge the Rechargeable Battery sufficiently by swinging the watch from side to side before setting the time and other functions.

1. Swing the watch side to side at a rate of twice per second.
2. After the watch is swung for approximately 500 times, the second hand begins to move in 1 second intervals. A further 200 swings will ensure about 1 day of power available. It is not necessary to charge the rechargeable battery fully before you wear the watch. While the watch is on your arm, the Automatic Power Generator will ensure constant operation.

**Note:** 1. Wearing the watch continuously for 12 hours will accumulate power to run the watch for approximately one and a half additional days. As a general guideline, if you wear the watch everyday for 12 hours over a period of a week, the power to run the watch for approximately 10 days will be additionally secured. If the watch enters the power save mode, this amount of energy will keep the watch running for approximately one month and a half. 2. No additional benefit is obtained by swinging the watch more quickly or with greater vigor. 3. When the watch is swung, the oscillating weight in the generating system rotates to drive the mechanism. As it rotates, it creates a sound; this is not a malfunction.

### AUTOMATIC POWER SAVE FUNCTION

In order to conserve the stored electrical energy, the watch automatically enters Power Save Mode to stop the hands from moving approximately 24 hours after the watch is left untouched. In a case that the fully charged watch enters the power save mode, the Time Relay Function of the watch remains operable for approximately 4 years.

### PERPETUAL CALENDAR FUNCTION

Once set, the calendar automatically adjusts for odd and even months including February of leap years until the year 2100. While the watch is in power save mode, the perpetual calendar continues to function (the calendar continues to properly advance).

### ENERGY DEPLETION FOREWARNING FUNCTION

When the second hand starts moving in two-second intervals instead of the normal one-second interval, the watch will run down in approximately 12 hours. If the power save function has been turned off by swinging the watch, and the second hand starts to move in two-second intervals, then the power reserve may have been drained to an extremely low level. In either case, charge the watch using the procedure above.

### HOW TO SET TIME AND DATE

Because the calendar is pre-adjusted at the factory, you may only need to set the time and date. Pull out the crown out to the second click. The second hand will stop on the spot. Turn the crown to set the time. Remember to check the 24 hour indicator to correctly set AM or PM. To set the time accurately, advance the minute hand 4 to 5 minutes ahead of the correct time, and then turn it back to the exact time.

To adjust the date pull the crown out to the first click. Rotate crown in either way to adjust to the correct date.

**Note:** Do not pull the crown out to adjust the date/time until the Time Relay Function is complete. This will cause the time data retained inside the watch to be erased, thus disabling the Time Relay Function.

### HOW TO DO A COMPLETE CALENDAR ADJUSTMENT


Complete calendar adjustment is only necessary if the watch is completely stopped due to shortage of stored energy. Each calendar item should be adjusted in sequence of year, month and date.

1. Pull out crown to first click.
2. Rotate crown to advance date and month until the correct year is displayed.  
Refer to the Leap Year Chart to determine if the current year is a leap year or to determine if it is 1, 2 or 3 years past the last leap year.
3. After setting the watch to the correct year, continue to rotate the crown to set the correct month and then the correct date.
4. Pull crown out to second click to set the correct time  
(see How To Set Time And Date).
5. Push crown back to original position.

**Note:** The date, month and year indicators work independently from the hands of the watch. Advancing the hands will not advance the date, month or year.

## KINETIC DIRECT DRIVE (5D44)


- Time/Calendar.
- Hour, minute, second hands.
- Date, retrograde day indicator.
- Direct Drive Indicator.
- Power reserve indicator.
- Real-time power indicator.
- Crown with Driving Wheel.
- Hand winding Capability.
- System reset.



❖ The position of the date window and day hand may differ depending on the model.

### CROWN WITH DRIVING WHEEL

- ◆ Some models may have a crown with a special structure as illustrated below. Refer to the following instructions when operating this type of crown, as it should be operated in a different way from that of ordinary ones.



To pull out the crown, pull out the **A portion** (crown).  
To turn the crown, turn the **B portion** (driving wheel).

### HOW TO CHARGE AND START THE WATCH

1. Turn the crown clockwise repeatedly to charge the watch.
2. As electric power is generated by the continuous turning of the driving wheel, the Direct Drive indicator hand will move to point at scale marking 0 and the second hand will start moving.
3. Continue to turn the crown to sufficiently charge the watch.
  - The Direct Drive indicator hand will move up and down to display the electric power generation status.
  - After charging the watch, the indicator hand will display the amount of power generated by the current manual winding for approximately 4 seconds, and then the hand returns to display the total amount of power reserve.
  - A fully charged watch will keep on operating for approximately 1 month.

### HOW TO READ THE DIRECT DRIVE INDICATOR

The direct drive indicator can be used to check:

- Power reserve amount.
- Real-time power generation status and newly generated amount of power while charging the watch.

#### Power reserve indicator

- The watch checks power reserve in the rechargeable battery and display how long the watch will keep operating in 18 steps.
- If the indicator hand moves to the 0 position, the watch will stop operating within 3 hours. When the watch stops, the indicator hand moves to the standby position to show that the watch stops operating due to power shortage.

#### Real-time power indicator

- When turning the driving wheel to charge the watch, the watch checks the newly generated amount of power and display in 19 steps (0-“M+1” scale marking).
- A maximum 6 hours of generated power can be displayed.

### HOW TO READ THE DIRECT DRIVE INDICATOR WHILE CHARGING THE WATCH

1. Turn the crown clockwise. After approximately 1 second, the direct drive indicator hands starts moving.
2. Indicator to turn the crown. The indicator hand moves upward and downward according to the power generation status. The faster the crown is turned the more power it generates.

3. Stop turning the crown, the direct dive indicator will display the total amount of power generated. After approximately 4 second the direct drive indicator will display the total amount of power reserve.

### HOW TO SET TIME

1. Pull the crown out to the second click. When the second hand is at the 12 o'clock position.
2. Turn the crown to set the time.
3. When finish setting the time push the crown back to normal position.

### HOW TO SET THE DATE AND DAY

1. Pull the crown out to the first click.
2. Turn the crown anticlockwise until the current date.
3. Turn the crown clockwise to set the day hand to point at the correct day of the week.
4. Push the crown back to the normal position.

### RESETTING THE BUILT-IN IC

When the watch stops operating even through it displays the remainder of the power reserve, follow the instruction below to reset the built-in IC.

1. Pull the crown out to the second click.
2. Press the reset button for 2 seconds or longer using a sharp-pointed tool.
3. Push the crown back into the normal position.
4. Turn the driving wheel to charge the watch at least until the indicator hand points at the second marking above “0”. And then set the time, date, and day of the week.
  - After resetting the built-in IC, all the generated/reserve power will be lost.
  - The indicator hand will point at 0 position, and the watch resume its normal operation.

### AUTOMATIC HAND ALIGNMENT

The position of the indicator hand may move out of alignment in rare cases. The watch automatically corrects the position of the indicator hand once every 24 hours. While correcting the hand position, the indicator hand may move abnormally, however, this is not a malfunction. After automatic hand alignment is performed, the indicator hand will return to display power reserve amount. When automatic hand alignment starts, the indicator hand moves to the area under the 0 position and vibrates, and then points at the 0 position. After automatic hand alignment is completed, the indicator hand returns to display power reserve amount.

#### ■ SCALE TABLE OF POWER RESERVE AMOUNT AND GENERATED POWER AMOUNT

Scale marking	Standby position	0	1	2	3	4	5	6	7	8	9	10	11
Indication on dial		0				12 (12 h)				D (Day)			
Power reserve amount	The watch stops operating.	0	3 H	6 H	9 H	12 H	15 H	18 H	21 H	1 D	2 D	3 D	4 D
Amount of generated power		0	20 Min.	40 Min.	1 H	1 H 20 Min.	1 H 40 Min.	2 H	2 H 20 Min.	2 H 40 Min.	3 H	3 H 20 Min.	3 H 40 Min.


  

Scale marking	12	13	14	15	16	17	18
Indication on dial	0		W (Week)		12	M (Month)	
Power reserve amount	5 D	6 D	1 W	2 W	3 W	30 D	
Amount of generated power	4 H	4 H 20 Min.	4 H 40 Min.	5 H	5 H 20 Min.	5 H 40 Min.	6 H

H : Hour  
D : Day  
W : Week  
\* The minimum amount of power reserve and generated power is described in the table.

## KINETIC DIRECT DRIVE

- Time/Calendar.
- Hour, minute, second hands.
- Date.
- Direct Drive Indicator.
- Power reserve indicator.
- Real-time power indicator.
- Hand winding Capability.
- System reset.



❖ The position of the date window may differ depending on the model.

### HOW TO CHARGE AND START THE WATCH

1. Turn the crown clockwise repeatedly to charge the watch.
  2. As electric power is generated by the continues turning of the crown, the Direct Drive indicator hand will moves to point at scale marking 0 and the second hand will start moving.
  3. Continue to turn the crown to sufficiently charge the watch.
- The Direct Drive indicator hand will moves up and down to display the electric power generation status.
  - After charging the watch, the indicator hand will display the amount of power generated by the current manual winding for approximately 4 seconds, and then the hand returns to display the total amount of power reserve.
  - A fully charged watch will keep on operating for approximately 1 month.

### HOW TO READ THE DIRECT DRIVE INDICATOR

The direct drive indicator can be used to check:

- Power reserve amount.
- Real-time power generation status and newly generated amount of power while charging the watch.

#### Power reserve indicator

- The watch checks power reserve in the rechargeable battery and display how long the watch will keep operating in 18 steps.
- If the indicator hands moves to the 0 position, the watch will stop operating within 3 hours. When the watch is stops, the indicator hand moves to the standby position to show that the watch stops operating due to power shortage.

#### Real-time power indicator

- When turning the crown to charge the watch, the watch checks the newly generated amount of power and display in 19 steps (0-“M+1” scale marking)
- A maximum 6 hours of generated power can be displayed.

### HOW TO READ THE DIRECT DRIVE INDICATOR WHILE CHARGING THE WATCH

1. Turn the crown clockwise. After approximately 1 second, the direct drive indicator hands starts moving.
2. Continue to turn the crown. The indicator hand moves upward and downward according to the power generation status. The faster the crown is turned the more power it generates.
3. Stop turning the crown, the direct dive indicator will display the total amount of power generated. After approximately 4 second the direct drive indicator will display the total amount of power reserve.

### HOW TO SET TIME

1. Pull the crown out to the second click. When the second hand is at the 12 o'clock position.
2. Turn the crown to set the time.
3. When finish setting the time push the crown back to normal position.

### HOW TO SET THE DATE

1. Pull the crown out to the first click.
2. Turn the crown anticlockwise until the current date.

### RESETTING THE BUILT-IN IC

When the watch stops operating even through it displays the remainder of the power reserve, follow the instruction below to reset the built-in IC.

1. Pull the crown out to the second click.
  2. Press the reset button for 2 seconds or longer using a sharp-pointed tool.
  3. Push the crown back into the normal position.
  4. Turn the crown to charge the watch at least until the indicator hand points at the second marking above “0”. And then set the time, date, and day of the week.
- After resetting the built-in IC, all the generated/reserve power will be lost.
  - The indicator hand will point at 0 position, and the watch resume its normal operation.

### ■ SCALE TABLE OF POWER RESERVE AMOUNT AND GENERATED POWER AMOUNT

Scale marking	Standby position	0	1	2	3	4	5	6	7	8	9	10	11
Indication on dial		0				12 (12 h)				D (Day)			
Power reserve amount	The watch stops operating.	0	3 H	6 H	9 H	12 H	15 H	18 H	21 H	1 D	2 D	3 D	4 D
Amount of generated power		0	20 Min.	40 Min.	1 H	1 H 20 Min.	1 H 40 Min.	2 H	2 H 20 Min.	2 H 40 Min.	3 H	3 H 20 Min.	3 H 40 Min.

Scale marking	12	13	14	15	16	17	18
Indication on dial	0		W (Week)		12	M (Month)	
Power reserve amount	5 D	6 D	1 W	2 W	3 W	30 D	
Amount of generated power	4 H	4 H 20 Min.	4 H 40 Min.	5 H	5 H 20 Min.	5 H 40 Min.	6 H

*H : Hour  
D : Day  
W : Week  
\* The minimum amount of power reserve and generated power is described in the table.*


### AUTOMATIC HAND ALIGNMENT

The position of the indicator hand may move out of alignment in rare cases.

The watch automatically corrects the position of the indicator hand once every 24 hours. While correcting the hand position, the indicator hand may move abnormally, however, this is not a malfunction. After automatic hand alignment is performed, the indicator hand will return to display power reserve amount. When automatic hand alignment starts, the indicator hand moves to the area under the 0 position and vibrates, and then points at the 0 position. After automatic hand alignment is completed, the indicator hand returns to display power reserve amount.


## KINETIC DIRECT DRIVE MOON PHASE (5D88)

- Time/Calendar.
- Hour, minute, second hands.
- Moon Phase Indicator.
- Date, day indicator.
- Direct Drive Indicator.
- Power reserve indicator.
- Real-time power indicator.
- Hand winding Capability.
- System reset.



### CROWN WITH DRIVING WHEEL

- ◆ Some models may have a crown with a special structure as illustrated below. Refer to the following instructions when operating this type of crown, as it should be operated in a different way from that of ordinary ones.



To pull out the crown, pull out the **A portion** (crown).  
To turn the crown, turn the **B portion** (driving wheel).

### HOW TO CHARGE AND START THE WATCH

1. Turn the crown clockwise repeatedly to charge the watch.
2. As electric power is generated by the continues turning of the driving wheel, the Direct Drive indicator hand will moves to point at scale marking 0 and the second hand will start moving.
3. Continue to turn the crown to sufficiently charge the watch.
  - The Direct Drive indicator hand will moves up and down to display the electric power generation status.
  - After charging the watch, the indicator hand will display the amount of power generated by the current manual winding for approximately 4 seconds, and then the hand returns to display the total amount of power reserve.
  - A fully charged watch will keep on operating for approximately 1 month.

### HOW TO READ THE DIRECT DRIVE INDICATOR

The direct drive indicator can be used to check:

- Power reserve amount.
- Real-time power generation status and newly generated amount of power while charging the watch.

#### Power reserve indicator

- The watch checks power reserve in the rechargeable battery and display how long the watch will keep operating in 18 steps.
- If the indicator hands moves to the 0 position, the watch will stop operating within 3 hours. When the watch is stops, the indicator hand moves to the standby position to show that the watch stops operating due to power shortage.

#### Real-time power indicator

- When turning the driving wheel to charge the watch, the watch checks the newly generated amount of power and display in 19 steps (0-“M+1” scale marking).
- A maximum 6 hours of generated power can be displayed.

### HOW TO READ THE DIRECT DRIVE INDICATOR WHILE CHARGING THE WATCH

1. Turn the crown clockwise. After approximately 1 second, the direct drive indicator hands starts moving.
2. Continue to turn the crown. The indicator hand moves upward and downward according to the power generation status. The faster the crown is turned the more power it generates.
3. Stop turning the crown, the direct dive indicator will display the total amount of power generated. After approximately 4 second the direct drive indicator will display the total amount of power reserve.

### HOW TO SET TIME

1. Pull the crown out to the second click. When the second hand is at the 12 o'clock position.
2. Turn the crown to set the time.
3. When finish setting the time push the crown back to normal position.

### HOW TO SET THE DATE AND DAY

1. Pull the crown out to the first click.
2. Turn the crown anticlockwise until the current date.
3. Turn the crown clockwise to set the day hand to point at the correct day of the week.
4. Push the crown back to the normal position.

### HOW TO SET THE MOON PHASE


- The moon phase represents the period from the time when the last new moon occurred to noon of the current day in day increments.
- The period between new moons is called a “synodic month,” and its average length is approximately 29.5 days.

1. Press the but ton using an object with a long tapered tip such as a ballpoint pen. When the but ton is pressed, the moon phase advances by one phase.

Round off the number of moon phases to the nearest whole number.

(Example; 7.8 → 8, 24.2 →24 )

- \* Refer to the weather report of your local newspaper for current moon phase information.
- \* Do not set the moon phase between 9 p.m. and 1 a.m., as the moon phase may not change to the correct display on the following day.



Moon phase 0 (new moon)	Moon phase 7	Moon phase 15 (full moon)	Moon phase 22



## KINETIC DIRECT DRIVE MOON PHASE (5D88) CONTINUED

### RESETTING THE BUILT-IN IC

When the watch stops operating even through it displays the remainder of the power reserve, follow the instruction below to reset the built-in IC.

1. Pull the crown out to the second click.
2. Press the reset button for 2 seconds or longer using a sharp-pointed tool.
3. Push the crown back into the normal position.
4. Turn the driving wheel to charge the watch at least until the indicator hand points at the second marking above "0". And then set the time, date, and day of the week.
  - After resetting the built-in IC, all the generated/reserve power will be lost.
  - The indicator hand will point at 0 position, and the watch resume its normal operation.

### AUTOMATIC HAND ALIGNMENT

The position of the indicator hand may move out of alignment in rare cases.

The watch automatically corrects the position of the indicator hand once every 24 hours. While correcting the hand position, the indicator hand may move abnormally, however, this is not a malfunction. After automatic hand alignment is performed, the indicator hand will return to display power reserve amount. When automatic hand alignment starts, the indicator hand moves to the area under the 0 position and vibrates, and then points at the 0 position. After automatic hand alignment is completed, the indicator hand returns to display power reserve amount.

■ SCALE TABLE OF POWER RESERVE AMOUNT AND GENERATED POWER AMOUNT

Scale marking	Standby position	0	1	2	3	4	5	6	7	8	9	10	11
Indication on dial		0				12 (12 h)				D (Day)			
Power reserve amount	The watch stops operating.	0	3 H	6 H	9 H	12 H	15 H	18 H	21 H	1 D	2 D	3 D	4 D
Amount of generated power		0	20 Min.	40 Min.	1 H	1 H 20 Min.	1 H 40 Min.	2 H	2 H 20 Min.	2 H 40 Min.	3 H	3 H 20 Min.	3 H 40 Min.


  

Scale marking	12	13	14	15	16	17	18
Indication on dial	0		W (Week)		12	M (Month)	
Power reserve amount	5 D	6 D	1 W	2 W	3 W	30 D	
Amount of generated power	4 H 20 Min.	4 H 40 Min.	4 H 20 Min.	5 H	5 H 20 Min.	5 H 40 Min.	6 H

*H: Hour*  
*D: Day*  
*W: Week*  
*\* The minimum amount of power reserve and generated power is described in the table.*

### KINETIC CHRONOGRAPH (7L22)

- Hour, minute and second hands.
- Calendar (Date).
- Stopwatch minute and 1/5th second hands.
- Stopwatch measures up to 45 minutes in 1/5th of a second.
- Automatic Power Generator.
- Energy Depletion Forewarning Function.
- Overcharge Prevention Function.
- 5 Month Power Storage.



#### HOW TO CHARGE AND START THE WATCH

When using the watch for the first time be sure to charge the Rechargeable Battery sufficiently by swinging the watch from side to side before setting the time and other functions.

1. Swing the watch side to side at a rate of twice per second.
2. After the watch is swung for approximately 500 times, the second hand begins to move in 1 second intervals. A further 200 swings will ensure about 1 day of power available. It is not necessary to charge the rechargeable battery fully before you wear the watch. While the watch is on your arm, the Automatic Power Generator will ensure constant operation.

**Notes:** 1. No additional benefit is obtained by swinging the watch more quickly or with greater vigor.  
2. When the watch is swung, the oscillating weight in the generating system rotates to drive the mechanism. As it rotates, it creates a sound: this is not a malfunction. 3. Do not pull the crown out to the second click position with the intention of stopping the second hand just to save energy. By doing so, a large amount of current flows through the built-in IC. Therefore, pulling the crown out to the second click position will not save energy but, in fact, consume more energy than usual.

#### ENERGY DEPLETION FOREWARNING FUNCTION

When the second hand starts moving in two-second intervals instead of the normal one-second interval, the watch will run down in approximately 12 hours.

#### HOW TO SET TIME AND DATE

1. Pull crown out to the first click position (unscrew crown if your watch is fitted with this feature).
2. Turn crown counter clockwise until the previous day's date appears.
3. Pull crown out to second click position.
4. Turn counter clockwise to advance the hour and minute hands past 12am. Doing so will advance the date to the current date.
5. Set hour and minute hands to desired time. Ensure you consider AM/PM period.
6. Push crown back in completely. (Ensure you screw crown back in if fitted with this feature.)

#### HOW TO USE STOPWATCH

The stopwatch can measure up to 45 minutes in 1/5th of a second increments.


After 48 minutes, the stopwatch stops automatically.

- Press Button 'A' to start, stop and restart the stopwatch.
- Press Button 'B' to reset the stopwatch.

\* Do not press Buttons 'A' and 'B' at the same time, or press one of the two buttons.

## PERPETUAL CALENDAR (6A32)

- Hour, minute and second hands.
- Calendar (Date).
- Once set, the calendar automatically adjusts for odd and even months including February of leap years up to February 28th 2100.
- Can indicate the year, month and date.



a: Normal position      b: First click      c: Second click

### BEFORE USING THE WATCH

Because the calendar is pre-adjusted at the factory, you only need to set the time and date and the calendar will automatically update itself. \*Before using the watch, set the time and date.

### HOW TO SET TIME AND DATE

1. Pull out the crown out to the second click when the second hand is at the 12 o'clock position.
2. Turn the crown in either direction to set the time and date.
3. Push the crown back completely when set to desired time.

Follow the procedures below to check the calendar and, if necessary, to adjust it.

- Do not check and adjust the calendar between 11pm and 1am. If the calendar is checked and adjusted between these times, the date may not change properly. In such case, first change the time to any time outside this period, and then set the date. After that, move the hands back to the correct time.
- If the crown is pulled out to the second click while the numeral in the calendar frame is advancing or moving back, the second hand may be misaligned from the 12 o'clock position (initial position).
- The button and crown operation cannot be made while the numeral in the calendar frame is advancing or moving back. Press the button or turn the crown after then numeral stops.
- If the watch is left untouched for more than 2 to 3 minutes while checking or adjusting the calendar, the watch will resume normal movement. In such a case, start again from the beginning of the procedures.

- Do not leave the crown at the first or second click when you use the watch, as this will shorten the battery life.


### BATTERY LIFE INDICATOR

When the second hand starts moving at two-second intervals instead of the normal one-second interval, replace the battery with a new one as soon as possible. Otherwise, the watch will stop operating in a couple of days. Time accuracy is not affected even if the hands are moving at two-second intervals. While the second hand is moving at two-second intervals, the date will not change. This is not a malfunction.

### CHECKING AND ADJUSTMENT OF THE CALENDAR AFTER BATTERY CHANGE

After the battery is replaced, be sure to check that the calendar is correct. If the watch does not indicate the year, month and date correctly adjust the calendar (see 'How To Check And Adjust The Calendar').


### HOW TO CHECK AND ADJUST CALENDAR




1) Pull crown out to first click.




2) Zero Matching.  
The Second Position  
The second hand moves to the initially set zero position which should be exactly at the 12 o'clock. If not, adjust it by turning the crown. Then press the button. The calendar disk also moves to the initially set zero position within this stage.




3) Zero Matching the Calendar Disk.  
The calendar disk swings back and forth for one time to show that you are adjusting the zero position of the calendar disk. The calendar disk should show the initially set zero position which is '1'. If not, adjust it by turning the crown. Then press the button.




4) Adjusting the Date.  
The second hand moves to 9 o'clock position to show that you are now adjusting the date. The calendar disk moves to the initially set current date. Adjust it, if necessary, by turning the crown. Then press the button.



5) Adjusting the Month.  
The second hand moves to 10 o'clock position to show that you are now adjusting the month. The calendar disk moves to the initially set current month. Adjust it, if necessary, by turning the crown. Then press the button.



6) Adjusting the Year.  
The second hand moves to 11 o'clock position to show that you are now adjusting the year. The calendar disk moves to the initially set current year. Adjust it, if necessary by turning the crown (the calendar displays the last 2 digits of the Christian Era until 2032, it will display 4). Refer year table, then press the button.



7) Completing the Adjustment. The calendar adjustment is completed by pushing the crown back to the normal position.

## OPERATING INSTRUCTIONS

---


### YEAR TABLE

LAST 1 OR 2 DIGITS OF THE YEAR	NUMBER OF YEARS SINCE THE LAST LEAP YEAR	YEAR	YEAR	YEAR	YEAR
4	Leap Year		2032	2060	2088
5	1 Year	2005	2033	2061	2089
6	2 Year	2006	2034	2062	2090
7	3 Year	2007	2035	2063	2091
8	4 Year (Leap Year)	2008	2036	2064	2092
9	1 Year	2009	2037	2065	2093
10	2 Year	2010	2038	2066	2094
11	3 Year	2011	2039	2067	2095
12	4 Year (Leap Year)	2012	2040	2068	2096
13	1 Year	2013	2041	2069	2097
14	2 Year	2014	2042	2070	2098
15	3 Year	2015	2043	2071	2099
16	4 Year (Leap Year)	2016	2044	2072	
28	4 Year (Leap Year)	2028	2056	2084	
29	1 Year	2029	2057	2085	
30	2 Year	2030	2058	2086	
31	3 Year	2031	2059	2087	



## CHRONOGRAPH PERPETUAL (7T86)

- Time.
- Day/Date indicator.
- Month/Year check on demand.
- Stopwatch measures 24 hours in 1/5th of a second increments.
- Alarm – 24 hour.
- Perpetual Calendar automatically adjusts until Feb 2100.



### HOW TO CHANGE MODE

Press Button B to change mode from 'Calendar/Alarm Mode' to 'Stopwatch Mode'.

### HOW TO SET TIME AND ALARM DIAL TIME

- 1) Pull crown out to 2nd click when the small second hand is at the 60 second mark. The small second hand will stop immediately.
- 2) Turn the crown to set the main dial time.
- 3) Press button B to set the alarm sub-dial time in 24 hour format.  
E.g 6pm is 18:00.

### HOW TO ADJUST PERPETUAL CALENDAR

- 1) Pull crown out to 1st Click.
- 2) Press button A for 5 seconds – the calendar hand will sweep around the dial.
- 3) Press B to set the date (hand will move quickly if kept pressed).
- 4) Press A once and the day indicator will point to CHR.
- 5) Press B to adjust the day of the week.
- 6) Press A and the calendar hand will point to the month.
- 7) Press B to adjust the month.
- 8) Press A and the calendar hand will point to the leap year indicators.
- 9) Press B to set the year (you must know the number of years elapsed since last leap year).
- 10) Press A to return to Date setting mode.
- 11) Press the crown back to the normal position.

### HOW TO USE THE STOPWATCH

- 1) In the normal crown model Press B, and the Day/Mode hand will point to CHR.
- 2) Press Button A to start and stop the stopwatch.
- 3) Press Button B to reset the stopwatch.
- 4) To perform split/lap times Press button B while the stopwatch is running, then B to release the hands to continue with timing.


### HOW TO USE THE ALARM

Ensure you have set the time of the alarm dial under the 'HOW TO SET TIME & ALARM DIAL'.

- 1) Pull crown out to first click.
  - 2) Press Button B set desired alarm time (keeping button B pressed will make the hands move faster) This dial is a 24 hour dial, so 6pm is 18:00.
  - 3) After desired time has been set press the crown back to the normal position.
- Alarm will sound for 20 seconds at desired time. To turn off alarm press Button A or B. To cancel an alarm set, pull crown out to first click and then press crown back to normal position.

### ALARM CHRONOGRAPH (7T62)

- Hour, minute and small second hands.
- Calendar (Date).
- Stopwatch minute and 1/5th second hands.
- Stopwatch measures up to 60 minutes in 1/5th of a second increments.
- Alarm can be set on a 12 hour basis, or, can be used as a second time zone.



#### HOW TO SET TIME AND DATE

1. Pull crown out to the first click position (unscrew crown if your watch is fitted with this feature).
2. Turn crown counter clockwise until the previous day's date appears.
3. Pull crown out to second click position.
4. Turn counter clockwise to advance the hour and minute hands past 12am. Doing so will advance the date to the current date.
5. Set hour and minute hands to desired time. Ensure you consider AM/PM period.
6. Push crown back in completely. (Ensure you screw crown back in if fitted with this feature.)

#### HOW TO SET ALARM TIME

1. Pull the crown out to the second click position.
2. Press 'B' to set the alarm hour and minute hands to the correct time.
3. Push the crown back to the normal position. Once the time is set, you do not have to adjust again unless there is a change in time (e.g. daylight savings).
4. For a dual time zone adjust hands on any desired time.

#### HOW TO SET ALARM

1. Pull the crown to the first click position.
2. Press button 'B' to set the alarm hour and minute hands to desired alarm time.
3. Push the crown back to the normal position.

**Note:** Alarm setting on a 12 hour basis only. Alarm will ring at the designated time for 20 seconds; one time only alarm. The alarm needs to be reset in order to re-engage the alarm function.

#### HOW TO USE STOPWATCH

The stopwatch can measure up to 60 minutes in 1/5th of a second increments. Press Button 'A' to start, stop and restart the stopwatch.

- Press Button 'A' to start/stop/restart the stopwatch.
  - Press Button 'B' to split/split release/reset the stopwatch.
- \* Do not press Buttons 'A' and 'B' at the same time, or press one of the two buttons while keeping the other pressed.

#### HOW TO ADJUST HAND POSITION

1. If chronograph hands will not return the 12 o'clock position when the chronograph is reset or when the battery is replaced with a new one, follow the procedure below to reset the hands to the correct position.
2. Pull crown out to the second click.
- Press and hold button 'A'. The stopwatch minute hand will sweep around dial. Press button 'B' to adjust minute hand.
- Press and hold button 'A'. The stopwatch 1/5th of a second hand will sweep around dial. Press button 'B' to adjust 1/5th of a second hand.
3. Push crown back into normal position.


**Note:** Holding in button 'B' when adjusting the hand position, hands will move faster.

#### HOW TO USE ALARM DIAL AS DUAL TIME DISPLAY

1. Pull the crown out to the second click position.
2. Press the button "B" to set the hour and minute hands to time of a different time zone.
3. Push the crown back to normal position.

## CHRONOGRAPH (7T04)

- Hour, minute and small second hands.
- Calendar (Date).
- Stopwatch minute, and 1/5th second hands.
- Stopwatch measures up to 60 minutes in 1/5th of a second increments.
- 24 hour hand



### HOW TO SET TIME AND DATE

- Pull crown out to the first click position (unscrew crown if your watch is fitted with this feature).
- Turn crown counter clockwise until the previous day's date appears.
- Pull crown out to second click position.
- Turn crown clockwise to advance the hour and minute hands past 12am. Doing so will advance the date to the current date.
- Set hour and minute hands to desired time. Ensure you consider AM/PM period.
- Push crown back in completely. (Ensure you screw crown back in if fitted with this feature).

### HOW TO USE STOPWATCH


- The stopwatch can measure up to 60 minutes in 1/5th of a second increments.
- Press Button 'A' to start/stop/restart the stopwatch.
- Press Button 'B' to split/split release/reset the stopwatch.
- Do not press Buttons 'A' and 'B' at the same time, or press one of the two buttons while keeping the other pressed.

## OPERATING INSTRUCTIONS

---

### CHRONOGRAPH (7T94)

- Hour, minute and small second hands.
- Calendar (Date).
- Stopwatch minute, and 1/5th second hands.
- Stopwatch measures up to 60 minutes in 1/5th of a second increments.



#### HOW TO SET TIME AND DATE

- Pull crown out to the first click position (unscrew crown if your watch is fitted with this feature).
- Turn crown counter clockwise until the previous day's date appears.
- Pull crown out to second click position.
- Turn counter clockwise to advance the hour and minute hands past 12am. Doing so will advance the date to the current date.
- Set hour and minute hands to desired time. Ensure you consider AM/PM period.
- Push crown back in completely. (Ensure you screw crown back in if fitted with this feature).


#### HOW TO USE STOPWATCH

- The stopwatch can measure up to 60 minutes in 1/5th of a second increments.
- Press Button 'A' to start/stop/restart the stopwatch.
- Press Button 'B' to split/split release/reset the stopwatch.
- Do not press Buttons 'A' and 'B' at the same time, or press one of the two buttons while keeping the other pressed.



## CHRONOGRAPH (7T92)

- Hour, minute and small second hands. Calendar (Date).
- Stopwatch hour, minute, second and 1/20th second hands.
- Stopwatch measures up to 12 hours in 1/20th of a second increments.



### HOW TO SET TIME AND DATE

1. Pull crown out to the first click position (unscrew crown if your watch is fitted with this feature).
2. Turn crown counter clockwise until the previous day's date appears.
3. Pull crown out to second click position.
4. Turn crown counter clockwise to advance the hour and minute hands past 12am. Doing so will advance the date to the current date.
5. Set hour and minute hands to desired time. Ensure you consider AM/PM period.
6. Push crown back in completely. (Ensure you screw crown back in if fitted with this feature.)


### HOW TO USE STOPWATCH

The stopwatch can measure up to 12 hours in 1/20th of a second increments.

- Press Button 'A' to start/stop/restart the stopwatch.
  - Press Button 'B' to split/split release/reset the stopwatch.
- \* Do not press Buttons 'A' and 'B' at the same time, or press one of the two buttons while keeping the other pressed.

## YACHTING TIMER (7T84)

- Time/Calendar.
- Hour, minute and small second hands.
- Date.
- Yacht Timer.
- 5, 6 & 10 minutes preset timers.
- Timer (TMR).
- Can be set to a maximum of 15 minutes in 1-minute increments.
- Stopwatch (CHR).
- Measure up to 12 hours in 1/5 second increments.
- Stopwatch will stop automatically when the measurement reaches 12 hours.
- Alarm (ALM).
- Single time alarm: sounds only once at a designated alarm time within 12 hours.
- Regular alarm: set to sound at a designated time everyday on a 12-hour basis.
- Local Time (LOC).
- A different time zone can be shown in 1-minute increments.



### HOW TO CHANGE THE MODE

1. Pull the crown out to the first click.
2. Press button A to set the mode indicator pointing at your desired mode.
3. After selecting the desired mode, push the crown back to normal position.

### HOW TO SET TIME ON MAIN DIAL AND SMALL DIAL

1. Pull the crown out to the second click, when the small second hand is at the 12 o'clock position.
2. Turn the crown to set the time of the main dial.
3. Press button B, to set the time for the small dial. With each press of button B the small watch hands will advance 1 minute. Pressing and holding button B will advance the small dial hands rapidly.
4. When finished setting the time, push the crown back to the normal position.

### HOW TO SET THE DATE

1. Pull the crown out to the first click.
2. Turn the crown clockwise to set the date. (When setting the date, do not press either button A or B, as pressing either button while the crown is at the first click position can change the mode and the setting in some modes).
3. Push the crown back to the normal position.

### HOW TO USE YACHTING TIMER


Yachting timer combines the function of a count down timer and a stopwatch that starts operating automatically when the timer finishes counting down. This function is particularly useful in yacht racing.

- Three pre-set yachting timer modes: 5, 6 and 10 minutes timers.
- Once you activate the yachting timer function, the selected timer will start counting down in 1 second increments.
- The remaining time will be indicated by the centre hand and the small dial will turn clockwise while the yachting time is counting down.
- When the yacht timer count down finishes, the watch will beep indicating time is up and the stopwatch will automatically start.
- The stopwatch can measure up to 12 hours in 1 second increments. When the measurement reaches 12 hours, the stopwatch will stop automatically.
- Only one yacht timer can be used at one time.
- Cannot change the selected timer while it is working. To change the timer, it is necessary to stop the current working timer before changing to another.
- Split time measurement is possible.

1. Pull the crown out to the first click.
2. Press button A, to set the mode indicator to point at the desired yacht timer.
3. Push the crown back to the normal position.
4. Press button A to start the yacht timer.
5. To reset the timer, press button A to stop the timer and press button B to reset.

The centre hand indicates the remaining minutes and the big hand of the small dial indicates the remaining seconds. When the remaining time is shorter than 60 seconds, the center hand also begins to countdown in 1 second increments.

**Example:** Timer mode display when the timer is set for 4 minutes



- \* If you press button B once again after the timer time is set for 15 minutes, the timer time returns to one minute.
- \* The set timer time will be retained even if the TIMER mode is changed to another mode.

### HOW TO RESET THE YACHT TIMER

To reset the yacht timer, the stopwatch needs to be stopped.

When the stopwatch hands are moving:

1. Press button A to stop the stopwatch.
2. Press button B to reset the yacht timer.

When the stopwatch hands stopped:

1. Press button B to reset the yacht timer.
- When the split time measurement is displayed while the stopwatch is measuring.
1. Press button B to release the stopwatch hands. The stopwatch hands return to the ongoing measurement movement.
2. Press button A to stop the stopwatch.
3. Press button B to reset the yacht timer.

When the split time measurement is displayed and the stopwatch is stopped.

1. Press button B to release the stopwatch hands. The stopwatch hands will stop.
2. Press button B to reset the yacht timer.

### RESTART SETTING FUNCTION

- Yachting timer mode features a restart setting function, which enable to restart the measurement correctly and easily after an interruption during the stopwatch measurement.
- The restart setting function can be used anytime while the stopwatch is measuring following the yacht timer counting.
- Press button A for approximately 2 seconds will activate the restart setting function.
- Restart of the measurement will be made at regular intervals from the initial start of the measurement.
- The intervals between the initial start of the measurement and the restarts are automatically decided according to the selected yacht timer which had finished its counting before the stopwatch had started.

### HOW TO USE THE TIMER

- The timer can set to a maximum of 15 minutes in 1 minute increments.
- The remaining time is indicated by the center hand and the two hands of the small watch.
- When the timer finishes counting down, the watch will beep indicating the time is up.

To set the Timer:

1. Pull the crown out to the first click.
2. Press button A to set the mode indicator pointing at the Timer mode.
3. Press button B to set the center hand to show the desired timer time. With each press of button B, the center hand moves one minute forward, adding one minute to the timer time.
4. Push the crown back to normal position.
- The number on the outer circle of the dial indicated by the centre hand shows the timer time. (The small hand of the small dial also indicates the timer time.)
5. Press Button A to start the timer, press button A to stop and press button B to reset.

### HOW TO USE THE STOPWATCH

- The stopwatch can measure up to 12 hours in 1/5 second increments.
- The large second hand measures 1/5 second, the large hand in the small watch measures the minutes and the small hand measures the hour.
- When the measurement reaches 12 hours, the stopwatch will automatically stop.
- Split time measurement.

## YACHTING TIMER (7T84) CONTINUED

1. Pull the crown out to the first click.
2. Press button A to set the mode indicator pointing at the chronograph mode.
3. Push the crown back to its normal position.
4. Press button A to start the stopwatch.
5. Press button A to stop the stopwatch.
6. Press button B to reset the stopwatch.
7. To accumulate elapsed time measurement, press button A to start and press button A to stop, press button A to restart the stopwatch and press button A to stop. Press button B to reset.
8. Split time measurement, press button A to start, press button B to split. Press button B for split release, press button A to stop and press button B again to reset. (Measurement and release of the split times can be repeated as many times as required by pressing button B).
9. Measurement of 2 competitors. Press button A and press button B for the finish time of the 1st competitor, press button A when 2nd competitor finishes. Then press button B for the finish time for 2nd competitor and press button B to reset.

### HOW TO SET THE ALARM

#### Single time alarm

- Single time alarm is set in the Time mode.
  - The alarm will only alert once at a designated time and it is automatically disengaged.
  - The alarm time can be set within 12 hours from the current time in 1 minute increments.
1. Pull the crown out to the first click.
  2. Press button A to set the mode indicator to point at the Time mode.
  3. Press button B to set the alarm, which will show in the small watch. By press button B the small watch hands will advance in 1 minute.
  4. Push the crown to its normal position.
  5. To stop the alarm alert, press either button A or B. The single time alarm will go for 20 seconds.

The single time alarm will only work when it is in Time mode.

To cancel the single time alarm

- Press button B to set the alarm time to current time
- Change the Time mode to another mode.

#### Regular alarm

- The regular alarm can be set to be alert at a designated time everyday.
  - The regular alarm is set in the Alarm mode.
  - The set alarm time can be used as many times as required.
1. Pull the crown to the first click.
  2. Press button A to set the mode indicator to point at Alarm mode.
  3. Press button B to set the small dial to show the desired regular alarm time.
  4. Push the crown back to the normal position.
  5. To stop the alarm alert, press either button A or B. The regular alarm will go for 20 seconds.

#### Sound demonstration function (Alarm sound preview)

1. Pull the crown out to first click.
2. Press button A to set the mode indicator pointing at the alarm mode.
3. Push the crown back to the normal position.
4. Press button A for more than 2 seconds. The alarm sound can be heard while button A is kept pressed.

### LOCAL TIME

- The small dial can be set to show the time in second time zone.
- Two different times can be shown at the same time using the main dial and the small dial as a dual time display.

### HOW TO SET THE LOCAL TIME

1. Pull the crown out to first click.
2. Press button A to set the mode indicator to point at Local time mode.
3. Press button B to set the local time. (The small watch shows the time in another time zone.)
4. Push the crown back to normal position.

### NECESSARY PROCEDURE AFTER BATTERY CHANGE

After the battery is replaced with a new one, or when an abnormal display appears, reset the watch build-in IC. The watch will resume its normal operation.

### HOW TO RESET THE IC


1. Pull the crown out to the second click.
2. Press button A and B at the same time.
3. Push the crown back to the normal position and check if the hands move as normal.

### HAND POSITION ADJUSTMENT

- Hand position adjustment is required when the hands are not correctly aligned for the use in the Stopwatch and Timer functions, or after a battery change or reset of the built-in IC.
1. Pull the crown out to second click.
  2. To adjust the small watch. Press button A for approximately 5 seconds. The small watch hands will start moving.
  3. Press button B to set the small watch hands to 12 o'clock, which is the initial position of the small watch hands.
  4. To adjust the center hand. Press button A the center hand will turn a full circle.
  5. Press button B to set the center hand to the 0 position.
  6. To adjust the mode indicator. Press button A the mode indicator will turn a full circle.
  7. Press button B to set the mode indicator pointing at the Time mode, which is the initial position of the mode indicator. Keep pressing the button B until the mode indicator exactly pointing at the dot marker.
  8. When adjustment is finish, push the crown back to normal position.
  9. After hand adjustment is complete, set the time and date following the instruction on how to set the time.

## SOLAR ALARM CHRONOGRAPH (V172)

- Time/calendar.
- 60-Minute stopwatch in 1/5-second increments with split time measurement function.
- Single-time alarm within 12 hours.
- Powered by light energy.
- No battery change required.
- Lasts for 6 months after full charge.
- Energy depletion forewarning function.
- Overcharging prevention function.



### MAKING ADJUSTMENTS TO THE WATCH

This watch is designed so that the following adjustments are made with the crown at the second click position:

1. main time setting
2. alarm hand adjustment
3. stopwatch hand position adjustment

Once the crown is pulled out to the second click, be sure to check and adjust 1. and 2. at the same time. If needed, 3. should also be adjusted then.

### HOW TO SET TIME

1. Pull out crown to the second click when the second hand is at the 12 o'clock position.
2. Turn the crown to set the hour and minute hands.

### HOW TO ADJUST THE ALARM HANDS

2. Press 'B' repeatedly to set the ALARM hands to the time indicated by the main time hands.

### HOW TO ADJUST STOPWATCH HAND POSITION

If the STOPWATCH hands are not in the "0" position, follow the procedure below to set them to the "0" position.

1. Press 'A' for 2 seconds.
2. Press 'B' repeatedly to set the STOPWATCH minute hand to the "0" position.
3. Press 'A' for 2 seconds.
4. Press 'B' repeatedly to set the STOPWATCH 1/5-second hand to the "0" position.

### HOW TO SET DATE

Before setting the date, be sure to set the main time.

1. Pull the crown out to the first click.
2. Turn the crown clockwise until the desired date appears.
3. Push the crown back into the normal position.

### HOW TO USE STOPWATCH

The stopwatch can measure up to 60 minutes in 1/5-second increments. When the measurement reaches 60 minutes, the stopwatch automatically stops.

Split time measurement is available.

Before using the stopwatch, be sure to check that the crown is set at the normal position and that the STOPWATCH hands are reset to the "0" position.

### HOW TO RESET STOPWATCH

While the stopwatch hands are moving:

1. Press Button 'A' to stop the stopwatch.
2. Press Button 'B' to reset the stopwatch.

When the stopwatch is stopped:

1. Press Button 'B' to reset the stopwatch.

When the split time measurement is displayed while the stopwatch is measuring:

1. Press Button 'B' to release the split time display. The stopwatch hands move quickly, and then indicate the measurement in progress.

2. Press Button 'A' to stop the stopwatch.

3. Press Button 'B' to reset the stopwatch.

When the split time measurement is displayed and the stopwatch is stopped:

1. Press Button 'B' to release the split time display. The stopwatch hands move quickly, and then stop.
2. Press Button 'B' to reset the stopwatch.

### HOW TO SET ALARM

The alarm can be set to ring only once at a designated time within the coming 12 hours.

- The alarm time can be set in one minute increments.
- You can preview the alarm sound by using the sound demonstration function.

Before using the alarm, check that the ALARM hands are adjusted to the current time.

1. Pull the crown out to the first click.
2. Press 'B' repeatedly to set the desired alarm time.
3. Push the crown back into the normal position.

At the designated time the alarm rings for 20 seconds, and it is automatically disengaged as it stops. To stop it manually, press Button A or B.

### HOW TO CHARGE AND START THE WATCH

When you start the watch or when the energy in the rechargeable battery is reduced to an extremely low level, charge it sufficiently by exposing the watch to light.

1. Expose the watch to sunlight or strong artificial light.
2. Keep the watch exposed to the light until the second hand moves at 1-second intervals.
3. When the watch is charged after it has completely stopped, set the date and time before wearing the watch.

### GUIDELINE OF CHARGING TIME/ACCURACY

Environment/Lightsource (lux)	V172		
	A (minutes)	B (hours)	C (hours)
General offices/ Fluorescent light (700)	150	60	-
30W20cm/ Fluorescent light (3000)	33	13	110
Cloudy weather/Sunlight (10000)	9	3.5	30
Fair weather/Sunlight (100000)	2	0.6	5
Expected life per charge from full charge to stoppage	6 months		
Loss/gain (monthly rate)	Less than 15 seconds when the watch is worn on your wrist at a normal temperature range (5 °C to 35 °C)		
Operational temperature range	-10 °C to 60 °C		


A: Time to charge 1 day of power  
B: Time required for steady operation  
C: Time required for full charge

The above table provides only a general guideline.



## SOLAR

- Powered by light energy.
- No battery change required.
- Lasts for 2 to 12 months after full charge (depends on the calibre).
- Energy depletion forewarning function (for cal. V111, V117, V145, V147, V157, V158, V181, V182, V187 only).
- Instant-start function (for cal. V145, V147, V157, V158, V181, V182, V187 only).
- Overcharging prevention function.



### HOW TO CHARGE AND START THE WATCH

When you start the watch or when the energy in the rechargeable battery is reduced to an extremely low level, charge it sufficiently by exposing the watch to light.

1. Expose the watch to sunlight or strong artificial light.
2. Keep the watch exposed to the light until the second hand moves at 1-second intervals.
3. When the watch is charged after it has completely stopped, set the date and time before wearing the watch.

### HOW TO SET TIME AND DATE

Models with two/three hands:

1. Pull out the crown to the first click.
2. Turn the crown to set the desired time.
3. Push back the crown completely (in accordance with a time signal for a three-hand model.)

Models with date:

1. Pull out the crown to the first click and set the previous date.
2. Pull out the crown to the second click when the second hand is at the 12 o'clock position.
3. Turn the crown until the desired date appears.
4. Turn the crown to set the hour and minute hands to the desired time.
5. Push back the crown completely in accordance with a time signal.

Models with day and date:

1. Pull out the crown to the first click and set the previous day and date.
2. Pull out the crown to the second click when the second hand is at the 12 o'clock position.
3. Turn the crown until the desired day and date appears.
4. Turn the crown to set the hour and minute hands to the desired time.
5. Push back the crown completely in accordance with a time signal.

### GUIDELINE OF CHARGING TIME/ACCURACY

Environment/Lightsource (lux)	V110			V111/V117		
	A (minutes)	B (hours)	C (hours)	A (minutes)	B (hours)	C (hours)
General offices/ Fluorescent light (700)	50	16	140	180	60	-
30W20cm/ Fluorescent light (3000)	11	3.5	30	35	10	180
Cloudy weather/Sunlight (10000)	3	0.9	8	12	4	60
Fair weather/Sunlight (100000)	1	0.3	2	2	0.5	10
Expected life per charge from full charge to stoppage	5 months			6 months		
Loss/gain (monthly rate)	Less than 20 seconds when the watch is worn on your wrist at a normal temperature range (5 °C to 35 °C)			Less than 15 seconds when the watch is worn on your wrist at a normal temperature range (5 °C to 35 °C)		
Operational temperature range	-5 °C to 50 °C			-10 °C to 60 °C		

V114/V115/V116			V147/V157/V158			V187		
A (minutes)	B (hours)	C (hours)	A (minutes)	B (hours)	C (hours)	A (minutes)	B (hours)	C (hours)
180	60	-	110	25	-	95	8	100
35	10	180	30	6	120	23	1.6	25
12	4	60	10	2	35	6	0.4	7
2	0.5	10	2	0.4	9	3	0.1	3
12 months			10 months			2 months		
Less than 15 seconds when the watch is worn on your wrist at a normal temperature range (5 °C to 35 °C)								
-10 °C to 60 °C								

V145			V181/V182		
A (minutes)	B (hours)	C (hours)	A (minutes)	B (hours)	C (hours)
50	11	175	75	6	82
10	2	40	18	1.3	20
3	0.5	10	5	0.3	5
1	0.1	3	2	0.1	2.1
6 months			2 months		
Less than 20 seconds when the watch is worn on your wrist at a normal temperature range (5 °C to 35 °C)					
-5 °C to 50 °C					

A: Time to charge 1 day of power  
B: Time required for steady operation  
C: Time required for full charge

The above table provides only a general guideline.

### ENERGY DEPLETION FOREWARNING FUNCTION

- If your watch has a second hand, when the energy stored in the rechargeable battery is reduced to an extremely low level, the second hand starts moving at 2-second intervals instead of the normal 1-second intervals. (Some calibres have no such function.) The watch remains accurate even while the second hand is moving at 2-second intervals.
- In that case, recharge the watch as soon as possible by exposing it to light. Otherwise, the watch may stop operating in about 3 days. (For recharging the watch, see "HOW TO CHARGE AND START THE WATCH")

To prevent the energy depletion:

- When wearing the watch, make sure that the watch is not covered by clothing.
- When the watch is not in use, leave it in a bright place as long as possible.

### SERVICE NETWORK FOR WARRANTY REPAIRS

#### **New Zealand**

Service Agent for Seiko, Pulsar, Lorus

Watch World

226A Bush Road, Albany,

Auckland NZ 0632

PO Box 100037, North Shore,

New Zealand 0745

Phone: +(649) 415 5668

Fax: +(649) 415 5662

Email: [admin@watchworld.co.nz](mailto:admin@watchworld.co.nz)

### 3 YEAR GUARANTEE

All SEIKO watches and clocks are covered by a 3 year guarantee. The guarantee covers defects in the material and workmanship from the date of purchase. As a SEIKO authorised dealer it is your responsibility to correctly fill in the guarantee with all the information required. The diagram on the right shows where to find the relevant information on the watch caseback.

In the case of incorrectly used guarantees, return them to SEIKO Australia or hand them to your SEIKO Australia Representative for free replacement, otherwise a charge for new guarantees will be applicable.



### Global Service Network

SEIKO's dedication to quality extends throughout its service network in all corners of the world, extending the same dedication to excellence and the highest quality service to SEIKO customers everywhere.

For over 100 years SEIKO has stood for quality – in manufacture, design and service. Today, our SEIKO service centres strive to offer the highest standard of after-sales service and ensure lasting consumer satisfaction. In the Oceania Region, SEIKO Australia Pty Ltd has a network of branch offices, service centres and authorised service agents throughout Australia, New Zealand, Papua New Guinea, and the Pacific Islands.

For service, repairs and spare parts enquiries, please phone 0800 734 561 or email [service@seiko.com.au](mailto:service@seiko.com.au)



# SEIKO

## CORPORATE

**As one of the world's largest watch and clock manufacturers, Seiko gives you greater reliability, guaranteed quality and more choice when considering:**

We can specialise our timepieces for corporate businesses or groups for:

- Service Awards
- Incentives & Rewards
- Product Launches
- Promotions
- Gifts for Employees or Clients
- Safety Awards
- Loyalty Programs
- Or any other business occasion.

**Specialised Services Include:**

- Printing a company logo on the dial of the watch or clock
- Engraving logos or personalised messages on the watch back or clasp
- Customised packaging
- Printing and engraving lead times approx 10 working days
- All products supplied in presentation boxes
- Full Seiko warranty applies to all models

**For more information contact  
the Corporate Sales Department:**

**Ph: +61 2 9805 4777**

**Fax: +61 2 9887 3577**

**Email: [corporate@seiko.com.au](mailto:corporate@seiko.com.au)**





Model Number	Page	Price
S23535P	54	\$675.00
S23547J	54	\$199.95
S23569J	54	\$775.00
S23571J	54	\$1,200.00
S23589J	54	\$145.00
S23593J	54	\$695.00
S23601P	54	\$299.00
S23603P	54	\$340.00
S23605P	54	\$399.00
S23619J	35	\$7,900.00
SFP608P	44	\$340.00
SFQ822P	50	\$825.00
SFQ824P	50	\$795.00
SFQ827P	50	\$725.00
SFQ830P	53	\$340.00
SGEB76P-9	22	\$625.00
SGED96P-9	22	\$775.00
SGEE89P	40	\$450.00
SGEE94P-9	41	\$899.00
SGEF41P	41	\$450.00
SGEF43P	41	\$450.00
SGEF45P	41	\$499.00
SGEF46P	41	\$550.00
SGEF48P-9	41	\$899.00
SGG480PS	44	\$360.00
SGG713P	40	\$399.00
SGG715P	40	\$399.00
SGG717P	40	\$399.00
SGG719P	40	\$460.00
SGGA61P	40	\$460.00
SGGA62P	40	\$495.00
SKA371P	24/35	\$875.00
SKA371P-2	24/35	\$825.00
SKA463P	24	\$550.00
SKA465P	24	\$650.00
SKA489P	24	\$599.00
SKA490P	24	\$699.00
SKA505P	24	\$699.00
SKA511P	11	\$1,300.00
SKA511P-2	11	\$1,250.00
SKK704P	43	\$475.00
SKK705P	43	\$399.00
SKK706P	43	\$450.00
SKK710P	43	\$475.00
SKP364P	43	\$725.00
SKP366P	43	\$750.00
SKP369P	41	\$650.00
SKP371P	41	\$750.00
SKP373P	44	\$599.00
SKP375P	44	\$650.00
SKP381P-2	44	\$599.00
SKP382P	41	\$850.00
SKT074P-9	42	\$360.00
SKT082P	42	\$385.00
SKX171KS	36/38	\$695.00
SKZ290J	39	\$695.00
SKZ312J	39	\$825.00
SKZ325K	38/38	\$950.00
SKZ327K	36/38	\$875.00
SKZ330K	36/38	\$950.00
SNAA02P-9	30	\$825.00
SNAA92P	17	\$1,350.00
SNAA93P	17	\$1,350.00
SNAA93P-2	17	\$1,200.00

Model Number	Page	Price
SNAC43P	30	\$775.00
SNAD10P	19	\$1,350.00
SNAD11P	19	\$1,350.00
SNAD89P	30	\$750.00
SNAE17P	17	\$1,250.00
SNAE19P	17	\$1,350.00
SNAE21P	17	\$1,400.00
SNAE32P	30	\$875.00
SNAE34P	21	\$999.00
SNAE35P	30	\$675.00
SNAE42P	30	\$650.00
SNAE43P	30	\$599.00
SNAE47P	30	\$650.00
SNAE49P	30	\$699.00
SNAE56P-2	21	\$999.00
SNAE57P-9	21	\$1,100.00
SNAE63P	11	\$999.00
SNAE67P	11	\$999.00
SNAE69P	11	\$999.00
SNAE70P	21	\$1,150.00
SNAE73P	21	\$899.00
SNAE74P	21	\$999.00
SNAE75P	10	\$1,200.00
SND417P	32	\$575.00
SNDA59P	16	\$1,795.00
SNDB21P	32	\$699.00
SNDB63P	33	\$525.00
SNDB71P	33	\$595.00
SNDC31P	33	\$425.00
SNDC37P	33	\$475.00
SNDC38P	33	\$550.00
SNDC81P	32	\$499.00
SNDC85P	32	\$499.00
SNDC89P-2	32	\$450.00
SNDC97P-9	33	\$799.00
SNDC99P	32	\$599.00
SNDD07P	32	\$625.00
SNDD23P	31	\$550.00
SNDZ37P	18	\$2,050.00
SNDZ38P	18	\$2,150.00
SNDZ40P	18	\$1,395.00
SNE087P	27	\$450.00
SNE088P	27	\$525.00
SNE090P	27	\$550.00
SNE093P	26	\$395.00
SNE094P	26	\$475.00
SNE095P	26	\$395.00
SNE098P-9	26	\$475.00
SNE107P	26/35	\$725.00
SNE107P-2	26/35	\$625.00
SNE109P	26/35	\$625.00
SNE121P	27	\$525.00
SNE124P-9	27	\$599.00
SNE125P-9	27	\$625.00
SNE127P	28	\$475.00
SNE128P-9	28	\$525.00
SNE131P	27	\$525.00
SNE132P	27	\$599.00
SNE134P	27	\$625.00
SNE138P	28	\$550.00
SNL045P	19	\$1,650.00
SNM041K	39	\$625.00
SNM048K	39	\$725.00
SNN233P	32	\$550.00

Model Number	Page	Price
SNN235P	32	\$450.00
SNP007P-9	20	\$1,250.00
SNP008P-9	20	\$1,350.00
SNP017P-9	20	\$1,550.00
SNP029P	19	\$1,750.00
SNP039P	12	\$1,700.00
SNP041P	12	\$1,700.00
SNP042P	12	\$1,800.00
SNP044P	12	\$1,800.00
SNQ045P	34	\$675.00
SNQ101P-9	34	\$675.00
SNQ102P-9	34	\$750.00
SNQ116P	14	\$850.00
SNQ117P	14	\$775.00
SNQ118P	14	\$850.00
SNQ123P	20	\$775.00
SNQ124P	20	\$850.00
SNZE19K	38	\$499.00
SNZE30K	39	\$499.00
SNZE32K	39	\$499.00
SNZE35K	39	\$399.00
SNZG13K	38	\$460.00
SNZH03K	38	\$525.00
SNZH06K	38	\$595.00
SNZH34K	39	\$825.00
SPC049P	16	\$1,995.00
SPC057P	13	\$1,025.00
SPC058P	13	\$1,200.00
SRH006P	16	\$2,250.00
SRK021P	13	\$775.00
SRK286P	15	\$1,495.00
SRKZ93P	15	\$1,395.00
SRKZ96P	15	\$925.00
SRP132K	37	\$750.00
SRP148K	37	\$699.00
SRP162K	37	\$699.00
SRP172K	37	\$699.00
SRX003P	12	\$2,250.00
SRX004P	12	\$2,450.00
SSA023J-2	13	\$1,200.00
SSA024J	13	\$1,300.00
SSC002P	25/29	\$750.00
SSC003P	25/29	\$650.00
SSC005P	25/29	\$650.00
SSC008P-2	25/29	\$950.00
SSC009P	25/29	\$825.00
SSC009P-3	25/29	\$750.00
SSC011P	25/29	\$899.00
SSC013P	25/29	\$750.00
SUJF60P	52	\$499.00
SUJF63P	52	\$595.00
SUJG16P-9	52	\$595.00
SUP019P	47	\$425.00
SUP022P	47	\$499.00
SUP024P	47	\$475.00
SUP026P	47	\$499.00
SUP027P	47	\$499.00
SUP028P	48	\$475.00
SUP030P	48	\$475.00
SUP032P	48	\$475.00
SUP032P-2	48/53	\$399.00
SUP052P	48	\$575.00
SUP066P	46	\$525.00
SUP068P	46	\$550.00

Model Number	Page	Price
SUP070P	47	\$575.00
SUP072P	47	\$599.00
SUP073P	46	\$425.00
SUP075P	47	\$525.00
SUP079P	47	\$550.00
SUP080P	47	\$575.00
SUP083P-9	48	\$525.00
SUP084P-9	48	\$599.00
SUP086P-9	48	\$599.00
SUP088P	48	\$595.00
SUP892P	28	\$575.00
SUP893P	28	\$550.00
SUT022P	45	\$525.00
SUT024P	45	\$550.00
SUT027P	46	\$475.00
SUT028P	46	\$575.00
SUT030P	46	\$599.00
SUT032P	46	\$625.00
SUT033P	46	\$575.00
SUT034P	46	\$650.00
SUT036P	46	\$675.00
SUT040P-9	45	\$599.00
SUT041P-9	45	\$625.00
SUT043P	45	\$525.00
SUT044P	45	\$599.00
SUT046P	45	\$625.00
SXDA12P	53	\$440.00
SXDA16P	53	\$440.00
SXDA19P	18	\$1,350.00
SXDA20P	18	\$1,450.00
SXDA48P-9	23	\$1,295.00
SXDA50P-9	23	\$725.00
SXDA74P	50	\$595.00
SXDB37P	49	\$495.00
SXDB54P	50	\$925.00
SXDB56P	50	\$875.00
SXDB58P	50	\$795.00
SXDB88P-9	49	\$695.00
SXDB94P	52	\$725.00
SXDB96P	52	\$675.00
SXDC11P-9	49	\$850.00
SXDC16P	51	\$550.00
SXDC24P	52	\$475.00
SXDC25P	52	\$399.00
SXDC26P	52	\$450.00
SXDC32P	51	\$599.00
SXDC36P-9	50	\$799.00
SXDC58P	52	\$475.00
SXDC77P	51	\$450.00
SXDC81P	51	\$499.00
SXDC82P	51	\$550.00
SXDC92P	23	\$799.00
SXDC94P	23	\$825.00
SXDC96P-9	51	\$699.00
SXDC98P-9	50	\$799.00
SXDE02P	15	\$850.00
SXDE04P	15	\$899.00
SXDE06P	23	\$799.00
SXDE07P	23	\$725.00
SXDE09P-9	51	\$650.00
SXDE19P	23	\$995.00
SXDE20P	23	\$1,100.00
SXGN56P	53	\$340.00
SZZC40P-9	52	\$499.00





# SEIKO

Sales orders & enquiries:  
nzsales@seiko.co.nz

For sales enquiries within New Zealand  
please phone 0800 734 561.

## **NEW ZEALAND**

226A Bush Road  
Albany  
New Zealand 0632  
PO Box 100037  
North Shore Mail Centre  
Auckland 0745  
Ph: +64 (9) 415 5668  
Fax: +64 (9) 415 5661

## **TRADE PRACTICES ACT 1974**

Resale Price maintenance (\$48 SS96 100). The prices shown in this catalogue are recommended retail prices as at 1st July 2011 and there is no obligation to comply with the recommendation. All prices are in New Zealand Dollars and all prices include GST. All prices are subject to change without notice. Seiko Australia Pty Ltd (ABN 63 000 797 946).  
SCATPCNZ0711