


ZZPerformance.com

Intercooler pump wiring instructions


1. Remove fender brace and mount controller box near fuse block.



2. Connect plug to pump.
3. Connect red wire to fuse block power.



4. Connect black wire to good ground. Be sure to scrape paint away if making a new ground connection.



5. Fill with 50/50 mix of water and antifreeze.
6. Run pump to purge air bubbles. This could take 15 minutes or more.
7. Fill as level in tube drops and check for leaks.



8. Reinstall bumper cover.
9. Piece in the picture is not reinstalled.



10. Next pictured piece gets modified as shown.



11. Install modified piece with its three 10mm bolts.
12. Reinstall headlights
13. Cut fill tube slightly below core support and install supplied plug.



14. Use zip ties to secure coolant hoses so they don't contact supercharger or accessory belts.

