

# Enterprise Server



## Introduction

A SmartStruxure solution server is the core of the system and performs key functionality, such as control logic, trend logging, and alarm supervision. The Enterprise Server is the Windows application version of a StruxureWare Building Operation server that collects site-wide data for aggregation and archiving, yet is flexible enough to run stand-alone applications. The Enterprise Server also serves as a single point of administration through WorkStation or WebStation for SmartStruxure solution, Schneider Electric's intelligent Building Management System.

## Features

At the top of the SmartStruxure solution architecture is the Enterprise Server. It is the central point from which users can configure, control, and monitor the entire system.

### Networking powerhouse

The Enterprise Server can run multiple control programs using a variety of protocols. It can manage alarms, users, schedules, and trend logs. Data from the Enterprise Server can be delivered directly to the user or to other devices and servers throughout the site or enterprise.

### Global view of the system

The entire system, including all of the Automation Servers and their associated devices, can be accessed and configured through the Enterprise Server.

This overview of the site provides easier mass change engineering and data analysis. The Enterprise Server also aggregates the event and alarm data from all its associated Automation Servers. Trend logs can also be aggregated through the use of extended trend logs.

### Text and graphics-based programming tools

Unique to the industry, the Enterprise Server has both Script and Function Block programming options. This flexibility assures that the best programming method can be selected for the application.

### Centralized alarms and data management

Alarms from multiple devices throughout the site, including Automation Servers, are collected by the Enterprise Server for centralized logging, display, and management. Users can also view event logs and trend logs from multiple servers.

The Enterprise Server hosts the historical and configuration databases. These databases store current information, including trends, alarms, user activity, and property information.

### Advanced activity log

It is important to log more than basic activity. In a SmartStruxure solution, every action is logged with a timestamp, the user who performed the action, and the values that were changed.

### WorkStation/WebStation interface

Through any client, the user experience is similar regardless of which SmartStruxure solution server the user is logged on to. The user can log directly on to an Enterprise Server to engineer, commission, supervise, and monitor the Automation Server as well as its attached I/O modules and field bus devices. For more information, see the WorkStation and WebStation data sheets.

Open building protocol support

One of the cornerstones of SmartStruxure solution is support for open standards. The Enterprise Server can natively communicate with three of the most popular standards for buildings: BACnet, LonWorks, and Modbus.

Native BTL-listed BACnet support

The Enterprise Server communicates directly to BACnet/IP networks. It is compliant with ASHRAE 135-2004, the Enterprise Server is BTL-listed as a BACnet Building Controller (B-BC), the most advance BACnet device profile, and as a BACnet Operator Workstation (B-OWS). This capability provides access to the full range of BACnet devices from Schneider Electric and other vendors. See the BTL Product Catalog for up-to-date details on BTL listed software revisions on BACnet International's home page. The Enterprise Server can also serve as a BACnet Broadcast Management Device (BBMD) to facilitate BACnet systems that span multiple IP networks.

Native LonWorks support

The Enterprise Server works with a range of LonTalk adapters to communicate to TP/FT-10 LonWorks networks. Integrated LonWorks functionality enables access to LonWorks devices from Schneider Electric and other vendors. LonWorks networks can be commissioned, bound, and configured from the Enterprise Server using the built-in LonWorks Network Management Tool. No third-party tools are needed. To increase ease of use, LNS device plug-ins are supported. This allows for easier engineering and maintenance of LonWorks devices from Schneider Electric and other vendors. There are some limitations on how LNS device plug-ins can be used.

Native Modbus support

The Enterprise Server natively integrates Modbus RS-485 master and slave configurations, as well as TCP client and server. This allows full access to third-party products and the range of Schneider Electric products that communicate on the Modbus protocol, such as power meters, UPS, circuit breakers, and lighting controllers.

Specifications

Hardware requirements

Processor .....	Minimum: 1.0 GHz
.....	Recommended: 2.0 GHz or higher
Memory .....	Minimum: 2 GB
.....	Recommended: 4 GB or higher

Web Services support

The Enterprise Server supports the use of Web Services based on open standards, such as SOAP and REST, to consume data into the SmartStruxure solution. Use incoming third-party data (temperature forecast, energy cost) over the Web to determine site modes, scheduling, and programming.

EcoStruxure Web Services support

EcoStruxure Web Services, Schneider Electric's Web Services standard, is natively supported in the Enterprise Server. EcoStruxure Web Services offers extra features between compliant systems whether within Schneider Electric or authorized third-party systems. These features include system directory browsing, read/write of current values, alarm receipt and acknowledgement, and historical trend log data. EcoStruxure Web Services is secure. User name and password are required to log on to the system.

IT friendly

The Enterprise Server communicates using networking standards, such as DHCP, HTTP, and HTTPS. This makes installation easy, management simple, and transactions secure.

Supported Protocols

- IP addressing
- TCP communications
- DHCP/DNS for rapid deployment and lookup of addresses
- HTTP/HTTPS for internet access through firewalls, which enables remote monitoring and control
- NTP (Network Time Protocol) for time synchronization throughout the system
- SMTP enables sending email messages

Hard Disk .....Minimum: 20 GB  
 The guidelines provided need to be scaled upwards as the system size grows in quantity of Automation Servers or expected historical archiving. The testing of the largest 1.4.0 system was accomplished on a machine with an 8 core @ 3.6 GHz processor, 32 GB of memory, and a hard drive of 3 TB.

Drive .....DVD drive is required if your copy of StruxureWare Building Operation was delivered on disc.

Other devices .....Microsoft mouse or compatible pointing device is required.

**Software requirements**

Operating systems .....Microsoft Windows XP Professional (32-bit) SP3  
 .....Microsoft Windows 7 (32-bit)  
 .....Microsoft Windows 7 (64-bit)  
 .....Microsoft Windows Server 2008 R2 (64-bit)

The following Microsoft Windows 7 editions are supported: Professional, Enterprise, and Ultimate.  
 The following Microsoft Windows Server 2008 R2 editions are supported: Standard, Web, Enterprise, Datacenter, and Itanium.

Required additional software .....Microsoft .NET Framework 4 Client Profile with update KB2468871

**Communication**

TCP .....Binary, port configurable, default 4444

HTTP .....Non-binary, port configurable, default 80

HTTPS .....Encrypted supporting SSL 1.0, 2.0, 3.0 and TSL 1.0, port configurable default 443

SMTP .....Email sending, port configurable, default 25

NTP .....Time synchronization

BACnet .....BACnet/IP, port configurable, default 47808

.....BTL B-BC (BACnet Building Controller)<sup>a</sup>

.....BTL B-OWS (BACnet Operator Workstation)<sup>a</sup>

a) See the BTL Product Catalog for up-to-date details on BTL listed firmware revisions on BACnet International's home page.

Supports the following LonTalk adapters: .....NIC709-PCI

.....NIC709-USB

.....NIC709-USB100

.....NIC709-IP

.....NIC852

Other protocols may be used for particular additional functionality. See Technical Documentation.

LNS version.....OpenLNS

Installed on WorkStation PC

SW-ES-BASE-0, StruxureWare Building Operation Enterprise Server license for a PC server, includes Reports Server license

(No maintenance subscription included)

.....SXSWESXX00001

**Add-on options**

SW-EWS-1, EcoStruxure Web Services (run-time) option

Consume only for one Enterprise Server, no maintenance .....SXSWEWSX00001

SW-EWS-2, EcoStruxure Web Services (run-time) option

Serve & Consume for one Enterprise Server, no maintenance .....SXSWEWSX00002

---

SW-EWS-3, EcoStruxure Web Services (run-time) option Serve & Consume, plus Historical trend log data for one Enterprise Server, no maintenance .....	SXWSWEWSX00003
SW-GWS-1, Web Services (Generic Consume) option For one Enterprise Server, no maintenance .....	SXWSWGWSX00001