



STOMP PAD

INSTALLATION INTSTRUCTIONS



I'M NOT A STICKER, DON'T TREAT ME LIKE ONE!!!

*APPLY TO A CLEAN, DRY, WARM (ROOM TEMP) SNOWBOARD AT LEAST 30 MINUTES BEFORE USE.

- 1) Clean snowboard with alcohol or dishwashing detergent to remove grease, grime and oils.
- 2) Cut plastic wrap along the edge of the stomp pad and remove it from the packaging.
- 3) Peel off the adhesive liner on the stomp pad.
- 4) Stick the stomp pad onto the board from one edge to the other while carefully pushing air out to avoid trapping bubbles.
- 5) Stomp on it! The more pressure the better.
- 6) Go out and ride!

STOMPGRIP, Inc.

888-612-5240 • 714-894-9388 • Fax 714-894-4648

customerservice@stompgrip.com

WWW.STOMPGRIP.COM