

Instructions manual: BluConsole

ACCESS TEMPERATURE GRAPHS AND REPORTS

Go to the „Measurements” page and click on the „Graph” button on the right of each logger. From this page, you can choose the start and end time for data shown and click on the „PDF”, „XLSX” or „CSV” buttons to download the corresponding temperature reports

CREATE SUB-ORGANIZATION

Go to the „Organizations” page and click on the „+” button at the top. You will be asked to enter a name, type (client by default), the parent company (indicate your organization to get data from the loggers of this sub-organization) and you can choose whether this sub-organization can use the SMS pool of the mother organization.

ADD NEW USER

Go to the „Users” page and click on the „+” button at the top. You will be asked to indicate an email, a password, a phone number for the SMS alerts, the type of user (USER has only access to data and ADMIN can change parameters), whether to receive temperature reports via email, the organization to which the user will be attached, the language for the alert messages, the time zone of the user and whether the user should get alerts via SMS and/or email.

ERASE ZONE, ORGANIZATION OR USER

Go to the „Zones”, „Organizations” or „Users” page, select the zone, organization or user to erase and click on the top „-” button. Please note that in order to erase a zone, it should not be associated to any logger. To erase an organization, it should not be associated to loggers, to hubs and/or to zones.