

NOTICE

*Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.

*This item should be assembled on a soft surface to prevent scratching the finish during assembly.

*This item may require periodic tightening.

*If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com

PREPARATION

*Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.

*If any part is missing or damaged, do not attempt to assemble the product.


*Estimated Assembly Time: 60 minutes.

*Tools Required for Assembly (included): Allen Key

CARE AND MAINTENANCE

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.


Part List



 **SAFAVIEH**
FURNITURE

Model# NST9604

Product Dimensions: 16"Wx15"Dx22"H











WARNING :

WEIGHT CAPACITY: 22 LBS.

DRAWER LOAD CAPACITY : 15.4 LBS.

Hardware List

HW1x12  $\varnothing 6 \times 35 \text{ mm}$	HW2x12  $\varnothing 15 \text{ mm}$	HW3x4  $\varnothing 12 \text{ mm}$	HW4x4  $\varnothing 6 \times 32 \text{ mm}$	HW5x16  $\varnothing 8 \times 30 \text{ mm}$	HW6x2  $\varnothing 6 \times 30 \text{ mm}$
HW7x2  $M 4 \times 12 \text{ mm}$	HW8x4  $M 6 \times 10.5 \text{ mm}$	HW9x4  $M 8 \times 39 \text{ mm}$	HW10x6  $M 3.5 \times 13 \text{ mm}$	HW11x1 	HW12x4 
HW13x1 	HW14x24  $M 4 \times 16 \text{ mm}$	HW15x4  $M 7 \times 50 \text{ mm}$	HW16x1  $L 4$	HW17x8 	HW18x8  $M 3.5 \times 15.5 \text{ mm}$
HW BC410x4 	HW RM35Ax1 				

Part List & HW For Multi-Box Items

Piece	Description	Qty	Carton Call
A	Top Board	1	1 of 1
B	Bottom Board	1	1 of 1
C	Side Board Left	1	1 of 1
D	Side Board Right	1	1 of 1
E	Front Drawer	1	1 of 1
F	Side Drawer Left	1	1 of 1
G	Side Drawer Right	1	1 of 1
H	Back Drawer	1	1 of 1
I	Bottom Drawer	1	1 of 1
J	Back Board	1	1 of 1
K	Bottom Skirt 1	2	1 of 1
L	Bottom Skirt 2	2	1 of 1
LS20B1	Leg	4	1 of 1


Piece	Description	Qty	Carton Call
HW1	Cambolt Big	12	1 of 1
HW2	CamLock Big	12	1 of 1
HW3	CamLock Small	4	1 of 1
HW4	Cambolt Small	4	1 of 1
HW5	Dowel Big	16	1 of 1
HW6	Dowel Small	2	1 of 1
HW7	Screw M 4 x 12 mm	2	1 of 1
HW8	Screw M 6 x 10.5 mm	4	1 of 1
HW9	Screw M 8 x 39 mm	4	1 of 1
HW10	Screw M 3.5 x 13 mm	6	1 of 1
HW11	Handle	1	1 of 1
HW12	Flange Nut	4	1 of 1
HW13	Wrench	1	1 of 1
HW14	Screw M 4 x 16 mm	24	1 of 1
HW15	Screw M 7 x 50 mm	4	1 of 1
HW16	Allen Key	1	1 of 1
HW17	Wedge	8	1 of 1
HW18	Screw M 3.5 x 15.5 mm	8	1 of 1
HW BC410	Corner Brace	4	1 of 1
HW RM35A	Rail	1	1 of 1

PREPARATION


Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 45 minutes.




STEP1: Insert Cambolt Small (HW4) into Front Drawer (E).
Insert Dowel Small (HW6) into Side Drawers (F & G)




STEP2: Combine Side Drawers (F & G) into Front Drawer (E)
then tighten camlock small (HW3) using screwdriver.
Insert Bottom Drawer (I) with laminated face facing upward
then put Back Drawer (H) and secure with Screw M8x39mm (HW9).




STEP3: Use Screw M4x12mm (HW7) to attach Handle (HW11)
to the Front Drawer.
Install the metal runner (HW RM35A) into position as shown in picture.
Secure with screws M3.5x13mm (HW10).




STEP4: Insert the Screw M3.5x15.5mm (HW18) and wedge (HW17)
into the bottom of the drawer according to the picture.




STEP5: Insert Cambolt Big (HW1) into Top Board (A).




STEP6: Insert Dowel Big (HW5) into Side Board Left (C) and Side Board Right (D). Continue with securing part of the metal runner (HW RM35A) into position as the above image, using screw M6x10.5mm (HW8).




STEP7: Attach Side Board Left (C) and Side Board Right (D) into Top Board (A). Secure with Camlock Big (HW2) and tighten it using screwdriver.




STEP8: Insert Back Board (J) then Bottom Board (B) facing front, secure with Screw M7x50mm (HW15), tighten screws using Allen Key (HW16).




STEP9: Insert Cambolt Big (HW1) into Bottom Board (B).




STEP10: Now let's combine the bottom skirt. Start with installing Corner Brace (HW BC410) into Bottom Skirt 2 (L) using Screw M4x16 (HW14). Do not overtight screw yet, leave around 2mm gap.





STEP11: Combine components from step 10 with remaining Bottom Skirt 1 (L), using Screw M4x16 (HW14). Do not overtight screw yet, leave around 2mm gap.






STEP12: Combine the Bottom Skirt 2 from step 11 with remaining Bottom Skirt 1 (K), using Screw M4x16 (HW14). Do not overtight screw yet, leave around 2mm gap.





STEP13: Insert Dowel Big (HW5) into assembled bottom skirt.




STEP14: Bring the assembled bottom skirt and insert into Bottom Board of the Night Stand .Secure with Camlock Big (HW2) then tighten using screwdriver.




STEP15: Remove plastic cap from Legs. Insert the bolt of the Leg (LS20B1) into hole of corner brace as shown in figure. Insert Flange Nut (HW12) first into the hanger bolt of leg, tighten all the flange nuts using provided Wrench (HW13). Ensure that all legs has been tightened, then continue with tighten all screws on the corner brace.



STEP16: Hold the sides of drawer, position the wheel of rail at drawer back and the wheel of rail at side boards, according to the image. Slide in the drawer bring the product into up right position into the night stand.



STEP17: Use Wedge (HW17), Screw M 3.5 x15.5 (HW18) to tighten the back of Night Stand by using screwdriver. Please align the top board and bottom board in 90° position against the side board, before securing the wedges (HW17).



STEP18: Assembly is complete.

TIPPING RESTRAINTS KIT INSTALLATION GUIDANCE

Different wall materials require unique wall fasteners.

The wall plugs (AA2) and screws (AA3) are designed for fixing to concrete walls only.

Please consult your local hardware store to ensure you are using the correct hardware for your wall type.

