



Contents:

- Upper Leg (1) _____ Large Ring (1) _____
- Lower Leg (1) _____ Small Ring (1) _____
- Swivel (1) _____ Parts Bag (1) _____
- Seat (1) _____

Completed By: _____




Upper Leg




Lower Leg

Start by crossing Upper Leg with Lower Leg. Fit flat center-sections of legs together.



Rotate Swivel 45°, allowing easy access to holes. Line up swivel with holes on top of legs. Use 4 - 1 1/2" rounded-head screws and 4 nuts to attach.

LEAVE LOOSE FOR ADJUSTMENT



Attach Small Ring by lining up with Upper Holes on legs. Use 1 1/2" screws w/tapered end to attach. A drill with the correct philips bit will aid in getting the screws started


LEAVE LOOSE FOR ADJUSTMENT



Attach Large Ring by lining up holes in ring with lower holes in legs. Insert 2" bolt through ring then leg, fastening nuts on inside of leg. Work on one hole at a time.

TIGHTEN ALL BOLTS ON LOWER RING, UPPER RING, AND SWIVEL.

Nuts fit 7/16" wrench



Turn Cushion upside-down and place base upside-down on it, lining up holes from swivel with cut-outs in cardboard on the seat. Use 1 1/2" wood screws to attach. Predrilling holes may assist in driving the screws into the seat.



Insert glides into bottom of legs using a mallet.

Enjoy your Stool



You can also view our Instructional Video on www.hollandbarstool.com