

GRAIN COVER SYSTEMS

GRAINMAX™ **PROTECTOR™**

OVAL/REC UNFOLD GUIDE


MULTI-PIECE with RAINFLAP & STRAPS

(Read All Notes Before Starting Cover Installation)

Note: Before unrolling, verify white side of cover will face upward to avoid unrolling backwards and repositioning cover.



1
STEP

- ◆ Divide bunker into sections based on the number and width of pieces required (start at the end of the bunker the wind is coming from).
- ◆ Piece #1 should be aligned at the 1st section division line. Place a pipe through the roll core and hang chains from a forklift, loader or other piece of equipment down to each end of the pipe to dispense roll. Carefully remove wrapping, as to not cut grain cover. Remove and retain installation instructions if attached.
- ◆ Tie a rope noose around the first 10 feet of cover and fold back on itself. Rope goes up and over the pile to a pulling vehicle (a ventilation tube on top ridge keeps rope from sinking into the grain).




2
STEP

- ◆ Dispense across width of the pile with an equal distance of overhang on both sides. Piece #2 will be placed next to Piece #1 and dispensed across the width of the pile. (important: check fold configuration to assure the RainFlap™ is in the correct position if included, if cover contains Fortress™ internal strap system, be sure to position the end panel without straps toward the end of the bunker).
- ◆ Join piece #1 and #2. Unfolded Piece #1 down the end slope, white side up (check fold configuration prior to dispensing). Unfold Piece #2 the opposite direction. Utilize ballast or turn vacuum fans on to help secure if necessary.



FINAL LAYOUT

- ◆ Place additional pieces next to the previous deployed edge, continue to dispense, join and unfold additional pieces as required.
- ◆ If the bunker has a tower inside, unroll the cover section on each side of the tower. You will need to cut the cover to fit around the tower. Scraps from outside edges can be used to fill voids in the tower, if needed.
- ◆ If you have bunker walls, overhang the grain cover edge by 3' and complete attachment to the side of the wall.



Note: To the best of our knowledge, unless otherwise stated, these are typical property values and are intended as guides only, not as specification limits. Chemical resistance, odor transmission, longevity as well as other performance criteria is not implied or given and actual testing must be performed for applicability in specific applications and/or conditions. RAVEN INDUSTRIES MAKES NO WARRANTIES AS TO THE FITNESS FOR A SPECIFIC USE OR MERCHANTABILITY OF PRODUCTS REFERRED TO, no guarantee of satisfactory results from reliance upon contained information or recommendations and disclaims all liability for resulting loss or damage. Limited Warranty available at www.ravenefd.com

RAVEN ENGINEERED FILMS

P.O. Box 5107 Sioux Falls, SD 57117-5107
Ph: +1 (605) 335-0174 • TF: +1 (800) 635-3456

© 2016 RAVEN INDUSTRIES INC. All rights reserved.

efdsales@ravenind.com
www.ravenefd.com

RAVEN

071917 EFD 1449