

Galaxy integration for victor v5.7

Release Notes

8200-1147-1266
Document Revision: A0
May 2021

This document provides important information about the victor Integration Software for Galaxy Intrusion Integration. Read this document before you install the product.

Product: Unified Galaxy Intrusion Integration

- Integration Software Version: 3.91.91.0

This driver release is qualified with victor when installed on:

- victor Unified Systems v3.91 (C•CURE v2.90 and victor v5.6)
- victor only Systems v5.7

Overview

The victor platform provides seamless integration with the Honeywell Galaxy Intrusion Security System, allowing customers to monitor their important intrusion system devices from victor. The software also monitors the Intrusion Panel Status, Set/Unset Partition, Activate/De-activate Output, and Bypass/Reset Zones.

Features

The Unified victor Application Server integration software for Galaxy Intrusion offers the following features:

- Supports GD-48/96/264/520 Dimension Intrusion Panels.
- Provides a descriptive display of Panels, and RIO Events Received.
- Synchronizes Panel to import data about the following objects:
 - Partition
 - Zones
 - Secondary devices

Note: When Synchronize from Panel action is performed, the User objects are not synchronized.
- Supports the following actions to control the Galaxy objects:
 - Zone: Bypass or Reset
 - Output: Activate or Deactivate
 - Partition: Set or Unset
- Polls for output, zone, partition, system, and RIO status.
- Supports Audit and Journal Log.
- Supports instant Manual Actions.
- Runs as a Windows service.
- Supports TLS 1.2 for security.

Hardware and Firmware Requirements

The victor Galaxy Intrusion Integration supports the following hardware:

- GD-48: v6.10, v6.50, v6.70, v6.79, v6.92

- GD-96: v6.70, v6.79, v6.92
- GD-264: v6.70, v6.79, v6.92
- GD-520: v6.70, v6.79, v6.92

Contents of the Installation Package

Table 1: Installation Package lists the contents of the Galaxy Intrusion Integration installation package:

Table 1: Installation Package

File	Description
Galaxy_Integration.exe	Galaxy Intrusion Integration software setup file
vUC-Galaxy-v5-7-UM-8200-1147-1267-A0-en.pdf	Galaxy Intrusion Integration User Manual
vUC-Galaxy-v5-7-RN-8200-1147-1266-A0-en.pdf	Galaxy Intrusion Integration Release Notes

Supported Installation Types

The victor Galaxy Intrusion Integration supports the following installation types:

- Unified Standalone
- victor Standalone
- Unified Enterprise
- victor Enterprise

Pre-Installation

Before you install the Galaxy Intrusion Integration, ensure that your system meets the following criteria:

On the victor Application Server:

1. You must have appropriate Windows permissions.
2. You must be a member in the local Administrators group, or have equivalent privileges.
3. You must install the victor Application Server with the following option:
 - Galaxy Intrusion

On the clients:

1. You must have appropriate Windows permissions.
2. You must be a member in the local Administrators group, or have equivalent privileges.
3. You must install the victor client.

Installation

Note:

- You must install the Galaxy Intrusion Integration in the same folder as victor. If the correct version of victor is not installed, a message is displayed prompting you to install the correct version.
- It is recommended to stop the CrossFire services before initiating the installation of Galaxy Intrusion Integration.

Follow the steps to install the Galaxy Intrusion Integration Software on the server and remote clients:

1. Double-click the `Galaxy_Integration.exe` file. The Install Wizard begins. The GALAXY Intrusion Integration **Welcome** screen appears.
2. Click **Next** and follow the Install Wizard prompts.
3. On the **License Agreement** page, select the **I accept the terms in the license agreement** check box and then click **Next**.
4. Click **Finish** to complete the installation.

Note: The Galaxy Intrusion Integration server components cannot be installed on a victor Application Server MAS.

Post-Installation

Perform the following steps after installation:

1. Launch the **Server Configuration Application**:
 - a. On the taskbar, click the **Start** button and then click **All Programs**.
 - b. Click **Tyco**, right-click the **Server Configuration** and then click **Run as Administrator**. The Server Configuration Application page opens.
2. Start the **CrossFire Services**:
 - a. On the **Server Configuration Application** page, click to open the **Services** tab.
 - b. Ensure that both Crossfire Framework Service and Crossfire Server Component Framework Service are running.
 - c. In the **Extension Services** area, locate the **Galaxy Driver Service**. Select the **Enabled** check box and then click the **Start** button. The status of the Galaxy Driver Service changes to **Running**.
3. Launch the victor client:
 - a. On the taskbar, click the **Start** button and then click **All Programs**.
 - b. Click **victor**.

Upgrading the Galaxy Integration

The v5.7 Galaxy driver supports the following upgrade scenarios:

- Upgrade from v5.3 to v5.6/v5.7
- Upgrade from v5.4.1 to v5.6/v5.7

To upgrade the Galaxy driver from a version earlier than v5.3 to v5.6/v5.7, follow an incremental upgrade path to get to version 5.3. You must upgrade the victor installation before you upgrade the Galaxy Intrusion Integration. For example:

- If the current driver is a victor v5.1 compatible driver, upgrade incrementally to a victor v5.3 compatible driver, and then upgrade to a victor v5.6/v5.7 compatible driver to maintain data integrity.
- If the current driver is a victor v5.2 compatible driver, upgrade incrementally to a victor v5.3 or v5.4.1 compatible driver, and then upgrade to a victor v5.6/v5.7 compatible driver to maintain data integrity.

Note: This driver is compatible with victor v5.6. A new installation or resynchronization is not required if the integration was installed on victor v5.6 and you upgrade to victor v5.7.

Caution:

- If you have made any changes in the configuration file - `TSP.Enterprise.Intrusion.Galaxy.Server.GalaxyDriverService.exe`, ensure that you back up the file before upgrading. The configuration file is located at `Tyco\CrossFire\ServerComponents`.
- If you upgrade victor and reboot your system before you upgrade the Galaxy integration, the Galaxy driver is stopped. You must upgrade the Galaxy integration to a victor v5.7 compatible driver before you can start the Galaxy driver.

Follow the steps below to upgrade the Galaxy integration from v5.3 or v5.4.1 to v5.7.

1. Use the victor installer or the Unified installer to upgrade victor to v5.7.
Note: Click **Later** on the prompt that appears after you upgrade victor. Do not click **Reboot**.

2. Run the Galaxy Integration installer.
3. Reboot the machine

Scalability

The driver supports 100 panels per server.

Language Support

This driver supports the English (US) language.

Compatibility Matrix

Table 2: Compatibility Matrix lists the Compatibility Matrix for the Galaxy Intrusion Integration:


Table 2: Compatibility Matrix	
victor versions 5.6 and 5.7	
Partner	Honeywell
Partner Product	Galaxy GD-48, GD-96, GD-264, GD-520
Partner Product version	Firmware -6.10, 6.50, 6.70, 6.79, 6.92
Integration driver version	3.91.91.0
victor License option	ADVC-GALAXY
Enterprise certified	Supported
Redundancy certified	Yes (everRun Enterprise)
Supported Server OS	All OS supported by victor server
Supported Client OS	All OS supported by victor Client
Supported SQL	All SQL supported by victor server

Known Issues and Limitations

This section describes the C•CURE 9000 Galaxy Intrusion known limitations.

- After installing Galaxy integration with the **Connection Strings Encrypted** check-box selected, Crossfire services failed to start.
Note: The following are the recommended steps for installing/upgrading the Galaxy Integration:
 1. Disable the check-box Connection Strings Encrypted in the Database tab under Server Configuration Application.
 2. Install the Galaxy Integration.
 3. Enable the check-box Connection Strings Encrypted again.
- If you install the Galaxy Intrusion Integration driver on remote clients, the **Integration Setup dialogue box** appears and you may be prompted to select an **Installation Option** for **Redundancy sever**. Ignore this message and click **Next** to continue with installation. If you select the **Redundancy sever installation using supported third party Redundancy Check Box**, provide the virtual server location, and then click **Next**; this selection is ignored and there is no functional impact.
- Performing **Set/Unset** actions on multiple **Galaxy Partitions**, may fail to Set or Unset certain Partitions. This can occur when action is performed on more than ten partitions.

- Performing an Activation or Deactivation action (manual Action or Galaxy Action) on a **Line 3** or **Line 4** Output from victor is not supported in this version of the Galaxy Intrusion Integration.
- This version of Galaxy Intrusion Integration supports only Microtec protocol.
- **Context Menu** is not displayed for Galaxy objects in victor client connected to MAS.
- Refreshing MAP in victor client connected to MAS results in displaying Galaxy object with icon 'X'
Workaround: Relaunch MAP.
- On a victor MAS Remote Client, **Left Click** action is not performed on Galaxy object configured in MAP.
- The Virtual Keypad of the panel locks up occasionally.
Workaround: You can wait for some time or close and open the Virtual keypad.
- There is a delay in Virtual Keypad response due to limitation in Galaxy panel.
- You can launch multiple Virtual Keypads in victor enterprise installation or on remote clients. If multiple Virtual Keypads are launched, then the activity performed on one Virtual Keypad is reflected on all the Virtual Keypads, hence launching multiple Virtual Keypads are not recommended.
- If multiple intrusion integrations (such as Neo, DMP, Galaxy, Sur-Gard and Bosch) are installed on the system, then performing the uninstallation of individual intrusion integration with the option **Database Drop** selected is not recommended as this will cause the other intrusion integrations to malfunction.
- If multiple intrusion integrations (such as Neo, DMP, Galaxy, Sur-Gard and Bosch) are installed on the system, then performing the upgrade of individual intrusion integration is not recommended. User must perform the upgrade of all the intrusion integrations at the same time.
- Every time Galaxy driver is restarted, following warning message gets logged in the Event Viewer. However this doesn't have any impact on integration.



Note: This version of driver only encodes and decodes payloads when connecting to the Galaxy Panels. Encryption of communication between the driver and panel is not supported currently, but it is planned for future versions. Authentication is not supported for this version of driver as the third party firmware on the Galaxy Panels does not support it.

Defects Fixed

Table 3: General Fixes following table lists the defects fixed in this version of the software:

Table 3: General Fixes

Category	SPAR Number	SPAR Description
Driver	728366	When victor only v5.4.1 system is upgraded to victor v5.6, then the upgrade of Galaxy v2.9/v5.6 integration fails.

End of Release Notes

The trademarks, logos, and service marks displayed on this document are registered in the United States [or other countries]. Any misuse of the trademarks is strictly prohibited and Johnson Controls will aggressively enforce its intellectual property rights to the fullest extent of the law, including pursuit of criminal prosecution wherever necessary. All trademarks not owned by Johnson Controls are the property of their respective owners, and are used with permission or allowed under applicable laws.

Product offerings and specifications are subject to change without notice. Actual products may vary from photos. Not all products include all features. Availability varies by region; contact your sales representative.

© 2021 Johnson Controls. All right reserved. JOHNSON CONTROLS, TYCO, and AMERICAN DYNAMICS are trademarks of Johnson Controls.