


SHARP®

SPC1010DX Accu-Set Digital Wall Clock Instruction Manual & Warranty

Thank you for your purchase of this quality clock. The utmost care has gone into the design and manufacture of your clock. Please read these instructions and store them in a safe place for future reference.

FEATURES

1. LCD display
2. Wall mount
3. UP / 12/24 button
4. TIME SET button
5. CAL. SET button
6. Lithium battery compartment
7. Battery compartment
8. DOWN / °C/°F button
9. Table stand
10. TIME ZONE switch
11. RESET button
12. DST ON/OFF button



SETTING PROCEDURE FOR THE CLOCK

Before inserting the 2 AA batteries into the battery compartment

1. Slide the **Time Zone** switch to the correct time zone.
2. Press the **DST** button to turn on the DST function if your area does observe DST.
3. Once all above is completed, insert 2 x AA/LR6 batteries (preferably alkaline batteries) into the battery compartment, following the polarity as shown on the diagram inside the compartment.
4. The clock will fast forward to the correct time.

Note: Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries, only batteries of the same or equivalent type as those recommended are to be used. Do not mix new and old batteries.

OPTIONAL MANUAL TIME SET FUNCTION

1. Press and hold the **TIME SET** button, the hour digit will start flashing.
2. Press the **UP** or **DOWN** button to advance to the correct hour.
3. Press the **TIME SET** button again, the minute digit will start flashing.
4. Press the **UP** or **DOWN** button to advance to the correct minute.
5. Press the **TIME SET** button again to confirm the setting.

OPTIONAL MANUAL CALENDAR SET FUNCTION

1. Press and hold the **CAL. SET** button, the year digit will start flashing.
2. Press the **UP** or **DOWN** button to advance to the correct year.
3. Press the **CAL. SET** button again, the month digit will start flashing.
4. Press the **UP** or **DOWN** button to advance to the correct month.
5. Repeat the above steps for date and language, and press the **CAL. SET** button again to confirm the setting.

TEMPERATURE DISPLAY

The temperature displays indoor temperature. At anytime switch between Celsius or Fahrenheit by pressing °C/°F button.

12/24 HOUR DISPLAY

Press the 12/24 button to switch between 12 hour or 24 hour display mode.

DST FUNCTION

- If you live in an area that does observe DST, press the **DST** button to turn on the DST function. The clock will now adjust automatically each spring and fall to correct for the 1-hour time change.
- If you live in area that does not observe DST, such as Arizona, Hawaii, or parts of Indiana, you do not need to do any setting.

REPLACING 3V LITHIUM BATTERY

The Accu-Set time memory is maintained by a lithium button cell battery, model CR2032. The expected life of this battery is about 3 years. Be sure that the two AA/LR6 batteries in the clock are fresh. This battery is located in the small battery compartment. Open the lithium battery compartment with a screwdriver and replace the CR2032 lithium battery observing the polarity. Then, close the compartment.

MAINTENANCE

- The batteries should be replaced if the display screen or alarm becomes dysfunctional or weak.
- Please use a soft cloth to clean the clock.
- Do not use any corrosive cleanser or chemical solutions on the clock.
- Do not expose to water or outdoors, this is for indoors use only.

RESET

- If the clock display does not work during setting, please check that batteries are in battery compartment completely and correctly with battery polarity as shown on the diagram. If this doesn't work, use a slim but blunt object e.g. toothpick etc. to press **RESET** hole, then the clock will return to the initial mode.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC WARNINGS

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**For Customer Service Please Call Toll Free at
1-(800)-221-0131 and ask for Customer Service.
Monday-Friday 9:00 AM - 4:00 PM EST**

Please call for assistance before returning the clock to the store.

One Year Limited Warranty

M.Z. Berger & Company warrants the original consumer purchaser of this product that it shall be free of defects in materials and workmanship for one year from the purchase date of this product. Defects caused by tampering, improper use, unauthorized modifications or repairs, immersion in water or abuse are not covered by this warranty. If a defect covered by this warranty occurs during the warranty period, wrap your clock carefully and send it to the following address:

MZ Berger Service Center
29-76 Northern Boulevard
Long Island City, NY 11101

You must include a Proof of Purchase, either the original receipt or a photocopy and a check or money order for USD \$6.00 to cover the cost of handling. Also include your return address inside the package. M.Z. Berger will repair or replace the clock and return it to you. M.Z. Berger will not be liable for any loss or damage, including incidental or consequential damages of any kind; from any breach of warranty either expressed or implied relating to the product. Since some states do not allow the exclusion or limitation of incidental or consequential damages, this limitation may not apply to you.

Printed in China

Model SPC10100DX

AccuSet and SHARP registered in the U.S. Patent and Trademark office.