# **Manual Supplement**

Manual Title:5320A Getting StartedSupplement Issue:3Part Number:2634331Issue Date:5/17Print Date:September 2006Page Count:1

Revision/Date: 2, 10/08

This supplement contains information necessary to ensure the accuracy of the above manual.



### Change #1, 449, 504

On pages 4, add the following to the *General Specifications*:

#### **Electromagnetic Compatibility (EMC)**

International......IEC 61326-1: Basic Electromagnetic Environment

CISPR 11: Group 1, Class A

Group 1: Equipment has intentionally generated and/or uses conductively-coupled radio frequency energy that is necessary for the internal function of the equipment itself

Class A: Equipment is suitable for use in all establishments other than domestic and those directly connected to a low-voltage power supply network that supplies buildings used for domestic purposes. There may be potential difficulties in ensuring electromagnetic compatibility in other environments due to conducted and radiated disturbances.

Emissions that exceed the levels required by CISPR 11 can occur when the equipment is connected to a test object.

### Change # 2, 468

On page 4, under **A** Fuse Protection, replace the existing content with:

## Change #3, 501, 504

On page 4, under **Power Consumption**, add Measurement:

Measurement ...... IEC 61010-2-030: CAT II 300 V

Remove, Safety Class, and Electrostatic Discharge and add:

Safety

Mains ...... IEC 61010-1: Overvoltage Category II, Pollution Degree 2

On page 8, in the *Test Current Measurement* section, replace the **Range** with:

On page 10, following **AC/DC Voltage Uncertainty**, *Current*, replace **Range** with:

5/17 1