



Water Connects Us®


MODELS

V-600-AA and V-500-AA


Vacuum Breaker Flush Connection

Installation Instructions

1. Cut length of tube to size, if required, no less than 6" from - CL (critical line) to end of tube. Slide the spud coupling, nylon slip gasket, rubber gasket and spud flange over the vacuum breaker tube and insert tube into fixture spud. Hand tighten spud coupling on fixture spud. Replace spud flange and gaskets, if necessary.



2. Align flushometer on top of vacuum breaker flush connection and secure by hand tightening vacuum breaker coupling. Align flushometer body and securely tighten tailpiece coupling, vacuum breaker coupling and spud coupling, respectively.



Additional instructions per ASSE 1001 and CSA B64.1

- The device shall not be subjected to continuous pressure for more than 12 hours.
- Check local plumbing code for specific mounting - height requirements.
- The device shall not be installed where the venting of water from device during its normal functioning causes damages.
- The device shall be installed downstream of last valve.
- The device shall be installed with a minimum of height of twice the water rise from flood level rim of the fixture to the critical level of the vacuum breaker per Clause 5.1 from CSA B64.1.

SLOAN
10500 Seymour Avenue
Franklin Park, IL 60131
P: 847.671.4300 / 800.9.VALVE.9
F: 847.671.4380 / 800.447.8329
customer.service@sloanvalve.com
www.sloanvalve.com