







MANHATTAN
COMFORT
Joy Dressing Table





For Best Results


- Do not throw away packaging materials until assembly is complete.
- Assemble item on a soft surface, such as cardboard or carpet, to protect finish.
- Proper assembly requires two people.



Tools Required

























Included in this Package



Maximum
weight
supported.

01	LOWER TOP	x1
02	RIGHT SIDE	x1
03	LOWER LEFT SIDE	x1
04	CENTRAL TOP	x1
05	RIGHT SIDE OF THE CELLAR	x1
06	SHELF OF THE CELLAR	x5
07	CELLAR LEFT SIDE	x1
08	SHELF	x2
09	UPPER LEFT SIDE	x1
10	UPPER TOP	x1
11	MOBILE SHELF	x1
12	LOWER BACK	x2
13	UPPER BACK	x3
14	CELLAR BACK	x1
15	LOWER DOOR	x2
16	DOOR WITH MIRROR	x1
17	NARROW UPPER DOOR	x1
18	FITTINGS	x1

18 Fittings

 A - HANDLE x3	 B - MINIFIX SCREW x13	 C - 15MM CONNECTOR x13	 D - 21MM SCREW COVER (MINIFIX) x13	 E - 7X50 SCREW x12	 F - ALLEN WRENCH x1
 G - 6X30MM WOODEN DOWEL x34	 H - 1/4X25MM SCREW x4	 I - 1/4X35MM SCREW x8	 J - M5X25MM SCREW x3	 K - 3,5X25MM SCREW x4	
 L - 5X40MM SCREW x10	 M - FEET KIT x1	 N - H PROFILE x1	 O - 10X10 NAIL x56	 P - FIXER FOR BACK WARDROBE x16	 Q - 03MM DOOR WING x2
 R - 12MM DOOR WING x6	 S - 26MM FRAME WING x8	 T - 3,5X14MM SCREW x32	 U - WHITE GLUE x1	 V - SHELF SUPPORT x4	


Where to find the items

Box 01			
01	06	11	16
02	07	12	17
03	08	13	18
04	09	14	
05	10	15	

Prepare the pieces


Step 1

Insert the wooden dowels (G) into parts 03, 04, 06, 08 and 09. Remember to use the glue (U).



Step 2


Insert screw (B) into part 02, 04, 07 and 09. Tighten to the limit.




Prepare the pieces

Step 3


Fix the hinges (S) on the marks on the doors 15, 16 and 17 using sixteen screw (T)



T - 3,5X14MM SCREW
x16







S - 26MM FRAME WING
x8




Step 4


Fix the door wing (R) on the marks on the 02, 03 and 07, using the screw (T).
And the door wing (Q) on the marks on of the part 09, using the screw (T)



T - 3,5X14MM SCREW
x16



Q - 03MM DOOR WING
x2




R - 12MM DOOR WING
x6

Assembly


Step 5

Put the parts 01 and 02 together and use two screws (E) and the Allen wrench (F).



Step 6



Put the parts 01 and 03 together and use two screws (E) and the Allen wrench (F).



Step 7

Put the glue (U) in the wooden dowel (G) already fixed into parts 03. Then put parts together with part 04.

Insert the four minifix connectors (C) in part 03 and 04 and rotate clockwise as shown. Tighten to the limit.






Tighten the minifix up to the limit to assembly don't be slack.

Assembly



Step 8

Put the glue (U) in the wooden dowel (G) already fixed into parts 06. Then put the parts 06 together with part 05. Turn the part and use the five screws (L) to fix the pieces.







Step 9

Put the part 05 together in the part 02 and Insert four screw (K) through parts 05 according to the drawing.



Step 10


Put the part 07 together in the parts 04 and 06, and Insert five screw (L) in part 07 and two screw (E) in part 04.




Assembly

Step 11

Put the glue (U) in the wooden dowel (F) already fixed into part 08, then insert the parts 08 together in the part 07. Use four minifix connector (C) in parts 08 and rotate clockwise as shown. Tighten to the limit.




Tighten the minifix up to the limit to assembly don't be slack.




Step 12

Put the glue (U) in the wooden dowel (F) already fixed into part 08. Then, put the part 04, 08 and 09 together and use five minifix connector (C) in parts 08 and 09, and rotate clockwise as shown. Tighten to the limit.






Tighten the minifix up to the limit to assembly don't be slack.



Step 13




Put feet on part 01 as the drawing. On each foot (M), use two screws (I) with the Allen wrench (F).



Assembly




Step 14

Put the part 10 together in the parts 02, 07 and 09, and use six screw (E) with the Allen wrench (F).






Step 15

Insert the screw (H) through parts 02 and 03 according to the drawing using the Allen wrench (F). The screw (H) must fix parts 02 and 03 on the feet (M).



Step 16


Fix the backs 12, 13, and 14 using the nails (O) and fixer for back wardrobe (P). Then fit the profile (N) into the Bottom part of this back (12)



Assembly



Step 17

insert four shelf support (V) in parts 02 and 03.
Then insert the part 11.



Step 18

Insert the frame wing (S) together in the door wing (R) for fix the doors (15) in parts 02 e 03



Assembly


Step 19

Insert the frame wing (S) in the door wing (R) for fix the door (16) in part 07.

Then insert a frame wing (S) in the door wing (Q) for fix the door (17) in the part 09.


When it is ok,

Insert the screw (J) from inside the door, tighten into the handle (A) on the outside.



Assembly


Step 20




Safe and Security

KIT FOR DRYWALL DW = DRYWALL


Go to Step 14




DW2 - x1



DW3 - x3




DW4 - x1




DW5 - x1

KIT FOR MASONRY MW = MASONRY WALL

Go to Step 18



MW1 - x4



MW2 - x4



MW3 - x4



MW4 - x4



MW5 - x2

WARNING



Serious or fatal crushing injuries can occur from furniture tip-over. **ALWAYS** secure this furniture to the wall using tip-over restraints. To further reduce the risk of serious injury and death from tip-overs:

- Place heaviest items in the lower drawer.
- Do not set TVs or other heavy objects on the top of this product.
- Never allow children to climb or hang on drawers doors or shelves.

**DON'T PULL THE FURNITURE TO CHANGE IT.
INSTEAD OF PULLING, PUSH IT ON THE DIRECTION YOU WANT.**


KIT FOR DRYWALL

1. Make holes on the wall following the model below and specifications:

- \varnothing 14mm (9/16") drill.
- ∇ Depth of 60mm (2.36").




Use an electric drill.



Step 21

8. Put the corner (DW4) on the upper top (10) of the product.




Step 22

Safe and Security


9. Put the Dressing Table to the wall and aligning the hole in the safety block with the hole that was made the drywall. Done so, insert the screw up to its maximum limit on.

Step 23



10. Put the cover of corner (DW5) on the corner (DW4).

Step 24



KIT FOR MASONRY


Step 25

1. Make holes on the wall following the model below and specifications:

- Ø 8mm (5/16") drill.
- Depth of 50mm (1.96").





Use an electric drill.





Step 26

2. Insert the bushing into the hole made on the wall.



Step 27

3. Put the screws into the bushings, but don't tighten until the end. It's necessary 0.39" (10mm) left to fit on the lock.





4. Put the lockes on the horizontal as the pictures below.

Step 28



Check the distance between wall's holes.
It must be the same distance between centers
of dresser's device.





5. Drag the product carefully until you meet the screw's head.
Fit the screw into the locker as the picture below.

Step 29



Put the two pieces together
and insert the seal.



TAKING GOOD CARE OF YOUR FURNITURE

Cleaning and caring instructions:

- Wipe the wood furniture down with a moist cloth to properly clean the furniture.
- Do not forget to dry your furniture out. Humidity can damage the finish or create mould.
- Chemical products are not recommended;
- Never clean the furniture with scouring powders, steel scrubber pads or any other product which can scratch its
- Furniture surfaces should not be covered with colored plastic or paper sheets.
- Avoid dragging objects on top of the furniture. They might scratch the finishing.
- Wood furniture are made of mould and termites resistant materials, however, it is recommended to use termiticides in infested places before installing the furniture.
- Avoid furniture exposure to direct Sun light. Drapers suggested.