

2016

WARRANTY, MAINTENANCE AND ROADSIDE ASSISTANCE GUIDE

IT'S YOUR RIDE.
KNOW WHAT'S UP.

COTCI-WMR16-01



what moves you

**IMPORTANT NOTICE
FOR THE
DELIVERING SALES CONSULTANT**

Please affix the New Vehicle Information
Statement in this area

IMPORTANT: Vehicle Delivery Certificate to be completed and signed at the time of delivery.

Table of Contents

INTRODUCTION

Satisfaction Over The Years	2
-----------------------------------	---

SCION NEW VEHICLE WARRANTY

Warranty Coverage At A Glance	3
General Warranty Information	4
Towing	4
Powertrain Warranty	5
Basic Vehicle Warranty	6
Accessory Warranty	6
Paint Defect Warranty	6
Safety Restraint Systems	6
Corrosion Perforation	6
Emission Control Warranty	7
What Your Warranty Does Not Cover	10

OWNER INFORMATION

General Information	12
Where To Go For Maintenance	12
Replacement Parts	13
Emergency Repairs	13
Buckle Up For Safety	14
Service For Radio And Sound Systems	14
When You Need Help	15
The Scion Commitment	17
Tire Pressure Monitoring System	19

EXTRA CARE PROTECTION

Extra Care Protection	21
-----------------------------	----

REQUIRED MAINTENANCE

Regular Maintenance Service	22
Interior Electrical Component Precautions	23
Required Maintenance	25
Maintenance Service Record	27
An Explanation of Scheduled Maintenance Items	31

OWNER'S RESPONSIBILITIES

Your Responsibilities As An Owner	33
Protecting Against Corrosion	34

SCION ROADSIDE ASSISTANCE

Scion Roadside Assistance	35
Extended Coverage	39
Scion Certified Collision Centres	39

SAFETY TIPS

Seatbelts and SRS Airbags	40
Child Safety / Pet Safety	41
Cautions when Driving and Stopping	42
Floor Mat Installation Caution	44

Satisfaction ... Over the Years

At Scion, our top priority is always our customers. We know your Scion is an important part of your life and something you depend on every day. It's for that very reason, we're dedicated to building products of the highest quality and reliability.

Our excellent warranty coverage is evidence that we stand behind the quality of our vehicles. We're confident, as you should be, that your Scion will provide you with many years of enjoyable driving.

Scion wishes to ensure your continued satisfaction and may need to contact you regarding special programs to assist with servicing beyond the normal warranty policy. When we establish special programs, we mail details to all applicable owners we have on record. It is for that reason, you need to utilize the Customer Information Change Certificate in the centre of this booklet should your address change, or if you've purchased this vehicle from a previous owner.

To provide you with additional protection against unexpected service costs, we offer our range of Scion Extra Care Protection plans. We'll tell you more about ECP later in this booklet. Your dealership can help you select the best plan for you.


Our goal is for every Scion customer to enjoy outstanding quality, dependability and peace of mind throughout their ownership experience.

We want you to be a satisfied member of the Toyota family for many years to come.

You'll find that our after-sales service is second to none. The combination of Scion trained technicians using Scion Genuine Parts is the reason why only your Scion dealer can provide you with the level of service excellence that your Scion deserves. We are committed to providing you with excellence in service at competitive rates.

Scion New Vehicle Warranty

WARRANTY COVERAGE AT A GLANCE



(A) Performance warranty (related parts) coverage is for 24 months or 40,000 km, whichever comes first.

* includes accessories if installed at time of delivery (see page 6 for more details) and paint defects.

Scion New Vehicle Warranty

SOME THINGS YOU SHOULD KNOW ABOUT YOUR WARRANTY:

WHO IS THE WARRANTOR?

The Warrantor for these limited warranties is Toyota Canada Inc., ("TOYOTA"), 1 Toyota Place, Scarborough, ON, M1H 1H9

WHEN DOES THE WARRANTY BEGIN?

The warranty period begins on the warranty registration date as shown on the new vehicle information statement on the inside cover of this booklet. The warranty registration date is the original in-service date and may be earlier than the date of sale.

WHICH VEHICLES ARE COVERED?

These warranties apply to all 2016 model-year Scion vehicles distributed by Toyota Canada Inc., which are originally sold by an authorized dealer in Canada and normally operated or touring in Canada, United States or U.S. territories.

REPAIRS MADE AT NO CHARGE

Repairs and adjustment covered by these warranties are made at no charge for parts and labour. Components will be repaired or replaced with new or remanufactured parts at the option of Toyota Canada Inc. Replaced components are warranted for the balance of the applicable New Vehicle Warranty.

WHAT IF MY VEHICLE MUST BE TOWED?

When your vehicle is inoperative due to a warranted part failure, towing service is covered to the nearest Scion/Toyota dealer. Should you require towing, contact the Scion Roadside Assistance Centre at 1-866-9SCION-1. An authorized service provided will be dispatched to provide you with the necessary Roadside Assistance. Refer to the Roadside Assistance information on pages 35-38 for more details.

OWNER'S RESPONSIBILITY :

It is the Owner's responsibility to ensure that the vehicle is maintained and operated in accordance with the written instructions for proper maintenance and use contained in your Owner's Manual and this Warranty, Maintenance and Roadside Assistance Guide.

In an emergency situation, where an authorized Scion/Toyota dealer is not reasonably available, you may perform the repair or have the repair performed at any service establishment or by a person of your choosing. You will then be required to present the replaced parts and paid repair invoices to an authorized Scion/Toyota dealer for reimbursement of the emergency repair cost. You will be reimbursed for warranted parts at the maximum manufacturer's suggested retail price and warranted labour at a geographically appropriate hourly rate multiplied by Scion's recommended time allowance for the repair.

Maintenance records and receipts should be transferred to each subsequent owner.

Scion New Vehicle Warranty

POWERTRAIN WARRANTY

The powertrain components listed on this page are covered under the Scion New Vehicle Warranty for a period of 60 months or 100,000 km, whichever comes first, subject to the exceptions indicated under "What Is Not Covered" on pages 10 & 11.

ENGINE:

✓	Cylinder Block/Head And All Internal Parts
✓	Intake Manifold
✓	Timing Gears
✓	Timing Gear Chain/Belt And Cover
✓	Flywheel
✓	Valve Covers
✓	Oil Pan
✓	Oil Pump
✓	Water Pump
✓	Fuel Pump
✓	Engine Control Module
✓	Engine Mounts
✓	Seals And Gaskets for the above listed components

TRANSMISSION AND TRANSAXLE:

✓	Transmission/Transaxle Case And All Internal Parts
✓	Clutch Cover
✓	Torque Converter
✓	Transmission/Transaxle Mounts
✓	Seals And Gaskets for the above listed components

FRONT WHEEL DRIVE:

✓	Final Drive Housing And All Internal Parts
✓	Axle Shafts
✓	Driveshafts
✓	Constant Velocity Joint
✓	Front Hub And Bearings for the above listed components
✓	Seals And Gaskets

REAR WHEEL DRIVE:

✓	Axle Housings And All Internal Parts
✓	Propeller Shafts
✓	"U" Joints
✓	Axle Shafts
✓	Driveshafts
✓	Bearings
✓	Driveshaft Centre Supports for the above listed components
✓	Seals And Gaskets

Scion New Vehicle Warranty

BASIC COMPLETE VEHICLE WARRANTY

YOUR SCION VEHICLE CARRIES AN EXTENSIVE 36 MONTH/60,000 KILOMETRE WARRANTY:

The basic complete vehicle warranty covers repairs on any part of the vehicle supplied by Toyota Canada Inc. that is defective in material or workmanship, subject to the exceptions indicated under "What Is Not Covered" on pages 10 & 11.

Coverage is for a period of 36 months or 60,000 km, whichever comes first, with the exception of wheel alignment, balancing and related adjustments, which are covered for 12 months or 20,000 kilometres, whichever comes first.

ACCESSORY WARRANTY

TOYOTA GENUINE ACCESSORIES* WARRANTY:

Installed by	Toyota Dealer		Other
Date Installed	During Basic Vehicle Warranty Period	After Basic Vehicle Warranty Has Expired	During or After Basic Vehicle Warranty Period
Coverage	90 days or the balance of the basic vehicle warranty period, whichever is greater	12 months /20,000 km	12 months / unlimited km
Toyota Pays For	Parts & Labour	Parts & Labour	Parts Only

* Accessories sold and distributed by Toyota Canada Inc.

PAINT DEFECT WARRANTY

Paint defects are warranted for 36 months from the warranty registration date, or 60,000 kilometres, whichever occurs first. Any body surface, which develops a blemish under normal use due to defective materials/

workmanship, is warrantable with the exception of the items listed under "What is Not Covered" as follows:

WHAT IS NOT COVERED:

- ☐ Paint chips
- ☐ Blemishes caused by stones or gravel
- ☐ Accident or other forms of impact
- ☐ Industrial fallout or pollution
- ☐ Bird droppings
- ☐ Previous repairs or modifications to the same body panel
- ☐ Normal paint aging conditions, fading etc.

SAFETY RESTRAINT SYSTEMS WARRANTY

This warranty covers repairs needed on any seatbelt or air bag system supplied by Toyota Canada Inc. that is defective in material or workmanship, subject to the exceptions indicated under "What Is Not Covered" on pages 10 & 11. Coverage is for a period of 60 months or 100,000 kilometres, whichever comes first.

CORROSION PERFORATION WARRANTY

This warranty covers repair of any original body sheet metal found, under normal use, to have developed a perforation (hole through the body panel) from corrosion due to defects in material or workmanship, subject to the exceptions indicated under "What Is Not Covered" on pages 10 & 11.

Coverage is for a period of 60 months regardless of distance travelled.

For information on how to protect your vehicle from corrosion, see the section entitled "PROTECTING AGAINST CORROSION" on page 34.

Scion New Vehicle Warranty

EMISSION CONTROL WARRANTY

EMISSION DEFECT WARRANTY:

Toyota Canada Inc. warrants to owners of 2016 model year vehicles that the Scion vehicle:

- ☐ Was designed, built and equipped so as to conform, at the time of sale, with all applicable emission standards
- ☐ Is, at the time the warranty commences, free from defects in materials and workmanship, which may cause the vehicle to fail to conform with the applicable emission standards during the warranty period

Toyota Canada Inc. will provide you with coverage for the emission control parts listed under Item 1 on page 8 for 36 months or 60,000 kilometres, whichever comes first, under the terms of the New Vehicle Warranty. In addition, specific components may be entitled to additional coverage under the terms of the New Vehicle Warranty-Powertrain Component Coverage.

Emission Standards also require that the specified major emission control components listed under Item 2 on page 9 are covered for 96 months or 130,000 kilometres, whichever comes first.

EMISSION PERFORMANCE WARRANTY

Some Provincial and Local jurisdictions may have established periodic vehicle inspection and maintenance (I/M) programs to encourage proper maintenance of your vehicle. If an approved I/M program is in force in your area, you are eligible for emission performance warranty coverage.

If the vehicle fails to conform to the applicable emission standards during the warranty period and such failure results or will result in you having to bear any penalty or other sanctions under local, provincial or federal law,

Scion will make all adjustments, repairs or replacements that are necessary to ensure that the vehicle conforms to the applicable standard at no cost to you if:

- ☐ The vehicle has been maintained and operated in compliance with the instructions for proper maintenance and use contained in your Owner's Manual
- ☐ The vehicle has not been misused or tampered with in a manner which caused the vehicle to fail to comply with the applicable emission standard
- ☐ Fuel other than that specified in the Owner's Manual has not been used

Toyota Canada Inc. will provide you with this coverage for 24 months from the warranty registration date or 40,000 kilometres, whichever comes first.

In addition, the specified major emission control components listed under Item 2 on page 9 will be covered for 96 months or 130,000 kilometres, whichever comes first.

STATEMENT OF EMISSION PERFORMANCE WARRANTY ENTITLEMENT:

A claim under this warranty will only be available if the vehicle fails an emission short test used by a provincial emission inspection/maintenance program, which has been approved by Toyota Canada Inc. Usually this means that an owner could be subject to a penalty under provincial law because of such failure. At the date of printing this warranty, some provinces did not have vehicle inspection/maintenance programs and had not enacted laws subjecting vehicle owners to such penalties. Therefore, in some provinces or local areas, this warranty will not apply.

Scion New Vehicle Warranty

EMISSION WARRANTY PARTS LIST:

1. Emission components covered against defect for 36 months 60,000 km or 24 months 40,000 km for performance:

AIR/FUEL METERING SYSTEM

- EFI Components
 - Airflow Sensor
 - Throttle Body
 - Other Components
- Air/Fuel Ratio Feedback Control System

AIR INDUCTION SYSTEM

- Intake Surge Tank

IGNITION SYSTEM

- Ignition Coil and Igniter
- Spark Plugs

POSITIVE CRANKCASE VENTILATION SYSTEM (PCV)

- PCV Valve or PCV Orifice
- Oil Filler Cap

EVAPORATIVE CONTROL SYSTEM

- Charcoal Canister
- Fuel Tank
- Fuel Filler Cap

EXHAUST GAS RECIRCULATION (EGR) SYSTEM

- EGR Valve
- EGR Gas Temperature Sensor
- Associated Parts

CATALYST SYSTEM

- Exhaust Manifold
- Exhaust Pipe (Manifold to Catalyst and/or Catalyst to Catalyst)

MISCELLANEOUS ITEMS USED IN ABOVE SYSTEMS

- Sensors, Switches and Valves
- Hoses, Clamps, Fittings, Tubing, Sealing Gaskets or Devices and Mounting Hardware, Pulleys, Belts and idlers

Scion New Vehicle Warranty

2. Specified Major Emission Control Components covered for 96 months
130,000 km:

- Engine Control Module
- Catalytic Converter and Protector
- Data Link Connector
- Bulbs for Malfunctioning Indicator Lamp
(Check Engine Warning Light)

FACTS ABOUT THE EMISSION DEFECT AND PERFORMANCE WARRANTY

REPLACEMENT PARTS:

The emission control systems of your vehicle were designed, built, and tested using Scion Genuine Parts. Your vehicle is certified as conforming to applicable emission control standards. It is recommended that Scion Genuine Parts be used, as replacement parts.

The use of non-Scion parts and the performance of any maintenance or repair by other than a Scion/Toyota dealer will not affect your emission defect or performance warranty coverage unless the replacement parts that are used are not of equivalent quality or capacity, or the repairs are not performed at the standard required and the effectiveness of the emission control systems is impaired.

IF YOUR VEHICLE FAILS AN EMISSION TEST:

A claim may be submitted immediately upon the failure of the vehicle to conform to the applicable standards by following these steps:

1. Take the vehicle to any authorized Scion/Toyota dealer and present a copy of the emission short test report as evidence of failure. Also, take your maintenance records in case they are needed.
2. The Scion/Toyota dealer will inspect your vehicle and determine the warranty applicability within a reasonable period of time (not to exceed 30 days) from your initial vehicle delivery date to any authorized Scion/Toyota dealer or within the time period required by local or provincial law.
3. If, for any reason, the claim is denied, an explanation will be presented to you.
4. If Toyota Canada Inc. fails to notify you of its decision within the time period specified, then Toyota Canada Inc. shall be responsible for repairing the vehicle free of charge unless the delay is attributable to the owner or factors beyond the control of Toyota Canada Inc. or the Scion/Toyota dealer.
5. If you wish to obtain further information regarding the emission performance warranty, or if you have failed to receive satisfactory assistance from your Scion/Toyota dealer then you may contact:

**TOYOTA CANADA
CUSTOMER INTERACTION CENTRE
1-888-869-6828**

Scion New Vehicle Warranty

WHAT IS NOT COVERED

NON-WARRANTABLE PARTS AND MATERIALS:

The following parts shall not be covered by the warranty when they are replaced as a maintenance service ordinarily required with the Vehicle use:

- Bulbs (excluding Sealed Beam, Halogen Bulbs, High Intensity Discharge-HID, Light Emitting Diode-LED)
- Fuses
- Spark Plugs (excluding Platinum, Iridium)
- Drive Belts (except Timing Belts)
- Air Cleaner Filter Element, Oil Filter, Fuel Filter, Air Conditioner Filter, Air Filter and Fuel Pump Filter
- Brake Linings, Brake Shoe and Brake Pads
- Wiper Blades and/or Rubbers
- Room Lamp and Transmitter Battery
- Electrolyte, Air Conditioning Refrigerant, Fuel, Fluids, Oil, Grease, Lubricants and Additives

FACTORS BEYOND THE MANUFACTURER'S CONTROL:

This warranty does not cover damage or failures resulting directly or indirectly from any of the following:

- Fire, accident or theft
- Abuse or negligence
- Misuse – for example, racing & competitive events, off-roading or overloading

- Improper adjustments or repairs
- Modification, alteration or tampering, disconnection, including installation of non-Scion Approved Accessories
- Repairs and adjustments caused by improper maintenance, lack of required maintenance and/or the use of fluids, fuel, oil or lubricants other than those recommended in your Owner's Manual
- Installation of non-Scion Parts
- Airborne chemicals, bird droppings, tree sap, road debris (including stone chips), salt, hail, floods, windstorms, lightning and other environmental conditions
- Water contamination
- Dirty fuel or fuel other than that specified in the Owner's Manual
- The continued use of the vehicle once a problem has been detected (e.g. illumination of Malfunction Indicator Light [M.I.L.], excessive vibration, poor performance, etc.) resulting in consequential damage beyond the covered component
- The replacement of simultaneous parts (e.g. front/rear, left/right) where no defect is found. (e.g. cannot replace two shock absorbers, where only one is found to have a defect)
- Repairs conducted on vehicles designated at any time as salvaged, scrapped, junked, totaled or written-off

Scion New Vehicle Warranty

This warranty also does not cover the following:

NORMAL SOUND, VIBRATION AND DETERIORATION

Conditions related to normal noise, wear, vibration, deterioration, discolouration, distortion, deformation and fading.

MAINTENANCE EXPENSE

Normal maintenance services such as: engine tune-ups, lubrication, cleaning and polishing, replacement of coolant, filters, spark plugs, fuses, remote key/key fob batteries, worn wiper blades, brake pads/linings and clutch linings.

VEHICLES WITH ALTERED ODOMETER READING

Failure of a vehicle on which the odometer has been altered or changed so that the actual kilometres driven cannot be determined.

SALVAGE OR WRITTEN-OFF VEHICLES

The new vehicle warranty no longer applies on any Scion vehicle which is designated at any time as salvaged, scrapped, junked, totalled or written-off.

INCIDENTAL DAMAGES

Incidental or consequential damages associated with a vehicle failure. Such damages include but are not limited to inconvenience, the cost of transportation (unless expressly provided in this warranty), telephone calls and lodging, the loss of personal or commercial property, and the loss of pay or revenue.

TIRES

Tires originally installed on a new 2016 model year Scion vehicle are warranted by the respective tire manufacturer. Refer to the tire pamphlet provided with your Scion vehicle. If an original tire on your Scion vehicle has a defect during the term of the tire manufacturer warranty, please contact your authorized Scion/Toyota dealer for assistance.

Any implied warranty of merchantability or fitness for a particular purpose applicable to this vehicle, where permitted by law, is limited in duration to the duration of this written warranty. The performance of repairs and needed adjustments is the exclusive remedy under this written warranty or any implied warranty. Toyota Canada Inc. shall not be liable for incidental or consequential damages by reasons of this written warranty or any implied warranty.

The provision of the above-written warranties is in addition to any statutory warranties or other rights or remedies as may otherwise exist at law.

Toyota Canada Inc. does not authorize any person or corporation to assume for it any obligation or liability or make any representation in respect of the Scion New Vehicle Warranty.

Owner Information

GENERAL INFORMATION

You are responsible for ensuring that your Scion is operated and maintained according to the instructions in the Owners Manual and this Warranty, Maintenance and Roadside Assistance Guide.

You should keep detailed records of vehicle maintenance, since under some circumstances they may be required for warranty coverage. These records must include date of service, kilometres at time of service and a description of service performed and/or parts installed. For your convenience, a maintenance log is included in this manual. If you sell your vehicle, you should give your maintenance records to the new owner.

WHERE TO GO FOR MAINTENANCE

Scion recommends having maintenance performed by an authorized Scion/Toyota dealership.

Scion/Toyota dealership technicians are specially trained to maintain and repair Scion vehicles. They stay current on the latest service information through Scion technical bulletins, service publications and training courses. Feel free to ask any Scion/Toyota dealership to show you its technicians' credentials.

You can be confident you're getting the best possible service for your vehicle when you take it to a Scion/Toyota dealership.

Owner Information

REPLACEMENT PARTS

Scion recommends using only Scion Genuine Parts when you need to replace a part on your vehicle. Like all Scion products, Scion Genuine Parts are built to the highest standards of quality, durability and performance. They are also designed to fit your vehicle's exact specifications.

Your Scion/Toyota dealership maintains an extensive inventory of Scion Genuine Parts to meet your vehicle service needs. And because it is linked electronically to Toyota's Parts Distribution Centres, the dealership has quick access to any parts it may not have in stock.

Scion Genuine Parts are covered by their own warranty or the remainder of any applicable New Vehicle Warranty (see your dealer for details).

Non-Scion parts, or any damage or failures resulting from their use are not covered by any Scion warranty.

EMERGENCY REPAIRS

Toyota Canada Inc. may, at its sole discretion, reimburse you for repairs effected by non-Scion/Toyota authorized dealerships where there is no dealership reasonably available. Toyota Canada Inc. will reimburse you for any of the repairs that are covered by warranty. To receive reimbursement, present to an authorized Scion/Toyota dealership your paid repair invoices and any parts that were removed from the vehicle. You will be reimbursed for warranted parts at the maximum manufacturer's suggested retail price and warranted labour at a geographically appropriate hourly rate multiplied by Scion's recommended time allowance for the repair.

If your vehicle requires emergency repair, Scion assumes no liability for subsequent failures caused by improper repairs or the use of non-Scion Parts unless you have the vehicle properly repaired in a timely manner. To ensure that warranty coverage remains intact, have your vehicle checked out by an authorized Scion/Toyota dealership as soon as possible after an emergency repair.

Owner Information

BUCKLE UP FOR SAFETY!

In most Canadian and many American jurisdictions the use of seat belts and the use of restraints for smaller children are mandatory and penalties are provided for non-observance of this law. Apart from this, the importance of using seat belts cannot be over-emphasized. Studies show that the safest place in a collision is generally inside your vehicle and seat belts help keep you there.

AIRBAGS DO NOT REPLACE SEAT BELTS:

Airbags are a Supplementary Restraint System (SRS) that inflates in a severe frontal or side collision. Airbags may not inflate in a moderate frontal or side collision nor are they designed to inflate in a rear collision. Therefore, seat belts must be worn at all times.

Never put objects in front of or on top of the airbags because these objects may prevent deployment or cause serious injury. *And never use rear-facing child restraint seats in the front passenger seat because the force and speed of the inflating bag could seriously injure a child.*

PROTECT YOUR CHILD WITH AN APPROVED CHILD RESTRAINT SEAT:

Even though eight out of ten injury accidents occur at speeds under 65 km/h (40 mph), children can be injured during quick turns or sudden stops at speeds below 10 km/h (6 mph). Children who are too small to wear regular seat belts should always be provided with an approved Child Restraint System.

For more information on the operation of seatbelts, airbags and child restraint seats, please see your Owner's Manual.

SERVICE FOR YOUR SCION'S RADIO AND SOUND SYSTEMS

Your Owner's Manual has complete information on radio operation. But as a general rule, radio performance and particularly FM reception may be affected by factors such as natural terrain, man-made obstacles and your distance from the radio station's transmitter.

However, if the problem is not due to any of the factors above and you find your radio does require servicing, your Scion's original equipment radio and sound system components are covered under the terms of the Toyota Canada Inc. Basic New Vehicle Warranty.

Any authorized Scion/Toyota dealer is prepared to minimize your inconvenience by replacing your radio/sound system rather than sending it out for repair by:

- Determining whether your radio can or cannot be repaired at the dealer.
- Ordering a replacement radio if it can't be repaired at the dealer.
- Installing the radio in your vehicle at your convenience once your replacement radio arrives at the dealer (usually within a few days).

Please note that only Scion original equipment audio and Scion/Toyota supplied/Dealer installed audio are covered under the Toyota Canada Inc. Basic New Vehicle Warranty.

WHEN YOU NEED HELP, WE'RE HERE TO HELP YOU

At Scion, service isn't just something we provide, it is a commitment we live by. We are committed to providing the very best product quality and customer care throughout your sales and service experience.

Your dealer's sales and service personnel are empowered to resolve any inquiries or concerns you may have with your sales experience or with the servicing of your Scion. However, despite the best intentions of all concerned, misunderstandings may occur. In these instances we recommend that you take the following steps to help ensure your satisfaction.

1. CONTACT YOUR DEALER

If you have any questions or concerns surrounding your Scion vehicle, your dealer Sales Manager, Service Manager, and Customer Relations Manager are there to help you. In most instances, your dealership's management personnel will be able to work with you to resolve your concern quickly and to your satisfaction.

Everyone at your Scion/Toyota dealership is truly interested in your satisfaction, so please allow your Scion/Toyota dealer the opportunity to demonstrate their commitment to you as a valued member of the Toyota family.

2. CONTACT THE TOYOTA CANADA INC. CUSTOMER INTERACTION CENTRE:

If for any reason you still require assistance or have further questions after discussing your concerns with your dealer management personnel, Scion Canada's Customer Interaction Centre Representatives are available to help you. You may reach them by calling 1-866-9SCION-1 or you may reach them through the Contact Us section of our website: www.scion.ca

Owner Information

To help us provide prompt assistance, please provide the following information when you contact us:

- Vehicle Identification Number (VIN). It's the 17 digit number which you will find when looking through the windshield at the lower corner driver's side. It is also listed on your sales agreement.
- The name of your Scion dealer
- The kilometres on your vehicle

CAMVAP –THIRD PARTY ARBITRATION

Toyota Canada Inc. endeavour's to resolve all customer concerns through our dealer network and with our direct involvement when necessary. Occasionally a customer concern cannot be resolved through Toyota Canada's Customer Interaction Centre. If the first two steps of our commitment have not provided you with a solution that is to your satisfaction, you may wish to contact the Canadian Motor Vehicle Arbitration Plan (CAMVAP). CAMVAP is an independent organization that assists in resolving disputes regarding defects with your vehicle's assembly and/or materials as well as the application and administration of your Scion New Vehicle Warranty.

CAMVAP will advise you about how your complaint can be reviewed and resolved by an independent third party through binding arbitration. There is no charge for using CAMVAP. Results are fast, fair and final as the award is binding on both you and Toyota Canada Inc.

CAMVAP is available across Canada. For more information and to obtain a copy of the CAMVAP consumer guide entitled "Your Guide to CAMVAP", please call CAMVAP directly at 1-800-207-0685 or visit CAMVAP's website at www.camvap.ca.

TOURING/RELOCATING OUTSIDE CANADA, THE UNITED STATES AND U.S. TERRITORIES

If you are touring or relocating outside Canada, the United States or U.S. Territories, and a problem arises, please consult a local Toyota dealer. Please note, however, that warranty service may not be provided by the local dealer because the local Toyota distributor may have no obligation to provide warranty service to your vehicle, and/or your Scion may not comply with the regulatory and/or environmental requirements of such country. In the United States, you may contact:

TOYOTA MOTOR SALES, U.S.A., Inc.
19001 S. Western Avenue,
P.O. Box 2714
Torrance, CA 90509-2714
Tel: 1-800-331-4331

Owner Information

ENVIRONMENTAL POLICY

As a responsible corporate citizen, Toyota Canada Inc. (TCI) is committed to protecting human health, natural resources and the local and global environment, in accordance with Toyota Motor Corporation's Environmental Charter. This dedication reaches further than compliance with the law. It encompasses the integration of sound environmental practices into our business decisions.

THE SCION COMMITMENT:

When you buy a Scion product, you can count on superb quality, durability and reliability, the foundation upon which we have built our reputation. Scion has always been committed to the principle of continuous improvement, such as more fuel efficient engines, enhanced safety features and environmentally friendly products.

You can do your part to help improve the world we all live in by taking note of the following Driving Tips. These tips will help to reduce emissions and improve your fuel economy, so please take a moment to review these simple strategies to help our environment and enhance the quality of life for future generations.

YOU CAN BE AN ECO DRIVER!

Tips from Scion that can save you money and reduce excessive emissions.

1. GET IN THE HABIT OF NOT IDLING THE ENGINE.

When waiting for someone or stopped for an extended period of time, turn off the engine. Instead of running it for 5 minutes, you could save 65 cc of gasoline and reduce CO₂ emissions by 420 grams (assuming 10 times per month).

2. REDUCE THE USE OF YOUR AIR CONDITIONER.

Turning off the air conditioner for 6 minutes could save 70 cc of gasoline and cut CO₂ emissions by 1340 grams (assuming a total of 3 hours per month).

Owner Information

3. CHECK YOUR TIRE PRESSURE REGULARLY.

Driving for 50 km with tires inflated to the proper pressure could save 150 cc of gasoline and cut CO₂ emissions by 1250 grams (assuming a total of 650 km a month) compared to running on underinflated tires by 0.5 kgf/cm² or 3 psi.

4. DRIVE AT AN ECONOMICAL SPEED.

You could boost your fuel economy by 10% to 30% by reducing speeds and not exceeding posted speed limits.

5. REMOVE UNNECESSARY WEIGHT FROM YOUR VEHICLE BEFORE DRIVING.

Taking 10 kg of unnecessary luggage or sports equipment out of your vehicle before driving 50 km could save 15 cc of gasoline and cut emissions by 130 grams (assuming a total of 650 km per month).

6. DON'T RACE THE ENGINE.

By not revving or racing the engine, you could save 6 cc of gasoline and cut emissions by 1150 grams (assuming 300 times per month).

7. AVOID 'JACK-RABBIT' STARTS AND FULL THROTTLE ACCELERATION.

By avoiding 'foot to the floor' starts and accelerating, you could save 17 cc of gasoline and cut CO₂ emissions by 360 grams (assuming a total of 40 times per month).

PLEASE NOTE: The fuel saving and emission reduction figures stated, are for the purpose of example. They are meant to represent what an average vehicle under average conditions may expect to obtain by following the Toyota Eco Driving tips. Your actual results may vary; but any attempt to reduce emissions will result in a cleaner world and we thank you!

Some Scion models are equipped with a technically-advanced Tire Pressure Monitoring System. This is primarily for safety reasons. While this tool keeps you informed about your pressure, it is no substitute for regular tire maintenance.

Scion recommends regular, first-hand visual inspection of your tires, as well as bi-weekly tire pressure checks.

HOW THE TIRE PRESSURE MONITORING SYSTEM WORKS

The System utilizes a sensor that accurately measures both tire pressure and tire air temperature. This sensor is fitted to the inner side of each wheel and transmits data via electric waves to the receiver. The receiver instantly compares the data received against the designated values and if an inconsistency is detected, the warning light symbol illuminates on your dashboard.

WARNING SYMBOL FOR LOW TIRE PRESSURE

If this symbol lights up, it is alerting you that one or more of your tires may be underinflated.

If this warning light keeps blinking on and off (for 60 to 90 seconds), it is indicating a malfunction in the system. After blinking for this time, the warning light may remain on. If the light remains on, contact your Scion/Toyota Dealer immediately for a system inspection.

DOES THE WARNING LIGHT ALWAYS INDICATE THAT TIRE PRESSURE IS LOW?

The warning light may indicate a system malfunction requiring a Scion/Toyota Dealer's attention. If it flashes before staying on continuously, the tire pressure could be within the appropriate range, but you should contact your Scion/Toyota Dealer for a system inspection.

Driving with incorrect tire inflation pressure may result in the following:

- Reduced safety
- Damage to the drivetrain
- Reduced fuel efficiency
- Reduced driving comfort and tire life

If a tire needs frequent filling, have it checked by your Scion/Toyota Dealer.

KEEP YOUR TIRES PROPERLY INFLATED

step 1 Check your tire pressure at least every two weeks - and before going on long trips. Since the temperature outside affects tire pressure, you should check your tires when your vehicle has not been driven more than 1.5 km - or has been parked for at least 3 hours.

step 2 If tire pressure is low, fill your tires to the air pressure recommended on the tire label.

If you have questions about these 2 steps or other tire maintenance inquiries, check your Owner's Manual or consult your Scion/Toyota Dealer.

Owner Information

FREQUENTLY ASKED QUESTIONS

WHY IS PROPER TIRE INFLATION IMPORTANT?

Maintaining the recommended tire pressure is essential for the safe and efficient operation of your Scion. Safety experts estimate that 25% of automobiles are running on tires with lower than recommended pressure. Properly inflated tires run cooler, last longer and improve fuel economy.

WHY DOES TIRE PRESSURE CHANGE?

Many factors affect tire pressure. That's why it is essential to check your tires regularly. Tire pressure can decrease due to tire damage, slow leaks or changes in the outside temperature. For every drop of 5.6°C in temperature, your tires lose 1 psi (pounds per square inch). Tires can also deflate naturally over time, losing as much as 1.5 psi per month.

WHAT DO I NEED TO KNOW WHEN I SERVICE OR REPLACE MY TIRES?

- Because tire repair or replacement may affect the tire pressure sensors, make sure you have your tires serviced by your Scion/Toyota Dealer.
- Make sure that only Scion authorized wheels are used on your vehicle. Tire pressure sensors may not work properly with wheels not supplied by Scion.

HOW DO I FIND THE PROPER PSI FOR MY TIRES?

The correct tire pressure (in psi) can usually be found on a label located in one of three places: the driver's door frame, sill or edge.

DRIVING WITH WINTER TIRES

Take the following precautions to reduce the risk of accidents. Failure to do so may result in a loss of vehicle control and cause an accident.

- Only use tires of the size specified for your vehicle.
- Maintain the recommended level of tire air pressure.

- Do not drive in excess of 120 km/h, regardless of the type of winter tires being used.
- Use winter tires on all four wheels.

WHEEL SELECTION

When you replace your vehicle's wheels, make sure that they are equivalent to those removed in load capacity, diameter, rim width and offset. Replacement wheels are available at your Scion/Toyota Dealer.

CHECKING AND MAINTAINING YOUR TIRE PRESSURE

ONLY CHECK THE TIRES WHEN THEY ARE COLD

If your vehicle has been parked for at least 3 hours and has not been driven for more than 1.5 kilometres, you will get an accurate cold tire inflation pressure reading.

ALWAYS USE A TIRE PRESSURE GAUGE

The appearance of the tire can be misleading. In addition, tire pressures that are even just a few pounds off can degrade ride and handling.

DO NOT BLEED OR REDUCE TIRE INFLATION PRESSURE AFTER DRIVING

It is normal for the tire inflation pressure to be higher after driving.

NEVER EXCEED THE VEHICLE CAPACITY WEIGHT

Passenger and luggage weight should be distributed as evenly as possible so the vehicle is well balanced.

WHEN INSPECTING/ADJUSTING TIRE PRESSURE, REINSTALL THE TIRE VALVE CAPS

Without the valve caps, dirt or moisture can get into the valve and cause air leakage. This can lead to tire failure and compromise your safety. If the caps have been lost, replace them as soon as possible.

Scion Extra Care Mechanical Protection

WE HAVE YOU COVERED! With Extra Care Mechanical Protection, your new Scion has inflation protected coverage on mechanical failures. It's the affordable and cost-effective way to guarantee your peace of mind and to protect your investment whether you buy or lease. In addition, it will enhance and extend your basic Scion Roadside Assistance with **SCION EXTRA CARE ROADSIDE ASSISTANCE** which provides you and your new Scion with additional coverage such as Trip Interruption and Travel Planning Assistance. ECP Plans will also cover you on up to 17 major mechanical component groups after the manufacturer's warranty expires, along with vehicle Rental Assistance and Tire Road Hazard Protection. Please consult your Scion/Toyota dealer for further details on this very valuable and affordable option. At ECP...we really do have YOU covered!

BUT MY SCION ALREADY HAS A FACTORY WARRANTY!

Yes, and it's one of the best! However, ECP is not a warranty ... it's much more. It can provide you and your new Scion with coverage such as:



Mechanical, accident towing and emergency road service



Vehicle rental assistance



Tire road hazard protection



Trip interruption assistance



Travel planning assistance



It will also cover your vehicle with mechanical protection for up to seven years or 200,000 km*



Maintenance benefit program***

COUNT THE WAYS SCION EXTRA CARE MECHANICAL PROTECTION ENHANCES YOUR DRIVING EXPERIENCE:

- ✓ Scion Authorized Parts
- ✓ Factory-trained Scion/Toyota technicians
- ✓ Assured, worry-free motoring
- ✓ Potential higher resale value
- ✓ Protects your budget against unexpected expenses
- ✓ Protects against the rising cost of vehicle repairs
- ✓ No deductible **
- ✓ Maintenance benefit program included (If purchased within 31 days of vehicle sale) ***

* Whichever comes first

** No deductible on New and Lease vehicle programs

*** See your dealer for more details

Required Maintenance

WE SERVICE YOUR SCION THE WAY WE BUILT IT

Your new Scion was designed and built to the highest standards and that quality means reliability, long-life and economical operation for years to come.

The quality of the investment you made in your new Scion can only be maintained by Scion Genuine Parts and Quality Service. And we think you'll find it pays to get the services you need from the people you trust.

All of the maintenance services your vehicle will need under the terms of your new vehicle warranty are outlined on the next few pages. Maintenance of your Scion is required every 6 months or 8,000 km, whichever comes first and includes the services and inspections recommended by Scion.

Additional services, if required due to individual operating conditions, may be recommended by your servicing dealer.

To help take the guesswork out of maintenance, we provide the Scion Maintenance Menu.

Please see your Scion/Toyota dealer for a priced copy of the Menu. It not only helps you budget for maintenance, but also illustrates just how little it will cost over the years to come.

Required Maintenance

WHEN YOU VISIT YOUR DEALER FOR SERVICE THE STAFF WILL:

- Review and get your agreement on which service is needed, what will be done and at what price.
- Record the date and kilometres of each service in this manual so you have it for your records.
- Review your invoice, answer any questions and schedule your next visit.
- Give you a copy of the Maintenance Menu with your next visit highlighted.

YOUR COMPLETE SATISFACTION IS IMPORTANT TO YOUR DEALER, AND THAT MEANS YOU CAN EXPECT EVEN MORE:

- Convenient and well-marked access to the Service Department and nearby parking.
- Clean, bright, pleasant service reception areas.
- Prompt, courteous attention from trained service personnel dedicated to meeting your service needs.
- Clear, simple and accurate explanations with “no-surprise” pricing.
- All work to be done right the first time and on time as promised.
- A convenient variety of payment options.
- A sincere desire to make you a regular customer by providing the services you need at a competitive price.
- Convenient on-line booking of service appointments, at participating dealers.

INTERIOR ELECTRICAL COMPONENT PRECAUTIONS

To avoid damaging electrical components and switches, by using non-approved and commercially available sprays (e.g. lubricants and greases), and non-approved operations (e.g. interior steam-cleaning and non-approved parts disassembly for reconditioning), the above-mentioned are strongly discouraged, as such activities may increase the risk to customer safety and vehicle longevity.

Free Oil & Filter Service

To help you get started with regular maintenance, Scion provides you one free oil change on a complimentary basis.

To obtain a complimentary oil and filter service, call a Scion/Toyota dealership to make an appointment.

COMPLIMENTARY SERVICE INCLUDES:

- Replacing engine oil and filter
- Removing and inspecting air filter element
- Lubricating locks, latches and hinges
- Inspecting lights, horn and wipers for proper function
- Inspecting coolant, brake and washer fluid levels
- Inspecting tires and adjusting pressure as required, including spare

You are responsible for the cost of any other services performed at the time of your complimentary oil & filter service.

Required Maintenance

Service	1	2	1	3	1	2	1	3	1	2	1	3	1	2	1	3	1	2	1	3	1	2	1	3	1	2	1	3
Service interval ('000 km)	8	16	24	32	40	48	56	64	72	80	88	96	104	112	120	128	136	144	152	160	168	176	184	192	200	208	216	224
Service interval (months)	6	12	18	24	30	36	42	48	54	60	66	72	78	84	90	96	102	108	114	120	126	132	138	144	150	156	162	168

All models

Personalized/Customized Settings (One time only)	●																											
Service # 1: (6 months/8,000 km)	●		●		●		●		●		●		●		●		●		●		●		●		●		●	
Service # 2: (12 months/16,000 km) - includes Service # 1		●				●			●				●				●				●				●			
Service # 3: (24 months/32,000 km) - includes Service # 1 and # 2				●				●				●				●				●				●				●
Brake Fluid Replacement : 36 months/48,000 km						●						●						●						●				
Replace Brake Booster Vacuum Pump (iM, only): 150 months/200,000 km																									●			
Replace Super Long Life Coolant: 120 months/160,000 km, then every 60 months/ 80,000 km																				●								
Replace Iridium Spark plugs (expect FR-S): 144 months/192,000 km																								●				

(FR-S Specific)

Replace Fuel Filter: 72 months/96,000 km												●																
Replace Iridium Spark Plugs: 72 months/96,000 km												●																
Replace Automatic Transmission Fluid: 72 months/96,000 km												●																

Required Maintenance

SERVICE # 1 (6 MONTHS/8,000 KM)

- Inspect and adjust all fluid levels
- Reset maintenance reminder light (if applicable)
- Remove wheels and visually inspect brake pads, calipers, rotors, brake lines and hoses *
- Remove & inspect cabin air filter (replace if needed)
- Remove & inspect engine air filter (replace if needed)
- Inspect wiper blades
- Check installation of driver's floor mat
- Check and adjust tire pressures (including spare)
- Check and record tire tread depth
- Record inspection results on inspection form and/or repair order
- Rotate tires (applicable to same size wheels, front & rear) or alternatively perform seasonal tire change-over (tires mounted on rims)
- Road-test vehicle

* Certain driving habits, and some specific climatic and regional operating conditions may necessitate the requirement of a "brake service" (removal, cleaning, deglazing and lubrication of all brake system components & adjustment of parking brake) on your vehicle to protect your brake system components from premature wear and tear and ultimately increase their longevity. If your vehicle requires a brake service, additional charges will apply.

PERSONALIZED/CUSTOMIZED SETTINGS (IF APPLICABLE)

Customize vehicle features in accordance with owner's preferences.

SERVICE # 2 (12 MONTHS/16,000 KM)

(includes Service # 1 + items listed below)

- Replace engine oil and oil filter
- Lubricate locks, latches and hinges
- Inspect lights, horn and wipers for proper function
- Check coolant, brake, transmission and washer fluid levels and fill as required
- Inspect drive belts
- Inspect lights, horn and wipers for proper function

SERVICE # 3 (24 MONTHS/32,000 KM)

(includes Service # 1 + Service # 2 + items listed below)

- Perform battery service & comprehensive electrical charging system evaluation
- Inspect valve clearance audibly
- Adjust belt tension if required
- Check steering gear linkage and shock absorbers for looseness, damage or leakage
- Inspect ball joints & dust covers, driveshafts and steering rack boots, chassis nuts and bolts for looseness or damage
- Inspect exhaust system for leaks, damage or broken hangers
- Inspect fuel system for leaks or damage, inspect condition of fuel tank band, fuel tank cap gasket, fuel tank vapour vent system hoses, fuel lines and connections
- Inspect and measure brake rotors and brake pads
- Examine tires for damage and wear
- Replace smart key battery (if equipped)

SPECIAL OPERATING CONDITIONS

If you primarily operate your vehicle under any of the following conditions, please refer to additional maintenance requirements, shown below:

1. Driving on dirt roads or dusty roads
2. Extensive idling and/or low-speed driving for long distances, such as police, taxi or door-to-door delivery service
3. Towing a trailer, using a camper or car top carrier

ADDITIONAL MAINTENANCE REQUIREMENTS

- Inspect brakes, steering and suspension components every 6 months/8,000 km
- Inspect driveshaft boots and body/chassis bolts, every 6 months/8,000 km
- Change manual transmission oil every 36 months/48,000 km (for condition # 3 above, only)
- Replace automatic transmission fluid every 72 months/96,000 km (for condition # 3 above, only)

Required Maintenance

MAINTENANCE SERVICE RECORD		
8,000 km / 6 months	16,000 km / 12 months	24,000 km / 18 months
Actual mileage:	Actual mileage:	Actual mileage:
Date:	Date:	Date:
Dealership:	Dealership:	Dealership:
Signature:	Signature:	Signature:
32,000 km / 24 months	40,000 km / 30 months	48,000 km / 36 months
Actual mileage:	Actual mileage:	Actual mileage:
Date:	Date:	Date:
Dealership:	Dealership:	Dealership:
Signature:	Signature:	Signature:
56,000 km / 42 months	64,000 km / 48 months	72,000 km / 54 months
Actual mileage:	Actual mileage:	Actual mileage:
Date:	Date:	Date:
Dealership:	Dealership:	Dealership:
Signature:	Signature:	Signature:

Required Maintenance

MAINTENANCE SERVICE RECORD		
80,000 km / 60 months	88,000 km / 66 months	96,000 km / 72 months
Actual mileage:	Actual mileage:	Actual mileage:
Date:	Date:	Date:
Dealership:	Dealership:	Dealership:
Signature:	Signature:	Signature:
104,000 km / 78 months	112,000 km / 84 months	120,000 km / 90 months
Actual mileage:	Actual mileage:	Actual mileage:
Date:	Date:	Date:
Dealership:	Dealership:	Dealership:
Signature:	Signature:	Signature:
128,000 km / 96 months	136,000 km / 102 months	144,000 km / 108 months
Actual mileage:	Actual mileage:	Actual mileage:
Date:	Date:	Date:
Dealership:	Dealership:	Dealership:
Signature:	Signature:	Signature:

Required Maintenance

MAINTENANCE SERVICE RECORD		
152,000 km / 114 months	160,000 km / 120 months	168,000 km / 126 months
Actual mileage:	Actual mileage:	Actual mileage:
Date:	Date:	Date:
Dealership:	Dealership:	Dealership:
Signature:	Signature:	Signature:
176,000 km / 132 months	184,000 km / 138 months	192,000 km / 144 months
Actual mileage:	Actual mileage:	Actual mileage:
Date:	Date:	Date:
Dealership:	Dealership:	Dealership:
Signature:	Signature:	Signature:
200,000 km / 150 months	208,000 km / 156 months	216,000 km / 162 months
Actual mileage:	Actual mileage:	Actual mileage:
Date:	Date:	Date:
Dealership:	Dealership:	Dealership:
Signature:	Signature:	Signature:

Required Maintenance

MAINTENANCE SERVICE RECORD		
224,000 km / 168 months	232,000 km / 174 months	240,000 km / 180 months
Actual mileage:	Actual mileage:	Actual mileage:
Date:	Date:	Date:
Dealership:	Dealership:	Dealership:
Signature:	Signature:	Signature:
248,000 km / 186 months	256,000 km / 192 months	264,000 km / 198 months
Actual mileage:	Actual mileage:	Actual mileage:
Date:	Date:	Date:
Dealership:	Dealership:	Dealership:
Signature:	Signature:	Signature:
272,000 km / 204 months	280,000 km / 210 months	288,000 km / 216 months
Actual mileage:	Actual mileage:	Actual mileage:
Date:	Date:	Date:
Dealership:	Dealership:	Dealership:
Signature:	Signature:	Signature:

Required Maintenance

AN EXPLANATION OF REQUIRED MAINTENANCE

The following explanations are provided to give you a greater awareness and understanding of the individual maintenance services that should be performed to ensure the long life and efficient operation of your Scion.

These services should be recorded in this booklet to document your vehicle's maintenance history. This can also help to increase its resale value. Your dealer's staff is fully prepared to explain any aspect of maintenance for you.

ENGINE OIL AND FILTER:

Replace your engine oil and filter as scheduled. Use an API SN quality level engine oil (or ILSAC GF-5 specification), such as Toyota Genuine Motor Oil. For recommended viscosity, refer to your vehicle's Owner's Manual.

DRIVE BELTS:

Inspect for cracks, excessive wear or looseness. Replace any damaged belts. Check belt tension and adjust as necessary.

CABIN AIR FILTER:

Replace your cabin air filter as needed.

ENGINE COOLANT:

Drain and refill the cooling system using only Toyota Super Long Life Coolant, to provide extended drain intervals. A qualified Scion/Toyota technician should perform this service.

EXHAUST PIPES AND MOUNTINGS:

Visually inspect the exhaust pipes, muffler and hangers for cracks, deterioration or damage. Start the engine and listen carefully for any exhaust leakage. Tighten connections or replace parts as necessary.

ENGINE AIR FILTER:

Inspect air filter element as scheduled, for accumulated dirt or damage. Replace engine air filter as needed.

FUEL LINES AND CONNECTIONS, FUEL TANK VAPOUR VENT SYSTEM HOSES, FUEL TANK BAND AND TANK CAP GASKET:

Visually inspect for corrosion, damage, cracks, loose or leaking connections. Tighten connections or replace parts as necessary.

Required Maintenance

SPARK PLUGS:

Install new plugs of the same type as originally equipped. A qualified Scion/Toyota technician should perform this service.

BRAKE LININGS AND DRUMS, PADS AND DISCS:

Check for scoring, burning, leaking fluid, broken parts, excessive wear or run-out. A qualified Scion/Toyota technician should perform this service.

BRAKE LINES AND HOSES:

Visually check for proper installation. Check for chafing, cracks, deterioration or any leakage. Replace any deteriorated or damaged parts immediately.

A qualified Scion/Toyota technician should perform this service.

STEERING LINKAGE:

With the vehicle stopped, check for excessive free play in steering wheel. Check linkage for bending or damage. Replace any damaged parts.

BALL JOINTS AND DUST COVERS:

Check the suspension, steering and steering linkage ball joints for looseness or damage. Check all dust covers for deterioration or damage. A qualified Scion/Toyota technician should perform this service.

STEERING COMPONENTS:

Inspect for signs of leakage. If any leakage is discovered, have it repaired immediately by a qualified Scion/Toyota technician.

DRIVESHAFT BOOTS:

Check the driveshaft boots and clamps for cracks, deterioration or damage. Check for any damaged parts and, if necessary, repack the grease. A qualified Scion/Toyota technician should perform these services.

AUTOMATIC / MANUAL TRANSMISSION AND TRANSAXLE/ DIFFERENTIAL:

Inspect for signs of leakage. If any leakage is discovered, have it repaired immediately by a qualified Scion/Toyota technician.

NUTS AND BOLTS ON CHASSIS AND BODY:

Retighten the seat mounting bolts and front and rear suspension member retaining bolts to specified torque.

TIRES:

Inspect tires for damage or wear every 6 months/8,000 km, rotate as required. The appropriate interval depends on factors such as vehicle design, winter tire usage, driving habits and road conditions.

Owner's Responsibilities

SOME TIPS ON HOW TO HANDLE YOUR RESPONSIBILITIES AS AN OWNER

LOOK AFTER YOUR SCION'S SCHEDULED REGULAR MAINTENANCE:

Your Scion has been designed to require as little maintenance as possible. That means each regularly scheduled maintenance visit is now more important than ever!

As the owner, it's your responsibility to properly operate, care for and maintain your Scion in accordance with specified instructions and to keep maintenance records. In some instances, it may be necessary for you to show that the required maintenance has been performed.

LOOKING AFTER YOUR OWN MAINTENANCE CAN SAVE YOU TIME AND MONEY:

There are some simple maintenance items you can look after if you have the tools and ability. However, some items are best left to the specialists at your Scion/Toyota dealer where they have the tools and skilled staff. Please check your Owner's Manual for items which are considered "do-it-yourself".

A CHECK LIST TO HELP YOU LOOK AFTER YOUR SCION'S DAILY CARE:

This list below will help you know what to check on a regular basis to keep your Scion in tip-top condition.

EXTERIOR

- ✓ Rotation & Condition of Tires
- ✓ Tire Inflation
- ✓ Wheel Nuts
- ✓ Wiper Blades
- ✓ Fluid Leaks
- ✓ Locks & Latches
- ✓ Lights & Signals

INTERIOR

- ✓ Horn/Warning Buzzers
- ✓ Wiper/Washer
- ✓ Defroster
- ✓ Seat Belt System
- ✓ Seat Components
- ✓ Mirrors
- ✓ Visors

UNDER HOOD

- ✓ Automatic Transmission Fluid (w/dipstick)
- ✓ Engine Oil
- ✓ Clutch/Brake Fluid
- ✓ Windshield Washer Fluid
- ✓ Engine Coolant
- ✓ Battery Condition

GENERAL

- ✓ Overall Vehicle Finish and Appearance
- ✓ Steering/Handling
- ✓ Radiator Hoses
- ✓ Drive Belts
- ✓ Exhaust System Condition
- ✓ Brake Operation

Owner's Responsibilities

SOME WARNING SIGNS THAT MAY INDICATE SERVICE IS NEEDED:

You should always be on the alert for these warning signs. There are visual and audible indicators that service may be needed.

- ✓ Engine ping or stumble
- ✓ Engine loss of power or unusual sounds
- ✓ Oil or fluid leaks
- ✓ Underinflated tires
- ✓ Vehicle pulls to one side on level pavement
- ✓ Noisy or ineffective brakes
- ✓ Abnormal fuel consumption
- ✓ Abnormal temperature indication

PROTECTING AGAINST CORROSION:

In order to help protect your vehicle against corrosion, it's very important that you wash your vehicle regularly, following these suggestions:

- Use cold clean water and a mild vehicle soap.
- Wash your vehicle in the shade.
- If insects, tar or similar deposits have accumulated on your vehicle, wash it as soon as possible.
- If you drive on salted or dust controlled roads or near the ocean, hose off the undercarriage at least once a month.
- Ensure the drain holes in the lower edges of the doors and rocker panels are clear.

TAKE SPECIAL MEASURES IF ANY OF THE FOLLOWING OCCUR:

- If you detect any stone chips or scratches in the paint, touch them up immediately.
- If your Scion is damaged due to an accident or any other cause which destroys the paint and protective coating, have your vehicle repaired as soon as possible. (The cost of these repairs is the responsibility of the owner.)
- If you carry special cargo such as chemicals, fertilizers, de-icer salt, etc., ensure that materials are well packaged and sealed.
- If you drive on gravel roads, consider installing mud or stone shields behind each wheel.

Scion Roadside Assistance

As the proud owner of your Scion, you won't have to worry about where you can obtain assistance when mishaps requiring Emergency Road Service or Mechanical Breakdown Towing occur. Throughout North America, our Roadside Assistance Representatives will always be there to ensure you receive prompt, efficient service from one of our approved service providers, 24 hours a day, 365 days a year. These services are available to you for a period of 36 months/unlimited kilometres (whichever comes first), and are transferable with the resale of the vehicle with the remaining original Toyota basic warranty.

MECHANICAL BREAKDOWN TOWING (REIMBURSEMENT OPTION: UP TO \$250)

Should your Scion experience a mechanical breakdown and be unable to proceed under its own power, Scion Roadside Assistance will arrange for a towing facility to tow your vehicle from the place of mechanical breakdown to the nearest Scion/Toyota dealership within 300 kilometres, or to your preferred Scion/Toyota dealership within 50 kilometres. An alternative service facility may be used if there is no Scion/Toyota Dealership within 300 kilometres.

ACCIDENT TOWING (REIMBURSEMENT OPTION: UP TO \$250)

A traffic accident can be a very frightening and unpleasant experience. Scion Roadside Assistance will be there to help. An accident is defined as the upset or collision of your Scion with any object moving or stationary.

Scion Roadside Assistance will arrange for a towing facility to tow your vehicle from the scene of the traffic accident to the nearest Scion/Toyota dealership within 300 kilometres, or to your preferred Scion/Toyota dealership within 50 kilometres. An alternative service facility may be used if there is no Scion/Toyota Dealership within 300 kilometres.

In the event that your municipality requires you to report to an Accident Reporting Centre, a second tow will be provided from the Accident Reporting Centre to the nearest Scion/Toyota dealer or alternative service facility (as specified above). The second tow from the Accident Reporting Centre must be arranged by calling Scion Roadside Assistance at 1-866-9SCION-1 upon completion of the accident report.

REIMBURSEMENT OPTION: In the event that alternative towing arrangements are made, Scion Roadside Assistance will consider you for reimbursement to a maximum of \$250, provided that your Scion was towed to a Scion/Toyota dealer, and that the following documents have been submitted:

- Original copy of the towing receipt
- Copy of the police report
- Letter from your insurance company stating what portion of the expenses have been covered
- Copy of the Scion/Toyota dealer repair invoice (proof of destination)

Scion Roadside Assistance

EMERGENCY ROAD SERVICE

(REIMBURSEMENT OPTION: UP TO \$100)

Scion Roadside Assistance will provide the following emergency roadside services for the duration of the basic warranty:

BATTERY BOOST: In the event that your Scion fails to start after the boost, it will be towed according to your Mechanical Breakdown towing benefits stated above.

LOCKOUT SERVICE: If you have locked your keys in your vehicle, Scion Roadside Assistance will dispatch a service facility to attempt to gain entry into your vehicle. (Cost of labour and/or replacement keys not included.) In the event that access cannot be gained, your vehicle will be towed according to your Mechanical Breakdown towing benefits stated above.

FUEL DELIVERY: In the event that you run out of fuel, Scion Roadside Assistance will deliver gasoline to your stranded vehicle. (Cost of gasoline included up to 5 litres.)

TIRE CHANGE: If you have a flat tire, your usable spare will be installed. (Tire repairs are not covered.)

WINCHING: If your vehicle becomes immobilized in a ditch, mud or snow, Scion Roadside Assistance will arrange to have your vehicle winched on to the nearest roadway. The vehicle must be accessible and located on, or adjacent to, a regularly traveled roadway. (This benefit does not apply to vehicles immobilized in a snow-covered driveway or parking lot.) In the event that your Scion is unable to proceed under its own power after winching, it will be towed according to your Accident towing benefits stated above.

HOW TO OBTAIN SERVICE

1. Should you require any of our Emergency Road Service simply call 1-866-9SCION-1.
2. Provide the Scion Roadside Assistance Representative with your name, vehicle identification number (VIN), the nature of your difficulty and the exact location of your vehicle.
3. An authorized service facility will be dispatched to provide you with the necessary Roadside Assistance.

In order to obtain service you must remain with your vehicle. The approved service facility will not provide service to unattended vehicles.

Scion Roadside Assistance

HOW TO CLAIM FOR ALTERNATE SERVICE ARRANGEMENTS

1. Scion Roadside Assistance should be contacted prior to making any alternate service arrangements to ensure reimbursement for the services rendered.
2. In the unlikely event that an authorized service facility is not available in the area of your breakdown, the Scion Roadside Assistance Representative will authorize you to obtain service from an alternate facility.
3. Obtain from the service facility a detailed receipt outlining the cause of disablement, the service required and distance towed, if applicable.
4. Submit the original receipts within thirty (30) days of the date of the incident. The original detailed repair invoice must accompany towing claims. Please submit claims for consideration to:

SCION ROADSIDE ASSISTANCE
P.O. BOX 5845
LONDON, ONTARIO N6A 4T4

5. Upon receipt and confirmation of the information, Scion Roadside Assistance will send you a reimbursement cheque according to your reimbursement limits. Scion Roadside Assistance reserves the right to decline any claim presented for payment later than thirty (30) days after

the date the service was performed or any claim not satisfying the requirements of this coverage.

GENERAL CONDITIONS

Scion Roadside Assistance agrees to provide to the driver of the registered Scion, the benefits as listed in this warranty, maintenance and roadside assistance guide, subject to the terms and conditions as set out in this publication.

The records of Scion Roadside Assistance determine the commencement and termination dates of your coverage and will be evidence of your eligibility to claim for benefits.

The benefits of the Scion Roadside Assistance Program are transferred when the vehicle ownership is transferred.

Any fraudulent alteration made to bills for service will render them invalid for claims reimbursement.

Only originals of receipts and/or charge copies submitted by you will be accepted for consideration for reimbursement. Originals will be returned upon request.

Scion Roadside Assistance

Benefits as described in this warranty, maintenance and roadside assistance guide will not be provided:

- A. Where there is any indication at the time of incident of the driver's consumption of alcoholic beverages or narcotics or where the driver was not in possession of a valid license to operate the vehicle, or when the driver's license is under suspension.
- B. While your Scion is not insured as required by law.
- C. In the event that the incident occurred while the driver was committing a criminal offense.

Services will not be covered if your Scion was driven into an area that is inaccessible to the service vehicle or is not on a regularly travelled roadway.

Cross-country, logging, autocross and any other form of off-road use is not covered.

The services contracted for, shall not cover emergency claims caused directly or indirectly, wholly or partly by war, riot, floods, invasion, insurrection, civil commotion or while your Scion is being used in military or police services.

All service providers are independent contractors and are not employees or agents of Toyota Canada. Any loss or damage to your Scion or personal property, resulting from the roadside service, is the responsibility of the roadside provider. Report any damage or loss to the manager of the service provider and to your own insurance company within 24 hours.

Toyota Canada reserves the right to discontinue providing roadside service to you, if in Toyota Canada's opinion there is abuse of roadside services.

All questions concerning Towing and Emergency Road Service should be directed to:

SCION ROADSIDE ASSISTANCE

**248 PALL MALL STREET,
P.O. BOX 5845,
LONDON ON N6A 4T4
1-866-9SCION-1**

EXTENDED COVERAGE

Extend your Roadside Assistance beyond the Basic Warranty Period.

Available for a small annual fee, you can continue your Roadside assistance beyond the 3 year 60,000 km Basic New Vehicle Warranty period. Coverage includes:

- Mechanical Breakdown Towing
- Battery Boost
- Lockout Service
- Fuel Delivery
- Tire Change
- Winching
+PLUS
- Trip Interruption
- Travel Planning

All the benefits of an Auto Club membership at a price that may surprise you.

For more information visit your Scion/Toyota Dealer and inquire about the benefits of Roadside Assistance.

SCION CERTIFIED COLLISION CENTRES

Unfortunately, accidents do happen and it's important to know what to do before you find yourself in this stressful situation.

Take a few minutes to review the "Accident and Repair Brochure" in your glove compartment and visit **www.scion.ca** for a list of Scion/Toyota certified collision centres.

Did you know?

- You do not have to accept a tow from the truck on the scene, Scion Roadside assistance has you covered.
- You have the right to have your vehicle repaired to its pre-accident condition, using Scion Genuine Parts at a Scion Certified Collision Centre.

Nobody knows your Scion better than a Scion Certified Collision Centre.

Seatbelts and SRS Airbags

BUCKLE UP FOR SAFETY!

In most Canadian and many American jurisdictions the use of seat belts and the use of restraints for smaller children are mandatory and penalties are provided for non-observance of this law. Apart from this, the importance of using seat belts cannot be over-emphasized. Studies show that the safest place in a collision is generally inside your vehicle and seat belts help keep you there.

HOW TO WEAR THE SEATBELTS CORRECTLY

All passengers should correctly fasten their seatbelts before the vehicle starts moving and should not unfasten them while in the vehicle.

Observe the following precautions. Failure to do so may cause serious injury or death.

- Passengers in rear seats who do not use their seatbelts may put not only themselves at risk, but those in front of them as well.



SIT WITH CORRECT POSTURE

- Sit upright with your back against the seatback.
- Adjust the position of the seatback. Sit up straight and well back in the seat.
- Avoid reclining the seatback any more than needed. In the event of an accident, if you are reclined, the lap belt may slide past your hips and apply restraint forces directly to your abdomen, or your neck may contact the shoulder belt, which could result in serious or life-threatening injuries.



CORRECTLY FASTEN THE SEATBELT

For instructions on how to adjust the seatbelts, please refer to the Owner's Manual for your vehicle.

- Extend the shoulder belt so that it comes fully over the shoulder, but does not come into contact with the neck or slide off the shoulder.
- Be sure to position the lap belt low over the pelvis below the abdomen.
- Do not twist the seatbelt.
- To fasten the seatbelt, push the plate into the buckle until a click sound is heard.
- While driving, do not adjust the position of the seat or unbuckle the seatbelt.



- The seatbelts provided for your vehicle are designed for people of adult size. In the case of a child who cannot properly wear the seatbelts, please refer to "Safety Information" in your Owner's Manual.

AIRBAGS DO NOT REPLACE SEAT BELTS:

Airbags are a Supplementary Restraint System (SRS) that inflates in a severe frontal or side collision. Airbags may not inflate in a moderate frontal or side collision nor are they designed to inflate in a rear collision. Therefore, seat belts must be worn at all times.

Never put objects in front of or on top of the airbags because these objects may prevent deployment or cause serious injury. *And never use rear-facing child restraint seats in the front passenger seat because the force and speed of the inflating bag could seriously injure a child.*

Child Safety / Pet Safety

CHILD SAFETY


THINK ABOUT CHILDREN'S SAFETY

Please be extremely careful when driving with young children.

Observe the following precautions. Failure to do so may cause serious injury or death.

DO NOT ALLOW CHILDREN TO PLAY WITH PARTS THAT OPEN AND CLOSE

- Do not allow children to play with a door, window or moon roof that leads to the outside because there is a danger that children may injure themselves or other accidents may occur.



WHEN DRIVING WITH CHILDREN

- Children should be seated in the rear seats, and not in the front passenger seat.
- An adult passenger should take a seat as close as possible to the child and pay attention to safety.
- To provide proper restraint, use a child restraint system following the manufacturer's instructions about the appropriate age and size of the child for the child restraint system. Install the child restraint system correctly, following the instructions provided by its manufacturer before placing the child in it.

PROTECT YOUR CHILD WITH AN APPROVED CHILD RESTRAINT SEAT:

Even though eight out of ten injury accidents occur at speeds under 65 km/h (40 mph), children can be injured during quick turns or sudden stops at speeds below 10 km/h (6 mph). Children who are too small to wear regular seat belts should always be provided with an approved Child Restraint System.

CHILD OR PET SAFETY

NEVER LEAVE CHILDREN OR PETS UNATTENDED IN A VEHICLE

- The interior temperature of a vehicle parked in sunlight can become extremely high, and an unattended child or pet can suffer heatstroke and dehydration, which can be fatal. Hypothermia is also a danger in cold weather. Do not leave a child or pet unattended in a vehicle. Also, the child could be involved in an unexpected accident by playing with the vehicle controls and equipment.
- Do not leave cigarette lighters, matches or other flammable objects inside the vehicle, because an unexpected accident or fire could result.



Cautions when Driving and Stopping

IF THE ACCELERATOR PEDAL IS CAUGHT UNDER THE FLOOR MAT AND IT IS DIFFICULT TO DISENGAGE

- Step 1** Steadily step on the brake pedal firmly with both feet and firmly depress it.
- Step 2** Shift the shift lever to N.
- Step 3** After slowing down, stop the vehicle in a safe place.
- Step 4** Stop the engine (or hybrid system).
- Step 5** Remove the floor mat once in a safe place.

(IF THE SHIFT LEVER CANNOT BE SHIFTED TO N)

- Step 1** Keep depressing the brake pedal with both feet to reduce vehicle speed as much as possible.
- Step 2a** Vehicles with a smart key system:
Stop the engine (or hybrid system) by pressing and holding the "ENGINE START STOP" (or "POWER") switch for 3 consecutive seconds or more.
- Step 2b** Vehicles without a Smart Key system:
Stop the engine by turning the engine switch to the "ACC" position.
- Step 3** Stop the vehicle in a safe place.
- Step 4** Remove the floor mat once in a safe place.

Cautions when Driving and Stopping

IF THE VEHICLE IS SUBMERGED, CALMLY GET OUT OF THE VEHICLE


- Unbuckle your seatbelt.
- If the volume of water does not prevent you from opening the door, open the door and immediately get out of the vehicle.
- If you cannot open the door, open the window and climb out the window. If you cannot open the window, break the glass, except the windshield, and climb out of the vehicle. At this time, be careful of the broken-out section of glass.
- If you cannot break the window, wait until the vehicle is flooded to the level that there is no difference in water pressure between the inside and outside of the vehicle, and immediately open the door and get out.

For more information on the operation of seatbelts, airbags and child restraint seats, please see your Owner's Manual.



Floor Mat Installation

Your vehicle may have been equipped with two sets of floor mats upon delivery which include the genuine Scion Carpet Floor Mats and genuine Scion accessory All-Weather Floor Mats that have been designed specifically for your model vehicle. You may also have purchased floor mats for your vehicle.




CAUTION

Please observe the following precautions when inserting the floor mat. Failure to do so may result in the floor mat slipping and interfering with the movement of the pedals during driving, resulting in an accident.

- Never install two floor mats on top of each other in the drivers seat position. Install only one floor mat in the driver's position, either the original Carpet Floor Mat or a floor mat, such as the genuine Scion accessory All-Weather Floor Mat that matches the size of the space on the carpet.
- Ensure the Drivers side mat is properly positioned, with the correct side facing upward and that it is secured to the retention hooks provided.

DRIVER'S FLOOR MAT CHECK ✓

- ✓ **PROPER MAT?**
install only the floor mat specified
- ✓ **ONLY ONE?**
never place one mat on top of another
- ✓ **SECURED PROPERLY?**
use only retention hooks and secure it



Use only the genuine retention hooks specified. Retention Hooks may vary in design.

For further information concerning floor mats, please refer to your Owner's Manual.




CUSTOMER INFORMATION CHANGE CARD

FOR UPDATED INFORMATION ABOUT YOUR VEHICLE!

1. Fill out card and return
2. Go online to toyota.ca/changeinfo
3. Call 1-866-9SCION-1 | 1-866-972-4661

Your Vehicle Identification Number can be found on your Vehicle Registration Certificate in this supplement or on the plate attached to the driver's side top of dashboard.

Toyota will treat the information you provide as confidential.



what moves you



1000068756-L3R0S5-BR01



SCION
PO BOX 4459 STN INDUSTRIAL PARK
MARKHAM ON L3R 9Z9

moisten and seal



Toyota Canada Inc.
Toyota Credit Canada Inc.
Toyota Financial Services

TOYOTA CANADA INC.
One Toyota Place, Toronto, Ontario M1H 1H9 | scion.ca

[illegible]

PRIMARY CUSTOMER

[illegible][illegible]

☐ **YES**, please add me to your electronic mailing lists so that I may receive [information related to product offerings, warranty coverage and advertising or marketing campaigns]. You may withdraw your consent to receive commercial electronic messages from us at any time.

e-mail Address

ADDRESS[illegible][illegible]

Province	

Postal Code						
			-			

Home Telephone									
			-				-		

Business Telephone									
			-				-		

Ext.			

Cell									
			-			-			

Fold, seal and mail today! ●

moisten and seal



Toyota Canada Inc.
Toyota Credit Canada Inc.
Toyota Financial Services

TOYOTA CANADA INC.
One Toyota Place, Toronto, Ontario M1H 1H9 | scion.ca

ALTERNATE CUSTOMER (If applicable)[illegible][illegible]

☐ **YES**, please add me to your electronic mailing lists so that I may receive [information related to product offerings, warranty coverage and advertising or marketing campaigns]. You may withdraw your consent to receive commercial electronic messages from us at any time.

e-mail Address

ADDRESS[illegible][illegible]

Province	

Postal Code						
			-			

Home Telephone									
			-				-		

Business Telephone									
			-				-		

Ext.			

Cell									
			-				-		

LANGUAGE PREFERRED:

☐ English/Anglais☐ **French/Francais**

moisten and seal

ROADSIDE ASSISTANCE

To Receive Roadside Assistance, Call

1-866-9SCION-1

(1 866 972 4661)

For 36 Months or 60,000 kilometres*



BENEFITS

Mechanical Breakdown Towing

(To your preferred Scion/Toyota dealership within 50 km or to the nearest Scion/Toyota dealership within 300 km.)

Accident Towing

(To your preferred Scion/Toyota dealership within 50 km or to the nearest Scion/Toyota dealership within 300 km. A second tow will be provided, if necessary to the accident-reporting centre.)

Emergency Road Service

- Boost a dead battery
- Provide key lockout service
- Deliver gasoline if stranded
- Change a flat tire
- Winching from a ditch

*Whichever comes first.

Note: See the Scion Roadside Assistance section in the Warranty, Maintenance and Roadside Assistance Guide for complete details of the Scion Roadside Assistance Benefits.



what moves you

ROADSIDE ASSISTANCE

1 866 9SCION-1

(1 866 972 4661)



Mechanical Breakdown Towing • Accident Towing
Boost a dead battery • Provide key lockout service
Deliver gasoline if stranded • Change a flat tire
• Winching from a ditch

ROADSIDE ASSISTANCE

1 866 9SCION-1

(1 866 972 4661)



Mechanical Breakdown Towing • Accident Towing
Boost a dead battery • Provide key lockout service
Deliver gasoline if stranded • Change a flat tire
• Winching from a ditch

Keep your Scion Roadside Assistance Card with you at all times. We have provided 2 cards for your convenience

- Vehicle Identification Number (VIN)
- Odometer reading
- Location of your vehicle (address or intersection).
- Service required

[illegible]

When calling Scion Roadside Assistance you should have the following information ready:

- Vehicle Identification Number (VIN)
- Odometer reading
- Location of your vehicle (address or intersection).
- Service required

[illegible]

**24 hour Nationwide assistance including
Canada and continental United States of America**

Keep your Scion Roadside Assistance Card with you at all times. We have provided 2 cards for your convenience

IN CASE OF AN ACCIDENT



- Stay calm—make sure no one is injured—if there are injuries, call for assistance immediately.
- Report the accident to the police—a police report will assist in filing an accident claim with your insurance company.
- Exchange key information (name/address/phone/insurance/etc.) with all parties (including witnesses).
- Insist that your vehicle be taken to the nearest Scion/Toyota dealership or Certified Collision Repair and Refinish Centre.
- Contact your insurance company as soon as possible after the accident.

When calling Scion Roadside Assistance you should have the following information ready:

- Vehicle Identification Number (VIN)
- Odometer reading
- Location of your vehicle (address or intersection)
- Service required

1-866-9SCION-1
[1 866 972 4661]



what moves you