

apuro

**Sous Vide
Water Bath**

Instruction manual



**Model
DM869-A**

Safety Tips

- Position on a flat, stable surface.
- A service agent/qualified technician should carry out installation and any repairs if required. Do not remove any components on this product.
- Consult Local and National Standards to comply with the following:
 - Health and Safety at Work Legislation
 - Fire Precautions
 - Wiring Regulations
 - Building Regulations
- DO NOT immerse the appliance in water above the **MAX** Fill line, or use jet/pressure washers to clean the appliance.
- Do not immerse the appliance below the **MIN** Fill line.
- Do not use the appliance for anything other than its intended use.
- Always switch off and disconnect the power supply to the appliance when not in use.
- Not suitable for outdoor use.
- Keep all packaging away from children. Dispose of the packaging in accordance to the regulations of local authorities.
- If the power cord is damaged, it must be replaced by an Apuro agent or a recommended qualified technician in order to avoid a hazard.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- DO NOT use if damaged.
- **DO NOT touch the outer surfaces of the appliance. They become hot during use.**



- Apuro recommend that this appliance should be periodically tested (at least annually) by a Competent Person. Testing should include, but not be limited to: Visual Inspection, Polarity Test, Earth Continuity, Insulation Continuity and Functional Testing.

Introduction

Please take a few moments to carefully read through this manual. Correct maintenance and operation of this machine will provide the best possible performance from your APURO product.

Pack Contents

The following is included:


- APURO Sous Vide Water Bath
- Instruction Manual
- Rack
- Base Plate

APURO prides itself on quality and service, ensuring that at the time of packaging the contents are supplied fully functional and free of damage.

Should you find any damage as a result of transit, please contact your APURO dealer immediately.

Function

LCD Display



Water Heating: When displayed water is being heated

Water Circulating: When displayed water is being stirred

Temperature: Displays actual temperature of water

Set Temperature: Temperature set point


Set Time: In setting mode display shows the time set point. In working mode display shows the time left.

Operation

1. Add water to the water bath.









Note: the water level (after the food is put in) should be higher than the MIN but lower than the MAX markings on the machine.

2. Turn on by pressing the On/Off button at the back of the machine.
3. Press the Temperature Display button  to set the unit to display °C or °F.



Note: Default setting is °C. After choosing °C or °F, the appliance will remember your setting for future use.

4. Press  **TIME**  and  **TEMP**  to set working time and temperature.
5. After setting time and temperature, press  to start the unit heating. Pressing  will stop the unit heating.




Note: The appliance is designed to hold temperature with lid on. It will not hold temperature without lid.

6. When the water reaches the desired temperature place the food to be cooked into the water bath.



Note: before Sous Vide cooking, the food should be vacuum packed first.

7. When set time has expired the Sous Vide will beep. Press  to stop the appliance heating.



Note: the appliance will go on beeping every 20 seconds. If there is no action by the operator the water temperature will be held at the pre-set temperature.


Cleaning, Care & Maintenance

- Switch off and disconnect from the power supply before cleaning.
- Allow to cool before wiping exterior surfaces and removing any loose debris.
- Empty the main body before cleaning.
- Remove the lid, rack and base plate. Clean the parts with warm soapy water.

Maintenance

- Ensure to locate the unit on a flat surface after cleaning.
- During cleaning, do not damage the interior components. Should any damage occur, call BUFFALO agent or qualified technician. Do not attempt any unauthorized repairs to avoid accidents.
- Always use fresh water. If the water is reused many times, mineral substances may adhere to the surface of the components, thus influence the appliance's performance.

De-scaling

Why...	Normally tap-water contains minerals. When water is heated to a certain temperature, there will be scales accumulated on the heater or surface of the appliance, which will affect its performance and contaminate the outlook as well.
When...	We suggest cleaning the machine after every 20 times of use, or when accumulated working time amounts to 100 hours or less. Or you can clean your appliance at different intervals as water quality varies in different places.
Preparation	Food grade vinegar (e.g. white vinegar)
How...	<ol style="list-style-type: none"> 1. Add water into the water bath up to the MAX marking. Then add 5g vinegar. CAUTION: Should any vinegar splash onto your eyes, rinse immediately with fresh water and turn to a doctor if needed! 2. Turn on the machine and set the working temperature to 80°C and working time to 3 hours (03:00). Now press  to start cleaning. After 3 hours, the machine will beep then turn off automatically. 3. Dispose of the solution of water and vinegar properly. Do not use the same solution for a second time. If the results are not satisfactory, repeat the above operations. 4. Clean the unit with fresh water thoroughly, then dry and store in a well-ventilated place. <p>Note: Make sure to clean the water filters (located on the inner wall) well. The filters can be screwed off for thorough cleaning.</p>



IMPORTANT: Failure to descale or maintain will invalidate your guarantee.

Troubleshooting

Fault	Probable Cause	Solution
Appliance does not heat	No power	Make sure the appliance is plugged in correctly
	Power switch is set to OFF	Set the power switch to ON
No power	Auto re-set activated	This product is fitted with a thermal protector. Allow unit to cool for 30-45 minutes
Slow to Heat	Unit needs descaling	Descalate the appliance

Fault	Probable Cause	Solution
Error code E01 is displayed	Water level is too low	Add water, making sure the water level is between the MIN and MAX line
Error code E02 is displayed	Set temperature cannot be reached	Ensure the lid is in place, water filters are not stuck, and fresh cool water is used. If the error code still persists, call Buffalo agent or qualified technician
LCD Display does not switch on	Power switch is set to OFF	Set the power switch to ON

Technical Specifications

Model	Voltage	Power	Current	Dimensions (h x w x d mm)	Weight
DM869-A	230V 50Hz	620W	2.8A	280 x 415 x 260	7.5kg

Electrical Wiring

The plug is to be connected to a suitable mains socket. This appliance is wired as follows:

- Live wire (coloured brown) to terminal marked L
- Neutral wire (coloured blue) to terminal marked N
- Earth wire (coloured green/yellow) to terminal marked E

This appliance must be earthed, using a dedicated earthing circuit.



If in doubt consult a qualified electrician.

Electrical isolation points must be kept clear of any obstructions. In the event of any emergency disconnection being required they must be readily accessible.

Compliance

The product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority responsible for waste disposal in your area.

APURO parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorities.

APURO products have been approved to carry the following symbol:



All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of APURO.
Every effort is made to ensure all details are correct at the time of going to press, however, APURO reserve the right to change specifications without notice.

DECLARATION OF CONFORMITY

• Conformiteitsverklaring • Déclaration de conformité • Konformitätserklärung • Dichiarazione di conformità •
• Declaración de conformidad • Declaração de conformidade

Equipment Type • Uitrustingstype • Type d'équipement • Gerätetyp • Tipo di apparecchiatura • Tipo de equipo • Tipo de equipamento		Model • Modèle • Modell • Modello • Modelo • Malli
Sous Vide Water Bath - 12.5Ltr		DM869-A
Application of Territory Legislation & Council Directives(s) Toepassing van Europese Richtlijn(en) • Application de la/des directive(s) du Conseil • Anwendbare EU-Richtlinie(n) • Applicazione delle Direttive • Aplicación de la(s) directiva(s) del consejo • Aplicação de directiva(s) do Conselho	Electrical safety IEC 60335-1:2010 +A1:2013 +A2:2017 IEC 60335-2-15: 2012 +A1:2016 EN 62233:2008 Electro-Magnetic Compatibility EN 55014-1:2017 EN 55014-2:2015 EN 61000-3-2: 2014 EN 61000-3-3: 2013	
Producer Name • Naam fabrikant • Nom du producteur • Name des Herstellers • Nome del produttore • Nombre del fabricante • Nome do fabricante		Apuro

I, the undersigned, hereby declare that the equipment specified above conforms to the above Territory Legislation, Directive(s) and Standard(s).

Ik, de ondergetekende, verklaar hierbij dat de hierboven gespecificeerde uitrusting goedgekeurd is volgens de bovenstaande Richtlijn(en) en Standaard(en).

Je soussigné, confirme la conformité de l'équipement cité dans la présente à la / aux Directive(s) et Norme(s) ci-dessus

Ich, der/die Unterzeichnende, erkläre hiermit, dass das oben angegebene Gerät der/den oben angeführten Richtlinie(n) und Norm(en) entspricht.

Il sottoscritto dichiara che l'apparecchiatura di sopra specificata è conforme alle Direttive e agli Standard sopra riportati.

El abajo firmante declara por la presente que el equipo arriba especificado está en conformidad con la(s) directiva(s) y estándar(es) arriba mencionadas.

Eu, o abaixo-assinado, declaro que o equipamento anteriormente especificado está em conformidade com a(s) anterior(es) Directiva(s) e Norma(s)

Date • Data • Date • Datum • Data •
Fecha • Data

Signature • Handtekening • Signature
• Unterschrift Firma • Firma •
Assinatura

Full Name • Volledige naam • Nom et
prénom • Vollständiger Name • Nome
completo • Nombre completo • Nome
por extenso

Position • Functie • Fonction • Position
• Qualifica • Posición • Função

Producer Address • Adres fabrikant •
Adresse du producteur • Anschrift des
Herstellers • Indirizzo del produttore •
Dirección del fabricante • Morada do
fabricante

5th February 2021

DocuSigned by:

Ashley Hooper

B39382C9FD9C478...

DocuSigned by:

Josie Holt

3582E210C4054DA...

Ashley Hooper

Josie Holt

Technical & Quality Manager

**Commercial Manager/ Responsible
Supplier**

**Fourth Way,
Avonmouth,
Bristol,
BS11 8TB
United Kingdom**

**15 Bagdally Road,
Campbelltown
NSW 2560**





DM869-A_A5_v3_20210223