

Product Specification Sheet

WNC-WT-JACK Transmitter with 1/4" Jack



Architects' and Engineers' Specifications

The transmitter shall be WNC-WT-JACK with 900 MHz spread spectrum technology for proven frequency-hopping transmissions for greater reliability. It shall be equipped with 1/4" phono jack for connectivity to any device providing normally open contact closure. Transmitter shall be fully supervised for battery voltage as well as operation.

Features

- Reliable 900 MHz spread frequency transmission
- Right angle 1/4" phono jack for connectivity
- Typical battery life is 48 months
- Mounting bracket for easy installation
- Fully supervised for battery voltage and operation

WNC-WT-JACK Transmitter with 1/4" Jack

The WNC-WT-JACK is a fully supervised 900 MHz spread spectrum transmitter with a right angle 1/4" phono jack on a 12" lead for connection to any device that provides contact closure. The transmitter can be programmed to alarm on normally open or normally closed contacts. Typical devices to be connected include but are not limited to: IV pump and ventilator alarms, bed and wheelchair exit pads and fall monitors. When the device signals an alarm condition, the WNC-WT-JACK transmitter wirelessly sends the alarm to the console where the alarm information is annunciated. Depending on console and outputs selected, the alarm information may be additionally sent to pocket pagers and other notification devices. A mounting kit is provided for quick and easy installation.

Specification

Housing: Height: 0.9"

Width: 1.7" Depth: 3.5"

• Weight: 1.7 oz. without battery

• Power: 3.0V lithium battery CR123A

• Connector: 1/4" phone right angle jack w/12" lead

System Components

Model No.	Description
Server	Video Display Console
MV400	400 Console Master
MV200	200 Console Master



Address: 5225 Sheridan Drive, Georgetown Square Toll-Free: 888.556.3998 Williamsville, New York 14221 Phone: 716.689.0871

E-mail: support@becsolutionsllc.com